

COMPUTER SYSTEMS COMPASS

PROGRAMMING TRAINING MANUAL



INSTRUCTION INDEX

		BY OCTAL OP	ERATION CODE			В	Y MNEMONIC O	PERATION COD	E
OCTAL OPERATION CODE	MNEMONIC OPERATION CODE	SECTION NUMBER	OCTAL OPERATION CODE	MNEMONIC OPERATION CODE	SECTION NUMBER	MNEMONIC OPERATION CODE	SECTION NUMBER	MNEMONIC OPERATION CODE	SECTION NUMBER
00.0 00.1 00.2 00.3 00.4 00.5 00.6 00.7 01 02.0 02.1-3 02.4 02.5-7 03.0 03.1 03.2 03.3 03.4 03.5 03.6 03.7 04.0 04.1-3 04.4 04.5 04.6 04.7 05.0 05.1-3 05.4 05.5 05.6 05.7 06.0-7 07.0-7 10.0 10.1-3 10.4 10.5-7 11.0 11.4 12.0-3 13.4-7 14.0 14.1-3 14.4 14.5 14.6 14.7 15.0 15.1-3 15.4 15.5 15.6 15.7 16.0 16.1-3 16.4 17.5 17.6 17.7 17.0 17.1-3 17.4 17.5 17.6 17.7 20 21 22 23 24 25 26 27 30 31 31 32 33 34 35 36 37	HLT SIZ SIZ SIZ SIZ SIZ SIZ SIZ SI	3.5.7 on 3.5.7 3.5.2 3.5.2 3.5.2 3.5.2 3.5.2 3.5.3 3.5.3 3.5.3 3.5.3 3.6.1 3.6.1 3.6.1 3.6.1 3.6.1 3.6.2 3.6	40 41 42 43 44 45 46 47 50 51 52 53.01 53.02 53.04 53.(0+b)0 53.(0+b)4 53.41 53.42 53.(4+b)0 53.(4+b)3 53.(4+b)4 55.0 55.1 55.2 55.3 55.4 55.5 55.6 57 60 61 62 63 64 65 70.0-3 70.4 70.5 70.6 70.7 71 71 72 73 73 74 74 75 77 76 77 77 77 77 77 77 77 77 77 77 77	STA, I STO, I SACH SQCH SWA, I STAQ, I SCHA, I STI, I MUA, I CPR, I TMQ TMA AQA TIA TMI AIA TQM TAM TAI TIM IAI LDI, I NO Operation ELQ	13.3.1 13.2.1 13.4.1 m 13.3.2 13.2.2 13.4.2 6.3 6.4 12.3.1 12.3.2 12.3.3 12.3.4 14.2.6 14.2.7 14.2.8 14.2.9 14.2.1 14.2.2 14.2.3 14.2.4 14.2.5 10.2.1 10.2.2 10.3 20.6 20.8.1 20.4 20.8.2 20.7 20.8.3 20.5 20.8.4 20.2 20.3 20.9.1 20.9.2 20.9.4 20.9.5 20.9.3 21.2 21.1	ADA,I ADAQ,I ADE AEU AIA ANA ANA,S ANI ANQ ANQ,S AQA AQE AQJ,EQ AQJ,EQ AQJ,JLT AQJ,NE ASE,S ASG,S AZJ,EQ AZJ,LT AZJ,NE CINS CON COPY CPR,I CTI CTI CTO DINT DVA,I DVAQ,I EAQ ECHA ECHA,S EINT ELQ ENA ENA,S ENI ENQ ENQ,S EOJ EUA ENA,S ENI ENQ ENQ,S EOJ EUA EXSE EINT ELQ ENA ENA,S ENI ENQ ENQ,S EOJ EUA ENA,S ENI ENQ ENQ,S EOJ EUA ENA,S ENI ENQ EZJ,LT FAD,I FPU,I FPU,I FPU,I FPU,I FSB,I HLT IAI IAPR IJD IJI INA INA,S INAC,INT INAW,INT INCL INI INPC,INT, B,N INQ INQ,S INS INTS IOCL ISD ISE ISG ISI LACH LCA,I LCAQ,I	3.3.1 6.1 14.2.8 13.2.2 9.5.2 7.4.2 7.4.2 7.4.3 7.4.3 9.5.1 13.4.2 3.5.3 3.5.3 3.5.3 3.5.3 3.5.3 3.5.2 3.5.2 3.5.2 3.5.2 3.5.2 20.9.5 20.9.2 211.4 20.10.5.1 20.10.5.1 20.10.5.2 3.3.4 6.4 13.4.1 8.2.6 8.2.6 21.1-2 13.3.1 3.4.4 3.4.4 13.2.1 20.10.5.1 20.10.5.2 3.3.4 6.4 13.4.1 8.2.6 8.2.6 21.1-2 13.3.1 13.4.4 3.4.4 13.2.1 120.9.1 14.2.2 14.2.3 12.3.1 12.3.3 12.3.5 9.5.3 3.5.7 3.4.1 3.4.4 3.4.1 3.6.2 3.6.3 3.5.7 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5 3.5	LDA, I LDA, I LDAQ, I LDAQ, I LDAQ, I LDAQ, I LDA, I LDAQ, I LDA, I LDQ, I LPA, I LQCH MEQ MOVE, INT MTH MUA, I NOP OTAC, INT OTAW, INT OUTC, INT, B,H PAUS QEL QSE QSE, S QSG QSG, S RAD, I RTJ SACH SBAQ, I SBAQ, I SBAQ, I SBCD SBE SCA, I SCAQ SCHA, I SCIM SEL SET SFPF SHA SHAQ SHQ SHQ SJ1 SJ2 SJ3 SJ4 SJ5 SJ6 SLS SCT SFPF SHA SHAQ SHQ SHQ SHQ SJ1 SJ2 SJ3 SJ4 SJ5 SJ6 SLS SCT SFPF SHA SHAQ SHQ SHQ SJ1 SJ2 SJ3 SJ4 SJ5 SJ6 SLS SCT SFPF SHA SHAQ SHQ SHQ SJ1 SJ2 SJ3 SJ4 SJ5 SJ6 SLS SCT SFPF SHA SHAQ SHQ SHQ SJ1 SJ2 SJ3 SJ4 SJ5 SJ6 SLS SCT SFPF SHA SHAQ SHQ SHQ SJ1 SJ2 SJ3 SJ4 SJ5 SJ6 SLS SCT STT, I STQ, I STA, I STAQ, I	3.1.1 14.2.6 3.1.3 7.2 3.1.2 7.4.1 8.2.2 11.1 10.3 11.2 3.3.3 6.3 20.8.3 20.8.4 20.7 20.5 10.4 & 20.10.5.3 13.3.2 3.6.1 3.6.1 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.1 3.6.1 3.6.2 3.6.2 3.6.2 3.6.1 3.6.1 3.6.2 3.6.2 3.6.6 3.5.6 3.6

Introduction to 3100/3200/3300/3500 Computer Hardware Introduction to SCOPE/COMPASS **COMPASS Instructions** Instruction Modification 48-bit Operations 48-bit, Fixed Point, Arithmetic **Logical Operations** Character Mode of Operation Inter-register Transfers Search and Move Operations Storage Tests Floating-point Operations 48-bit Register Operations B C D Digit Operations COMPASS Pseudo Instructions SCOPE Organization of I/O SCOPE Control Cards SCOPE Debugging Aids **COMPASS Assembly of Constants** Input/Output Without CIO Interrupts Sample COMPASS Programs Additional Exercises

3100 3200 3300 3500

COMPASS
PROGRAMMING
TRAINING
MANUAL

Aknowledgement

With the exception of an index, three appendices, two additional chapters, a few new sections and extensive editting, the very excellent programming training manual that follows has been written by Mr. H. D. Pridmore and his staff at Commonwealth Bureau of Census and Statistics in Australia. We are grateful to Mr. Pridmore and the Bureau for permission to modify and print their manual so that all 3100/3200/3300/3500 users may benefit from their efforts.

EDP Education Services Department Corporate Marketing Control Data Corporation May 8, 1967

		·		

CONTENTS

CHAPTER 1 - INTRODUCTION TO 3100/3200/3300/3500 COMPUTER HARDWARE

- 1.1 3200 HARDWARE
 - 1.1.1 Diagram of 3200 Computer
 - 1.1.2 Data Bus
 - 1.1.3 Arithmetic Section
 - 1.1.4 Program Control
 - 1.1.5 Block Control
 - 1.1.6 Diagram of 3200 Console Register Display
- 1.2 3200 CORE STORAGE
 - 1.2.1 Storage Word
 - 1.2.2 Word Addressing

CHAPTER 2 - INTRODUCTION TO SCOPE/COMPASS

- 2.1 INTRODUCTION TO THE SCOPE MONITOR
 - 2.1.1 SCOPE Library Tape
 - 2.1.2 SCOPE System Terms
 - 2.1.3 SCOPE Control Card
 - 2.1.4 SCOPE/COMPASS Run
 - 2.1.5 SCOPE/Program Execution Run
- 2.2 INTRODUCTION TO THE COMPASS ASSEMBLY SYSTEM
 - 2.2.1 Assembly Process
 - 2.2.2 General Word Addressing Instruction Format
 - 2.2.3 COMPASS Source Program Coding
 - 2.2.3.1 LOCATION Field
 - 2.2.3.2 OPERATION Field
 - 2.2.3.3 ADDRESS Field
 - 2.2.3.4 COMMENTS Field
 - 2.2.4 Coding Simple COMPASS Programs
 - 2.2.4.1 Beginning the Program
 - 2.2.4.2 Ending the Program
 - 2.2.4.3 SCOPE Entry
 - 2.2.4.4 Deck Structure for COMPASS Course Exercises

CHAPTER 3 - COMPASS INSTRUCTIONS

- 3.1 LOAD INSTRUCTIONS
 - 3.1.1 Load A
 - 3.1.2 Load Q
 - 3.1.3 Load Index
- 3.2 STORE INSTRUCTIONS
 - 3.2.1 Store A
 - 3.2.2 Store Q
 - 3.2.3 Store Index
- 3.3 ARITHMETIC, FIXED POINT, 24-BIT PRECISION
 - 3.3.1 Add to A
 - 3.3.2 Subtract from A
 - 3.3.3 Multiply A
 - 3.3.4 Divide A
 - 3.3.5 Replace Add
- 3.4 REGISTER OPERATIONS WITHOUT STORAGE REFERENCE
 - 3.4.1 Increase A
 - 3.4.2 Increase Q
 - 3.4.3 Increase Index
 - 3.4.4 Enter Register
- 3.5 JUMP INSTRUCTIONS
 - 3.5.1 Unconditional Jump
 - 3.5.2 Compare A with Zero, Jump
 - 3.5.3 Compare A with Q, Jump
 - 3.5.4 Return Jump
 - 3.5.5 Unconditional Halt
 - 3.5.6 Selective Jump
 - 3.5.7 Index Jump (Incremental/Decremental)
- 3.6 SKIP INSTRUCTIONS
 - 3.6.1 Skip if Equal
 - 3.6.2 Skip if Greater Than or Equal
 - 3.6.3 Index Skip Incremental/Decremental

CHAPTER 3 -

- 3.7 STORE WORD ADDRESS
- 3.8 SHIFT INSTRUCTIONS
 - 3.8.1 Shift Instruction Format
 - 3.8.2 Shift A and Shift Q

CHAPTER 4 - INSTRUCTION MODIFICATION

- 4.1 SIGN EXTENSION
- 4.2 ADDRESS MODES
- 4.3 INDEX MODIFICATION OF WORD ADDRESSING INSTRUCTIONS

CHAPTER 5 - 48-BIT OPERATIONS

- 5.1 LOAD AQ
- 5.2 STORE AQ
- 5.3 SHIFT AQ

CHAPTER 6 - 48-BIT, FIXED POINT, ARITHMETIC

- 6.1 ADD TO AQ
- 6.2 SUBTRACT FROM AQ
- 6.3 MULTIPLY AQ
- 6.4 DIVIDE AQ

CHAPTER 7 - LOGICAL OPERATIONS

- 7.1 LOGIC TABLES
 - 7.1.1 Logical "AND"
 - 7.1.2 Inclusive "OR"
 - 7.1.3 Exclusive "OR"
 - 7.1.4 Examples of Logical Operations Using Octal Numbers
- 7.2 LOAD A LOGICAL
- 7.3 LOAD COMPLEMENTS
 - 7.3.1 Load A Complement
 - 7.3.2 Load AQ Complement

CHAPTER 7 -

- 7.4 LOGICAL "AND" OPERATIONS
 - 7.4.1 Logical Product A
 - 7.4.2 AND of A and y
 - 7.4.3 AND of Q and y
 - 7.4.4 AND of Index Register Bb and y
- 7.5 EXCLUSIVE "OR" OPERATIONS
 - 7.5.1 Selectively Complement A
 - 7.5.2 Exclusive OR of A and y
 - 7.5.3 Exclusive OR of Q and y
 - 7.5.4 Exclusive OR of Index Register Bb and y
- 7.6 SELECTIVELY SET A

CHAPTER 8 - CHARACTER MODE OF OPERATION

- 8.1 INTRODUCTION
- 8.2 CHARACTER ADDRESS INSTRUCTIONS
 - 8.2.1 Load A Character
 - 8.2.2 Load Q Character
 - 8.2.3 Store A Character
 - 8.2.4 Store Q Character
 - 8.2.5 Store Character Address
 - 8.2.6 Enter Character Address into A
- 8.3 INDEX MODIFICATION OF CHARACTER ADDRESSING INSTRUCTIONS

CHAPTER 9 - INTER-REGISTER TRANSFERS

- 9.1 TRANSFERS BETWEEN THE A REGISTER AND INDEX REGISTERS
 - 9.1.1 Index Register to A Register
 - 9.1.2 A Register to Index Register
- 9.2 TRANSFERS BETWEEN THE A REGISTER AND THE REGISTER FILE
 - 9.2.1 Register File to A Register
 - 9.2.2 A Register to Register File
- 9.3 TRANSFERS BETWEEN THE Q REGISTER AND THE REGISTER FILE

CHAPTER 9 -

- 9.3.1 Register File to Q Register
- 9.3.2 Q Register to Register File
- 9.4 TRANSFERS BETWEEN INDEX REGISTERS AND THE REGISTER FILE
 - 9.4.1 Register File to Index Register
 - 9.4.2 Index Register to Register File
- 9.5 INTER-REGISTER ADDITION
 - 9.5.1 Add Contents of Q to Contents of A
 - 9.5.2 Add Contents of Index Register to Contents of A
 - 9.5.3 Add Contents of A to Contents of Index Register

CHAPTER 10 - SEARCH AND MOVE OPERATIONS

- 10.1 BLOCK CONTROL
- 10.2 SEARCH OPERATIONS
 - 10.2.1 Search for Character Equality
 - 10.2.2 Search for Character Inequality
- 10.3 MOVE INSTRUCTION
- 10.4 PAUSE INSTRUCTION

(as used with SEARCH/MOVE Instructions)

CHAPTER 11 - STORAGE TESTS

- 11.1 MASKED EQUALITY SEARCH
- 11.2 MASKED THRESHOLD SEARCH
- 11.3 STORAGE SHIFT
- 11.4 COMPARE (WITHIN LIMITS TEST)

CHAPTER 12 - FLOATING POINT OPERATIONS

- 12.1 INTRODUCTION
 - 12.1.1 Storage of Floating Point Numbers
 - 12.1.2 Normalizing the Coefficient
 - 12.1.3 Exponent
 - 12.1.4 Conversion Procedures

CHAPTER 12 -

- 12.1.5 Unpacking Floating Point Numbers
- 12.2 EXECUTION OF FLOATING POINT OPERATIONS
 - 12.2.1 Addition
 - 12.2.2 Subtraction
 - 12.2.3 Rounding of Floating Point Numbers
 - 12.2.4 Multiplication
 - 12.2.5 Division
- 12.3 FLOATING POINT INSTRUCTIONS
 - 12.3.1 Floating Point ADD
 - 12.3.2 Floating Point SUBTRACT
 - 12.3.3 Floating Point MULTIPLY
 - 12.3.4 Floating Point DIVIDE

CHAPTER 13 - 48-BIT REGISTER OPERATIONS

- 13.1 48-BIT E REGISTER
 - 13.1.1 Introduction
 - 13.1.2 Trapped Instructions for the E Register
- 13.2 TRANSFERS BETWEEN A AND E
 - 13.2.1 Transfer E_{II} to A
 - 13.2.2 Transfer A to E_{II}
- 13.3 TRANSFERS BETWEEN Q AND E.
 - 13.3.1 Transfer E_{I} to Q
 - 13.3.2 Transfer Q to $E_{\rm L}$
- 13.4 TRANSFERS BETWEEN AQ AND E
 - 13.4.1 Transfer E to AQ
 - 13.4.2 Transfer AQ to E
- 13.5 SCALE AQ
- 13.6 USE OF THE SCALE AQ INSTRUCTION

CHAPTER 14 - BCD DIGIT OPERATIONS

14.1 INTRODUCTION

CHAPTER 14 -

- 14.1.1 BCD Digits
- 14.1.2 Field
- 14.1.3 Sign Bits
- 14.1.4 E_D Register (In Machine)
- 14.1.5 E_D Register (On Console)
- 14.1.6 BCD Fault

14.2 BCD INSTRUCTIONS

- 14.2.1 Shift E_{D} Register
- 14.2.2 E_D Equal to ZERO Jump
- 14.2.3 E_{D} Less Than ZERO Jump
- 14.2.4 E_D Overflow Jump
- 14.2.5 Setting Field Length in D Register
- 14.2.6 Load E_D
- 14.2.7 Store E_D
- 14.2.8 Add to $E_{\rm D}$
- 14.2.9 Subtract From E_D
- 14.3 BCD TRAPPED INSTRUCTIONS

CHAPTER 15 - COMPASS PSEUDO INSTRUCTIONS

- 15.1 CONCEPTS OF PSEUDO INSTRUCTIONS
- 15.2 PROGRAM DEFINITION
 - 15.2.1 IDENT Instruction
 - 15.2.2 END Instruction
 - 15.2.3 FINIS Instruction
- 15.3 ASSEMBLY AREAS
 - 15.3.1 Introduction
 - 15.3.2 DATA Area
 - 15.3.3 Return Assembly Control to Subprogram PRG Area
 - 15.3.4 COMMON Area
 - 15.3.5 ORGR Instruction
- 15.4 STORAGE RESERVATIONS

CHAPTER 15 -

- 15.4.1 Word Block
- 15.4.2 Character Block
- 15.5 ENTRY AND EXTERNAL INSTRUCTIONS
 - 15.5.1 ENTRY Pseudo Instruction
 - 15.5.2 EXTERNAL Pseudo Instruction
 - 15.5.3 SCOPE Loading of Subprogram
- 15.6 SYMBOL DEFINITION BY EQUIVALENCING
 - 15.6.1 Introduction
 - 15.6.2 Word Equating
 - 15.6.3 Character Equating
- 15.7 COMPASS OUTPUT LISTING CONTROL
 - 15.7.1 REMarks
 - 15.7.2 NO LIST Instruction
 - 15.7.3 Resume LISTing Instruction
 - 15.7.4 SPACE Instruction
 - 15.7.5 New Page EJECT Instruction
 - 15.7.6 TITLE Instruction
 - 15.7.7 Comments

CHAPTER 16 - SCOPE ORGANIZATION OF INPUT/OUTPUT

- 16.1 INTRODUCTION
 - 16.1.1 Programmer Units
 - 16.1.2 Scratch Units
 - 16.1.3 Systems Units
- 16.2 CENTRAL INPUT/OUTPUT ROUTINE
 - 16.2.1 Introduction
 - 16.2.2 Calling Sequences
 - 16.2.3 Input/Output Operations
 - 16.2.4 Tape Control Operations
 - 16.2.5 Unit Status Requests
 - 16.2.6 Format Selection
 - 16.2.7 Page Control of the Line Printer

CHAPTER 17 - SCOPE CONTROL CARDS

- 17.1 INTRODUCTION
- 17.2 SEQUENCE CARD
- 17.3 JOB CARD
- 17.4 ENDSCOPE STATEMENT
- 17.5 ENDREEL STATEMENT
- 17.6 CTO STATEMENT
- 17.7 REWIND STATEMENT
- 17.8 UNLOAD STATEMENT
- 17.9 EQUIP STATEMENTS
 - 17.9.1 Hardware Definition
 - 17.9.2 Equating Logical Units
 - 17.9.3 Physical Unit Assignment
- 17.10 TRANSFER STATEMENT
- 17.11 LOAD STATEMENT
- 17.12 COMPASS LIBRARY CALLING STATEMENT
- 17.13 RUN STATEMENT
- 17.14 DIAGRAMMATIC DECK

CHAPTER 18 - SCOPE DEBUGGING AIDS

- 18.1 OCTAL CORRECTION CARDS
 - 18.1.1 Location Symbols
 - 18.1.2 Octal Corrections
 - 18.1.3 Relocation Factors
 - 18.1.4 Error Indicators
- 18.2 SNAP DUMPS
 - 18.2.1 Errors
 - 18.2.2 Location
 - 18.2.3 First and Last Word Addresses
 - 18.2.4 Mode
 - 18.2.5 Identification
 - 18.2.6 Note

CHAPTER 18 -

- 18.2.7 Example
- 18.2.8 Rules for Using SNAP
- 18.3 OTHER DEBUGGING AIDS
 - 18.3.1 Memory Map
 - 18.3.2 Abnormal Termination Dump
- 18.4 COMPASS ERROR CODES

CHAPTER 19 - COMPASS ASSEMBLY OF CONSTANTS

- 19.1 OCTAL CONSTANT PSEUDO INSTRUCTIONS
- 19.2 DECIMAL CONSTANTS, FIXED POINT
- 19.3 DOUBLE PRECISION AND/OR FLOATING POINT CONSTANTS
- 19.4 BCD CONSTANTS
- 19.5 BCD CHARACTER CONSTANTS
- 19.6 VARIABLE FIELD CONSTANTS
 - 19.6.1 Introduction
 - 19.6.2 Octal Mode
 - 19.6.3 Hollerith Mode
 - 19.6.4 Word Address Arithmetic Mode
 - 19.6.5 Character Address Mode
 - 19.6.6 Example of VFD Instruction

CHAPTER 20 - INPUT/OUTPUT WITHOUT CIO

- 20.1 INPUT/OUTPUT CHARACTERISTICS
 - 20.1.1 Introduction
 - 20.1.2 Interface Signals
 - 20.1.3 System Configuration
 - 20.1.4 Logical Sequence of Events for Initiating

 INPUT/OUTPUT Operations
- 20.2 CONNECT
- 20.3 SELECT
- 20.4 WORD ADDRESSED INPUT TO STORAGE

CHAPTER 20 -

20 5	MORD	ADDRESSED	OUTPUT	FROM	STORAGE

- 20.6 CHARACTER ADDRESSED INPUT TO STORAGE
- 20.7 CHARACTER ADDRESSED OUTPUT FROM STORAGE
- 20.8 INPUT/OUTPUT TO AND FROM THE A REGISTER
 - 20.8.1 Input Character to A
 - 20.8.2 Input Word to A
 - 20.8.3 Output Character from A
 - 20.8.4 Output Word from A
- 20.9 SENSING INSTRUCTIONS
 - 20.9.1 Sense External Status
 - 20.9.2 Copy External Status and Interrupt Mask Register
 - 20.9.3 Sense Interrupt
 - 20.9.4 Sense Internal Status
 - 20.9.5 Copy Internal Status and Interrupt Mask Register
 - 20.9.6 Comments on Internal Status and the Interrupt

Mask Register

- 20.10 CONSOLE TYPEWRITER INPUT/OUTPUT
 - 20.10.1 General Description
 - 20.10.2 Operation
 - 20.10.2.1 Set Tabs, Margins and Spacing
 - 20.10.2.2 Clear
 - 20.10.2.3 Status Checking
 - 20.10.2.4 Type In and Type Load
 - 20.10.2.5 Type Out and Type Dump
 - 20.10.3 Typewriter Console Switches and Indicators
 - 20.10.4 Character Codes
 - 20.10.5 Input/Output Instructions
 - 20.10.5.1 Set Console Typewriter Input
 - 20.10.5.2 Set Console Typewriter Output
 - 20.10.5.3 Pause Instruction

(as used with console typewriter

instructions)

CHAPTER 21 - INTERRUPTS

- 21.1 INTERRUPTS USING CIC
- 21.2 INTERRUPTS WITHOUT USING CIC
- 21.3 I/O USING CIC
- 21.4 INTERRUPT MASK REGISTER BIT ASSIGNMENTS
- 21.5 CIT ASSIGNMENTS

INTRODUCTION TO 3100/3200/3300/3500 COMPUTER HARDWARE


1.1 3200 HARDWARE

- 1.1.1 Diagram of 3200 Computer
- 1.1.2 Data Bus
- 1.1.3 Arithmetic Section
- 1.1.4 Program Control
- 1.1.5 Block Control
- 1.1.6 Diagram of 3200 Console Register Display

1.2 3200 CORE STORAGE


- 1.2.1 Storage Word
- 1.2.2 Word Addressing

The majority of the programming that will be done for the 3100/3200/3300/3500 computers will be done with a subset of the total instruction repertoire for the particular machine. The subset chosen for this manual applies primarily to the 3100/3200 computers because of the BCD instructions chosen. If this chapter were eliminated, what remains applies equally to all computers in the series. The 3300/3500 computers in addition to having different BCD instructions, have some additional features and instructions. These will not be discussed here. The student is referred to the appropriate machine reference manual for a description of those additions. The timing information included in this manual applies to the 3200/ 3300 computers. 3100 times are about forty percent higher; 3500 times are at least forty percent lower. Other then in the case of timing information and the BCD instructions, the manual points out those areas that are specifically 3200, which was the machine chosen as representative of those in the series.



3200 COMPUTER SYSTEM

1.1.1 Diagram of 3200 computer



1.1.2 Data Bus

The data bus is the path along which data flows between the various sections of the computer. The sections (storage, the arithmetic unit, the console typewriter, and the input/output section) are connected in parallel to the data bus. During execution of each instruction, program control determines which unique path is to be enabled so that the function called tor in the program instruction can be carried out.

The data bus contains a 24-bit register called the Data Bus Register (DBR) which is used to hold data temporarily during a data transfer.

1.1.3 Arithmetic Section

The arithmetic section of the 3200 processor consists of three operational registers, namely -

- (i) A arithmetic register
 (ii) Q auxiliary arithmetic register
 (iii) E optional arithmetic register.

(i) The A Register (Accumulator)

The A Register is the principal arithmetic register. It is a 24-bit register, whose contents can be displayed on the console of the 3200.

All arithmetic and logical operations use the A register in formulating a result. It is the only register with provision for adding its contents to the contents of a storage word or another register.

(ii) The Q Register (Quotient)

The Q register is an auxiliary register and is generally used in conjunction with the A register. It is a 24-bit register, whose contents can be displayed on the 3200 console. Combined with A it forms a 48-bit register, AQ. Most arithmetic operations possible with the A register are also possible with the AQ register. The Q register often is used to provide temporary storage for the contents of the A register while the A register is used for some other operation.

(iii) The E Register

This register acts as a supplement to the AQ register. It is a 48-bit register, whose contents can be displayed on the 3200 console, in the display sections usually occupied by A and Q. (The upper 24 bits of E - called $\rm E_U$ - are displayed in A, and the lower 24 bits of E - called $\rm E_L$ - are displayed in Q.) The register is used in 48-bit precision multiplication and division, and in floating point multiplication and division.

In BCD operations, the E register is designated the ${\rm E}_{\rm D}$ register, and its size is extended to 53 bits, to enable it to handle thirteen 4-bit characters, plus a sign bit.

1.1.4 Program Control

The program control section contains six operational registers, all of which may be displayed on the 3200 console. They are -

- (i) F program control register
- (ii) P Program address counter
- (iii) C Communication register
- (iv) B Three index registers, B, B, and B,

(i) The F Register

This 24-bit register is used to hold the instruction during the time it is being executed.

(ii) The P Register

This 15-bit register holds the <u>address</u> of the instruction currently being executed, and generates, in sequence, the storage addresses which contain the individual instructions. After execution of an instruction, P is altered to indicate the address of the next instruction to be read. The address is sent via the S (address) BUS to the specified storage module where the instruction is read.

(iii) The C Register

The 24-bit C register is used to enter quantities into Storage, A, Q, E, B or P registers via the console key board. The quantity is entered in C, and then transferred to the specified register when the "transfer" button on the keyboard is pushed.

(iv) The B Registers

The 15-bit B registers (Index registers) are used principally as counters and instruction modifiers.

1.1.5 Block Control

For a general description of the use of Block Control see Section 10.1.

(i) The Register File

The register file is a 64 word (24-bits per word) rapid access memory with a cycle time 0.5 microseconds. Although the programmer can access all registers in the file with the inter-register transfer instructions, certain registers are reserved for specific purposes. These are defined in the following table:

REGISTER NUMBER	RESERVED FOR
00-07	Modified I/O instruction word containing the current character address (Channel 0-7 control)
10-17	Modified I/O instruction word containing the last character address plus (or minus) one (Channel 0-7).
20	Current character address for search control
21	Source address for move control
22	Real time clock, current time
23	Current character address for typewriter control
24-27	Temporary storage
30	Last character address + 1 for search control
31	Destination address for move control
32	Real time clock, time at which to generate interrupt
33	Last character address + 1 for typewriter control
34-77	Temporary storage


Because of the fast access time, use of Registers 24-27 and 34-77 as temporary storage will speed up program execution. Other registers may also be used for temporary storage if their use will not disrupt operations in progress.

(ii) The Real Time Clock

The real time clock is a 24-bit counter that is incremented each millisecond. The current time is stored in Register 22. It is removed from storage each millisecond, updated, and compared with the contents of Register 32. When the two are equal, an interrupt condition occurs.

The clock has a period of 16,777,216 milliseconds (approximately 4 hours 40 minutes). It starts as soon as power is supplied to the computer. Its contents may be examined at any time by transferring them to the A register using an inter-register transfer statement. It may be reset to any 24 bit quantity (including zero) by loading A, and transferring the contents of A into Register 22.

1.1.6 Diagram of 3200 Console Register Display



1.2 3200 CORE STORAGE

1.2.1 Storage Word

27	26	25	24	23 18	17	12	11	06	05	00
Po	P ₁	P ₂	Рз	Character 0	Cha	aracter 1	Cha	aracter 2	Chara	cter 3
	Parit	y bit	ts			Characte	desig	nators		

The 3200 is a word machine with each word consisting of 28 bits. Each word may be regarded as four 6-bit characters as shown above, with parity bits for each character located in bits 24-27.

1.2.2 Word Addressing

Each word in the storage of the 3200 is addressable. The address of a particular word is its relative position in the storage. The first word is word 00000, the second is word 00001, the third 00002, etc. The address is specified as five octal digits, which may be broken down to indicate the actual location of the word in core.

The 3200 core is composed of <u>modules</u> of 8,192 words each. There may be up to four such modules attached to the computer, and the modules are numbered from 0 through 3. Thus an 8K 3200 would have only one module, numbered $0_8 (00_2)$, a 16K 3200 would have two modules, 00_2 and 01_2 , and so on.

Each 8K module is made up of two 4,096 word $\underline{\text{fields}}$, numbered field 0 and field 1.

Module 00

Field	Field
O	1
1	

Within each field, words may be regarded as numbered from 0000 to 7777_8 (4096_{10} words). The position of a word in a field is known as its Co-ordinate address in that field.

Thus a 15-bit address 01200_8 may be divided up to indicate its position in core as follows:

bits 00 - 11 indicate the co-ordinate address (1200₈)

bit 12 indicates the field (0)

bits 13 - 14 indicate the module (0)

Examples:

Address 31040_8 = Module 1, field 1, address 1040_8

Address 77777_8 = Module 3, field 1, address 7777_8

INTRODUCTION TO SCOPE/COMPASS

2.1 INTRODUCTION TO THE SCOPE MONITOR

- 2.1.1 SCOPE Library Tape
- 2.1.2 SCOPE System terms
- 2.1.3 SCOPE Control Card
- 2.1.4 SCOPE/COMPASS Run
- 2.1.5 SCOPE/Program Execution Run

2.2 INTRODUCTION TO THE COMPASS ASSEMBLY SYSTEM

- 2.2.1 Assembly Process
- 2.2.2 General Word Addressing Instruction Format
- 2.2.3 COMPASS Source Program Coding
 - 2.2.3.1 LOCATION Field
 - 2.2.3.2 OPERATION Field
 - 2.2.3.3 ADDRESS Field
 - 2.2.3.4 COMMENTS Field

2.2.4 Coding Simple COMPASS Programs

- 2.2.4.1 Beginning the Program
- 2.2.4.2 Ending the Program
- 2.2.4.3 SCOPE Entry
- 2.2.4.4 Deck Structure for COMPASS Course Exercises


2.1 INTRODUCTION TO THE SCOPE MONITOR

The SCOPE monitor is a program that provides a system of operator and programmer aids to increase through-put and to simplify the operator's job.

Its purpose is to increase job processing efficiency by increasing information through-put, and to minimize operator errors, operator intervention and idle computer time.

2.1.1 SCOPE Library Tape

The library tape serves as the source for the SCOPE operating system as well as those library routines operating under control of SCOPE. The tape consists of two files:



LIBRARY TAPE FORMAT

The first file consists of absolute binary information which, from this point on, will be considered the SCOPE operating system. The second file consists of relocatable binary subprograms such as COMPASS, FORTRAN, COBOL, etc.

2.1.2 SCOPE System Terms

RUN

The complete execution of a subprogram under the control of $\ensuremath{\mathsf{SCOPE}}$.

JOB

The sets of tasks assigned to SCOPE by the programmer. A job consists of one or more runs.

STACKED JOBS

A stack consists of one or more jobs. The termination of a job is signaled by the printout of the SEQUENCE card for the next job.

NON-STACKED JOBS

A stack which consists of only one job. The presents of the "NS" parameter on the job card indicates that this job is a non-stacked job.

The termination of a non-stacked job is signaled by the printout of "NORMAL END" or "ABNORMAL END" at which time processing will halt.

2.1.2 (cont.)

SUBPROGRAM

The smallest unit recognized by the SCOPE LOADER.


LUN

A two-digit decimal number representing a logical reference to a physical I/O unit.


2.1.3 SCOPE Control Card

Refer to Chapter 17

2.1.4 SCOPE/COMPASS Run



SCOPE/COMPASS RUN



SCOPE/PROGRAM EXECUTION RUN

2.2 INTRODUCTION TO THE COMPASS ASSEMBLY SYSTEM

- (a) COMPASS is the <u>COMP</u>rehensive <u>AS</u>sembly <u>S</u>ystem for use with Control Data Computers.
- (b) COMPASS operates under the SCOPE monitor system.
- (c) COMPASS enables the programmer to write machine language through the use of mnemonic instructions and symbolic addresses. The COMPASS assembler translates these instructions and addresses into machine language.
- (d) In COMPASS source language, the programmer is also able to specify constants, exercise control over subprogram communication and control the assembly process with a powerful set of PSEUDO (assembly) instructions.
- (e) A COMPASS program consists of a number of linked subprograms, each of which will be assembled independently and linked by the LOADER, prior to execution of the program.
- (f) A COMPASS subprogram consists of lines of coding preceded by an IDENT pseudo instruction, and followed by an END pseudo instruction. The size of the subprogram and the magnitude of the problems solved by it are at the discretion of the programmer.

2.2.1 Assembly Process

(a) Assembly language is much closer to machine code than languages like FORTRAN and COBOL. A line of FORTRAN coding may generate many machine instructions (perhaps in the ratio of 1:10). Most COMPASS instructions generate only one machine instruction.

Example: STA COUNT


If COUNT is located at address 1748,

this instruction would be assembled as

40000174

(b) The assembly process may be represented diagrammatically as follows:

DIAGRAM OF THE ASSEMBLY PROCESS




- Note: (a) The COMPASS assembly program converts programs written in COMPASS into machine language for execution under the SCOPE monitor system.
 - (b) Source programs may be punched on cards or paper tape, or written on magnetic tape.
 - (c) Output from the assembler includes an assembly listing and a relocatable binary object deck. The output deck may be punched out on cards, or written on a magnetic tape for immediate execution.

- (d) What does the assembler do?
 - (i) Allocates storage locations to instructions and to blocks defined in pseudo or area-definition instructions. Note use of "ORGR".
 - (ii) Replaces symbolic addresses with allocated storage locations from (i).
 - (iii) Replaces symbolic instruction addresses with actual instruction addresses from (i).
 - (iv) Indicates index register use and/or indirect addressing in the relevant bits of the necessary instructions.
 - (v) Converts mnemonic operation-codes to machine language equivalents.
 - (vi) Stores literals in a special literal table, after checking for any prior use of that literal.
 - (vii) Replaces literals in the instructions with the addresses of the table locations of the literals.
 - (viii) Check for assembly language (source language) errors and generates necessary diagnostic messages.

Most assemblers perform these functions in a number of passes. The source program is first written on to tape, at the same time carrying out some of the above functions. Then the tape is passed against the assembler at least once more to carry out the remainder of the functions.

2.2.2 General Word Addressing Instruction Format

The 3200 (24-bit) word addressing instruction takes the following general form -



Where f = function code of 6 bits.
Range is 00₈ through 77₈.
This code determines the type of action to be carried out.

e.g. 20g = Load the A register.

 31_8 = Subtract from the A register.

- Addressing mode of 1 bit.
 If this bit is a zero, direct addressing is carried out.
 If this bit is a 1 bit, indirect addressing is carried out.
- o = Index designator of 2 bits.

 If b = 00, no index is used

 If b = 01, index 1 is used

 b = 10, index 2 is used
 - b = 10, index 2 is used b = 11, index 3 is used.
- m = Execution address of 15 bits. This is the <u>address</u> in memory at which data required for execution will be found. The 24-bit quantity found at that address will be used in a manner determined by the rest of the instruction.
- y = Operand of 15 bits.

 This specifies a 15 bit quantity which will be used as data in some way. It is the actual data, not the address of the data.

Exercise: Divide up the following octal instructions into their components:

Note that the address "m" specified in a word address instruction can be divided further to indicate its actual location in storage.

2.2.3. COMPASS Source Program - Coding

The following fields are used on the COMPASS coding sheets and on COMPASS punched cards.

NAME OF FIELD	COLUMNS ON CARD OR CODING SHEET
Location	1 ~ 8
Operation	10 - 20
Address	21 - 40
Comments	41 - 72
Identification	73 - 80

The use of these fields is discussed following the samples of the COMPASS CODING FORM and the COMPASS CARD.

Instructions in subprograms to be assembled by COMPASS are written on coding forms. The information on the coding form will be punched into cards or prepared on other suitable media for input to COMPASS. Following is a sample COMPASS CODING FORM.

	COMPASS CODIN	G FORM	0.0	NTROL DATA	NAME	
PROGRAM					PAGE	
ROUTINE					DATE	
LOCATION	OPERATION, MONTHERS ABOVE	SSS FRELD	COMMENTS			MENT .
10101010101010	• • • • · · · · · · · · · · · · · · · ·	atestrelacias inclusion in Substitution in Sub	को अधिको को व्यो को स्थान स्थान स्थान । 	edeste initalminiminimini	enter les l'estentes l'entes l'estent aut.	Tal Market Line to State of St
						4
11111			بيبيين		ستستست	
111111						
			<u> </u>		ببببييي	
					حسيسي	4
11111						4
						ستنتا
			<u></u>	بينينين		
					بتستنيين	
			<u></u>			44444
			<u></u>			
			<u></u>	طللتليين		4
						44444
			minan			
			uduuu			
				سسسسس		4
	سنسسبك		سسسبس			
			minu			4
						4
	<u>. </u>		سسسب		ببببببب	
			سسسبس			سسسب
	. 🛮		minu		للتنبيين	

COMPASS CODING FORM (half-size)

Each line of the coding form represents one card when punched into cards.

Following is a sample of the COMPASS CARD.

1															į																																																					
ŀ															ì																																														1							
		LOC	CAT	101	N	ı						TIC			į							ΑD	DR	ES	s	FIE	LE	,																		co	MN	ŒΝ	TS															10	DEN	ıΤ		
0	0	0 1	0 () (9	0	0	0 0	0	0	o	0	0 (, 0	9	0	0 0	0	0	0	0	0	0 () () (0	0	0	0	0	0 1	0 (0	0	0	0 (0	0	0	0	0	0 1	0 (0 0	0	0	0	0	0	0 (0 (Ö	0	0	0 (0 0	0	0	0	0	olr	0 1	0 1	0 1	0 () (0	0
1	2	3 .	4 5	6	7	8	9 1	0 11	12	13	14	15	6 1	7 18	19	20	21 2	2 23	24	25	26	27 :	28 2	9 3	0 3	1 32	33	34	35	36 :	37 3	8 3	9 40	41	42	ŧ3 4	4 4	5 46	47	48	49	50 5	51 5	2 5	3 54	55	56	57	58 5	59 6	0 61	62	63 (64 6	65 6	6 67	68	69	70	π:	72	13 7	74 7	75 7	<i>1</i> 6 7	7 71	, 79	80
1 2 3	1	1	1 1	1	1	1	1	1 1	1	1	1	1	1 1	1	1	1	1 1	1	1	1	1	1	1 1	1	1	1	1	1	1	1	1	1 1	1	1	1	1	1 1	1	1	1	1	1	1	1 1	1	1	1	1	1	1 1	1	1	1	1	1	1 1	1	1	1	1	1	1	1	1	1 1	1 1	1	1
2	2	2 :	2 2	2 2	2	2	2	2 2	2	2	2	2 :	2 2	2 2	2	2 :	2 2	2	2	2	2	2	2 2	2 2	2 2	. 2	2	2	2	2	2 :	2 2	2	2	2 :	2 :	2 2	!				•	ø				•		•	h							2	2	2	2	2	2 :	2 :	2 :	2 2	2 2	2	2
3	3	3 :	3 3	3	3	3	3	3 3	3	3	3	3	3 3	3	3	3	3 3	3	3	3	3	3	3 3	3 3	3	3	3	3	3	3	3 :	3 3	3	3	3	3 :	3	ì				1	1		1	١				þ	7						3	3	3	3	3	3 :	3 :	3	3 :	3	3	3
4	4	4	4 4	ļ 4	4	4	4	1 4	4	4	4	4	4 4	4	4	4	4 4	4	4	4	4	4	4 4	1 4	ļ 4	4	4	4	4	4	4	1 4	4	4	4	4 4	! 4	ļ		4				L L	1.00	l											4	4	4	4	4	4 4	4 4	4 .	4 4	1 4	. 4	4
5	5	5 !	5 5	5 5	5	5	5	5 5	5	5	5	5	5 5	5	5	5	5 5	5	5	5	5	5	5 5	5 5	5	5	5	5	5	5	5 :	5 5	5	5	5 !	5 :	5 5	i	1	·					4.00			ı	ı								5	5	5	5	5	5 !	5 !	5 !	5 :	j 5	5	5
6	6.	6 1	6 6	6	6	6	6	6 6	6	6	6	6	6 8	6	6	6	6 E	6	6	6	6	6	6 6	6	6	6	6	6	6	6	6 (6 E	6	6	6	6 (6					_						J		Ì							6	6	6	6	6	6 (6 (6 (6 f	6	6	6
7	7	7	7 7	1 7	7	7	7	17	7	7	7	7	7 7	17	7	7	7 7	7	7	7	7	7	7 7	7 7	1 7	7	7	7	7	7	7	7 7	7	7	7	7 7	7	,				4		ı	•			_									7	7	7	7	7	1	7	7	7 7	17	7	7
8	8	8	8 8	8	8	8	8	8 8	8	8	8	8	8 8	8	8	8	8 8	8	ŝ	8	8	8	8 8	3 8	8 8	8	8	8	8	8	8 8	8 8	8	8	8	8 8	8	8	8	8	8	8 (8 8	8 8	8	8	8	8	8 1	8 8	8	8	8	8	8 8	3 8	8	8	8	8	8	8 1	8 1	8 (8 8	8 8	8	3
, -	9	-			9	- ;	energy.		•	-	9	9 :	9 9	9	9	9	9 9	9	9	9	9	9	9 9	9 9	9	•	•	•	•	•	•		9	_	-	•	-	•	•	9	9	9 9	9 9	9 9	9	9	•	•	•	• •		•	•	•	٠,		•	9	•	•	٠,,	•	•	•	• •		•	•
ᄔ	2	3	4 :	6	7	8;	3 1	0 11	12	13	14	15 1	6 F	1.11	19	20	1 2	2 23	24	25	26	21 2	28 2 T 12	9 3	0 3	32	33	34	35	36	37 3	8 3	9 40	41 4	(2 4	3 4	4 45	46	47	48	19 :	iO 5	1 5	2 53	54	55	56	57	58 5	9 6	0 61	62	63 (64 (55 6	6 67	68	69	70	71 7	1217	3 7	14 7	15 7	76 T	1 70	79	80

COMPASS CARD (full size)

2.2.3.1 LOCATION Field

Symbol

lic	Address	of the	instruction	written	on that	line.
e.,	g.	L ø Ø₽	ADA	TABLE		
			-			
			-			
			•			
			UJP	L Ø ØP		
<u>OR</u>	Symboli instruc		s of a stor	age area	set up	by a pseudo
e.,	g.	ALEK	øст	4		
			-			
			-			
			-			
			LDA	V TĚK		
Re	strictio	ns - (a)	1-8 chara			be right
		(b)	First cha			
		(c)	Special c		s are no	t allowed,
_	_	(d)			re illeg	al.
Ex	amples:					

<u>Li</u>	EGAL	<u>I</u>	LLEGA L
ABCDE	A1A1A1	1A1A1A	Z Z
A1234	XYZ.23	TØM+5	ABCDEFGHIJ
х	PART3	27	FØG*

Special Comment Card

An asterisk in Column 1 of the location field means that the rest of the card will be treated as if it is a comment.

2.2.3.2 OPERATION Field

This field can contain

- (a) Mnemonic operation codes.
- (b) Pseudo instruction Mnemonics.
- (c) Macro instruction names.
- (d) Octal instructions 00₈-77₈.

The code must begin in col. 10, otherwise it will assemble as 00_8 (halt code). Modifiers are written in this field.

e.g. CHAR BSS,C 4 means set up an area consisting of 4 $\underline{\text{characters}}$ and labelled "CHAR".

Examples:

05

BSS

ENA,S

LDA

LDA, I

INPC, INT, B, H

MACNAME

2.2.3.3 ADDRESS Field

This field can contain:

- (a) Symbols
- (b) Constants
- (c) Special Characters
- (d) Literals
- (e) Expressions

The address field can begin anywhere after the operation field, provided it is separated from the operation field by at least one blank.

2.2.3.3 (cont.1)

However, it must begin before column 41, and finish before column 73.

(a) Symbols:

A symbol appearing in the address field must be defined by appearance in the location field of an instruction in the subprogram, or be declared as external. If it is not so defined, an error flag "U" - undefined symbol - will be given on the listing. The symbol may be relocatable or non-relocatable. The value assigned to a non-relocatable symbol will not be modified on loading.

Examples: LDA CIC.2 (relocatable)

CIC.2 ENA C

LDA INTADDR (non-relocatable)

INTADDR EQU 2

(b) Constants:

Integer constants can represent a number of functions depending on the type of instruction -

e.g. octal address (LDA) (LDA 100B)
constant value (ENA) (ENA 100B)

shift factor (SHA) (SHA 6)

Octal integers must be suffixed by the letter B.

NOTE: Numbers in address field are assumed to be decimal unless followed by a B.

(c) Special Characters:

Two special entries may be made in the address field (i) A single asterisk is interpreted as the current value
of the address counter when the * is encountered.

Example: ENA 0

LDA *-1

means: Load the A register with the instruction preceding the LDA instruction.

(i.e. with assembled ENA 0)

(ii) The double asterisk causes the address portion of the instruction to be assembled with a 1-bit in each bit position, and is used where modification of the address will take place during execution.

Example: START UJP **:
Assembled as 01077777

(d) Literals:

If the address field refers to an operand (a value), the entry may be a literal, expressed as -mv.

where m = the mode
v = the value

Double precision literals are expressed as =2mv.

2.2.3.3 (cont.2)

The mode of the literal may be:

(i) Decimal

DVA = D23

DVAQ =2D2753

(ii) Octal

LDA = Ø777

LDAQ =2Ø77777777777777

(Up to 16 octal digits may be specified for double precision)

(iii) Hollerith

LDA =HABCD (max: 4 characters)

LDAQ =2HABCDEFGH (max: 8 characters)

(e) Address Expression:

Address expressions may be formed.

Examples: LDA TØM-2

ENA SYM+46B

SYM EQU 275B

Subprogram, data and common relocatable symbols may be mixed.

NOTE: External symbols, the double asterisk and literals may not appear in an address expression.

2.2.3.4 COMMENTS Field

Comments may be included with any instruction. A blank column must separate them from the last character in the address field and they may extend to column 72.

Comments have no effect on assembly, but will be included on the assembly listing.

It is highly recommended that liberal use should be made of comments and comments cards.

An example is shown on the following page.

2.2.3.4 (cont.)

	IDENT	øne	
*			
* COMPASS	cøurse	EXERCISE 3	
*	J. SMITH		
*			
	ENTRY	START	*SCOPE ENTRY*
START	UJP	**	
	enq	14B	
	ENA	0	INITIALIZATION
	STA	SUM	OF COUNTERS
	STA	cøunt	
*			
*			
LØØP	LDA	SUM	
	ADA	cøunt	
	STA	SUM	MAIN
	LDA	cøunt	LØØP
	AQJ,EQ	START	
	INA	1	
	STA	Cøunt	
	UJP	LØØP	
*			
*			
*			
cøunt	BSS	1	
SUM	BSS	1	

START

END

2.2.4 Coding Simple COMPASS Programs

2.2.4.1 Beginning the Program

The first card in the deck must be an IDENT card. This card has the word IDENT punched beginning at Column 10, and the program name (of 1-8 alphanumeric characters, the first of which must be alphabetic) punched beginning at Column 20.

Examples:

	1 2 3 4 5 6 7 8	9 0	39 40 41 42 43
	1 1 2 1 1 1	IDENT TEST 42	
		and the second s	<u></u>
or		IDENT G427	
or	20 (17 (17 (17 (17 (17 (17 (17 (17 (17 (17	IDENT OPCODER	
			-
			1

2.2.4.2 Ending the Program

The last card in the deck must be an END card. The word END is punched beginning at Column 10, and the entry point (the beginning instruction in the program) is punched beginning at column 20. (However, see later section on END statement in relation to programs containing more than one sub-program).

Examples:

	1	10	20
or		END	START BEGIN
or		END	løøp in

2.2.4.3 SCOPE Entry

So that the program can be run under SCOPE, it is necessary to ensure that control returns to SCOPE when the program is finished. The entry point into the program should take the following form to enable this to be done:

	1	10	20
	START	UJP	**
or	BEG IN	UJP	**
or	Løøpin	UJP	**

This will be the first executable statement in the program. SCOPE will enter the return address into the location START instead of the two asterisks. The last executable instruction in the program should be a jump back to the beginning so that control can be returned to SCOPE.

Examples:

	1	10	20
or	тøм	UJP UJP	START BEGIN LØØPIN

2.2.4.4 Deck Structure for COMPASS Course Exercises

```
(i) Assembly only
          7SEQUENCE,666
          <sup>7</sup><sub>9</sub>JOB,1112115,6404,5
          COMPASS,L
              (COMPASS source deck
                 FINIS
                              (punching begins in column 10)
                   (end of file card)
 (ii)
         Assembly and execution:
         7SEQUENCE,666
         <sup>7</sup>JOB,1112115,6404,3
         7EQUIP, 56=MT
         COMPASS,L,X
              COMPASS source deck
                 FINIS
         7LOAD, 56
         7RUN,4
                 Data
         77
                   (end of file card)
(iii)
         Alternative "assembly only".
         Use all cards as for execution, except RUN and DATA.
         Any LOADER errors will then be indicated, but the
         program will not be executed.
 NOTE: 1. The \frac{7}{9} is a multiple punching in column 1 of the card.
         2. The end of file card has a multiple 7,8 punching in
             columns 1 and 2. It signifies the end of the job.
             (EOF cards used on other systems that use
                12 12
                1 1
                 4 4
                       in column 1 thru 4 are also acceptable.)
            7 7 7 7
            8 8
```

COMPASS INSTRUCTIONS

- 3.1 LOAD INSTRUCTIONS
 - 3.1.1 Load A
 - 3.1.2 Load Q
 - 3.1.3 Load Index
- 3.2 STORE INSTRUCTIONS
 - 3.2.1 Store A
 - 3.2.2 Store Q
 - 3.2.3 Store Index
- 3.3 ARITHMETIC, FIXED POINT, 24-BIT PRECISION
 - 3.3.1 Add to A
 - 3.3.2 Subtract from A
 - 3.3.3 Multiply A
 - 3.3.4 Divide A
 - 3.3.5 Replace Add
- 3.4 REGISTER OPERATIONS WITHOUT STORAGE REFERENCE
 - 3.4.1 Increase A
 - 3.4.2 Increase Q
 - 3.4.3 Increase Index
 - 3.4.4 Enter Register
- 3.5 JUMP INSTRUCTIONS
 - 3.5.1 Unconditional Jump
 - 3.5.2 Compare A with Zero, Jump
 - 3.5.3 Compare A with Q, Jump
 - 3.5.4 Return Jump
 - 3.5.5 Unconditional Halt
 - 3.5.6 Selective Jump
 - 3.5.7 Index Jump (Incremental/Decremental)
- 3.6 SKIP INSTRUCTIONS
 - 3.6.1 Skip if Equal
 - 3.6.2 Skip if Greater Than or Equal
 - 3.6.3 Index Skip Incremental/Decremental
- 3.7 STORE WORD ADDRESS
- 3.8 SHIFT INSTRUCTIONS
 - 3.8.1 Shift Instruction Format
 - 3.8.2 Shift A and Shift Q

Chapter 3

3.1.1 Load A

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	
	LDA,I , , , b	

23	18	17	16 15	14 00
	20	а	b	m

a = addressing mode designator

b = index designator

m = storage address.

Description: Loads A Register with the 24-bit contents of storage address M, where $M = m+(B^b)$. NOTE: () indicates contents of.

(i) If the contents of location $100_{\rm R}$ in memory is Examples: 52307777, what will be the contents of A after execution of the following statement?

> LDA 100B Answer : (A) = 52307777

(ii) If location 100₈ is called by the symbolic address LØC, what will be the contents of A after execution of the following statement?

> LØC LDA Answer : (A) = 52307777

(iii) A block of memory in octal is as follows:

LØC 00 00 00 01 00 00 00 10 00 01 00 00 00 10 00 00

What will be the contents of A after executic of the following statement?

LØC+4

Answer : (A) = 00 01 00 00

Exercises on Load A:

(i) LØC LDA

> LDA LØC

What will be the contents of A at the end of the above section of a program?

(The function code for LDA = 200).

(ii) If location 1018 contains

3.1.1 (cont.)

What is the octal amount loaded in A as a result of the following instruction?

LDA 101B 520376/4

(iii) If MASK is location 1058, and a block of memory is as follows,

104	1234 1234
105	7023 1307
106	1111 2222
107	6073 4261
110	3333 3333
111	4444 3066

What will be in A after execution of the following instruction?

LDA MASK+3

(iv) The instruction to be executed is:

LDA =D43

Which answer gives the correct contents of A after the instruction has been executed?

- a. 43g
- b. 35₁₀
- c. The contents of location 43
- d. 53₈

3.1.2 Load Q

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
1 1 1 : 1 1 1	LDQ,I m,b
. [2:5:+:4:5:17:18	0 11 122 123 124 125 125 125 125 126 127 128

23	18	17	16 15	14	00
21		а	b	m	

a = addressing mode indicator

b = index designator

m = storage address.

<u>Description</u>: Load Q with a 24-bit quantity from storage address M where $M = m + (B^b)$

Examples: (i) LDQ MASH

Load Q with the 24-bit quantity at the symbolic address MASK.

(ii) If MASK contains 00001111

LDQ MASK

(Q) = 0000 1111

3.1.2 (cont.1)

(iii) If MASK = location 1048 and a block of memory is as shown, what will be the contents of Q after execution of the following instruction?

MASK-4

LDQ

•	
76	14 00 00 20
77	25 25 52 52
100	11 22 33 44
101	55 66 77 00
102	17 53 17 53
103	20 64 20 64
104	31 75 31 75
105	42 06 42 06
106	53 17 53 17
107	64 20 64 20
	(Q) = 11 22 33

Exercises on Load Q

(1) What will be the contents of Q after execution of each of the following instructions? (The block of memory to be used is shown below).

00267	00	00	01	01
	20	10	40	40
	11	11	17	17
	20	20	20	20
	16	25	34	07
LØC	60	60	60	60
	21	22	23	24
	10	00	00	10

- (a) LDQ 272B
- (b) LDQ 184
- (c) LDQ LØC-3
- (d) LDQ L ϕ C+2
- (2) If PLACE = location 2617_8 , and a block of memory is as shown,

			26	
	12	50	37	46
	23	61	40	57
02616	34	72	51	60
	45	03	62	71
	56	14	73	02
	67	25	04	13
	70	36	15	24
	01	47	66	65

3.1.2 (cont.2)

What will be the contents of Q after execution of each of the following instructions?

- (a) LDQ 2613B
- (b) LDQ PLACE-1
- (c) LDQ PLACE+3
- (d) LDQ 1427

3.1.3 Load Index

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	LDI,I m,b
- : 2 : \$: 4 : 5 : 5 : T : 8	

23 18	17	16 15	14	00
54	a	b		m

a * addressing mode designator

b = index designator

m = storage address

<u>Description</u>: Load Index Register B^b with the lower 15 bits of the contents of storage address m. No address modification using index registers is possible.

"b" indicates which index register is to be loaded.

Examples:

(i) If
$$(CIØ) = 12345670$$

What will be the contents of index register 2 as a result of the following instruction?

Answer:
$$B_2 = 45670$$

(ii) A block of memory is as shown:

ГÒС	0	0	0	0	0	0	0	1	
	7	7	7	7	7	7	7	7	_
	2	3	4	2	3	4	2	3	
	1	0	4	1	0	4	0	4	_
	4				1				
	2	0	Ô	2	2	1	2	4	
	4	1	2	3	4	4	1	4	_

The index registers are as follows:

What will be the contents of the registers after the following?

LDI	Løc+3, 3
LDI	Løc+6,1

3.1.3 (cont.)

 $\underline{\text{Answer:}} \quad \mathbf{B}_{1} = 34414$

 $B_2 = 00001$

 $B_3 = 10404$

Exercises on Load Index instruction

(1) What will be the contents of the index registers after execution of each of the following instructions, if

(CAB) = 00100001

(STØRE) = 77777771

(TEMP) = 40100010

(HIGH) = 20002020

 $(L\phi C3) = 33003303$

- (a) LDI CAB, 1
- (b) LDI HIGH, 3
- (c) LDI STØRE, 2
- (d) LDI TEMP, 1
- (e) LDI LØC3,3
- (f) LDI HIGH, 2
- (2) A block of memory is as shown:

If TAG = Location 410₈, what will be the contents of the Index registers after execution of the following instructions?

- (a) LDI TAG-2,3
- (b) LDI TAG+4,1
- (c) LDI 411B, 2
- (d) LDI TAG, 1
- (e) LDI TAG+2,3

3.2 STORE INSTRUCTIONS

3.2.1 Store A

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	STA,I m,b
	0 (11 111 114 114 115 116 1 5 118 119 119 110 1111 115 115 15 15 15 15 15 15 15 15 15

23	18	17	16 15	14	00
4	0	а	b	m	

a = addressing mode designator

b = index designator

m = storage address.

 $\frac{\text{Description}}{\text{location M.}} : \text{Stores the contents of the A Register in storage location M.} \quad (\texttt{M} = \texttt{m+}(\texttt{B}^b)). \quad \texttt{Contents of A are unchanged.}$

Examples: (i) STA HØLD

The value in A is stored in the location specified by the symbol HØLD.

(ii)(A) = 1212 3434

TEMP = Location 1018

 $HØLD = Location 103_8$

100	00 00 00 00	
101 .	11 11 11 11	TEMP
102	22 22 22 22	
103	33 33 33 33	HOLI
104	44 44 44 44	
105	55 55 55 55	
106	66 66 66 66	
107	77 77 77 77	
110	00 00 00 00	

What will be contained in the above block after the following:

LDA	100B
STA	TEMP +2
LDA	HØLD− 2
STA	106B
LDA	нøld +5
STA	TEMP

Answer:

100	00	00	00	00
101	00	00	00	00
102	22	22	22	22
103	00	00	00	00
104	44	44	44	44
105	55	55	55	55
106	11	11	11	11
107	77	77	77	77
110	00	00	00	00

Exercises on STA Instruction

(i) If TEMPY is location 3028, and the block of memory shown results from the following instruction

STA TEMPY+4

What were the contents of A before execution of the instruction?

301	7723 7723
302	1111 1111
303	2222 2222
304	3044 6133
305	2442 4224
306	1212 3434
307	7777 5555

(ii) If HØLD = Location 1038 and TAG = Location 1018, what will be the contents of the block of memory below after execution of the following instructions?

LDA HØLD-1
STA TAG+3

(iii) If the above instructions were followed by

LDA 101B STA 69

LDA TAG

STA TAG -1

LDA HØLD

STA HØLD+3

What would be the final contents of the block of memory?

TAG+5

3.2.2 Store Q

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	STQ,I m,b
	C de lie lie lie lie lie lie lie les les les les les les les les les le

23	18 17	16 15	14	00
41	á	b	m	

a = addressing mode designator

b = index designator

m = storage address

3.2.2 (cont.)

Description: Stores the 24-bit quantity in Q at address M,

where $M = m + (B^b)$

Example:

*+1 LDQ

RESULT STQ

(= 41 00 05 00)

ORGR

BSS

500B

RESULT

1

What would be the contents of RESULT after execution of the above?

Answer: RESULT = 41000500

Exercise :

A block of memory is as shown:

What will be its contents after execution of the following?

LØC+3 LDQ LØC+1 STQ LØC+2 LDQ MASK+1 STQ MASK-4 LDQ LØC +6 STQ

3.2.3 Store Index

LOCATION	 OPERATION, MODIFIERS ADDRESS FIELD
	STI,I m,b
1 2 3 4 3 4 7	 to the listing in the training to be the trained between the training to the training of the training to the t

23	18	17	16 15	14	00
	47	а	b	m	

a = addressing mode designator

b = index designator

m = storage address

Store the (B^b) in the lower 15 bits of storage address m. N.B. The upper 9 bits of m remain unchanged. "b" indicates the index register. If b = 0, the lower

15 bits of "m" are set to zero.

Description:

Examples: (i) STI TMP2,2 where (TMP2) = 40050012 $(B^2) = 63636$

After execution (TMP2) = 40063636

(ii) If (FIELDA) = 31244444 (CHANGE) = 11111111

What will be the contents of TEMPY after execution of the following?

LDA FIELDA
STA TEMPY
LDI CHANGE, 3
STI TEMPY, 3

Answer: (TEMPY) = 31211111

(iii) If (B¹) = 00502 STA ** LDA *-1

> STA HØLD STI HØLD, 1

What will be the contents of HØLD?

Answer: (HØLD) = 4000 0502

Exercises on Store Index instruction

(1) If (L/C) = 21043072 $(B^2) = 00004$

> What will be contents of LØC after execution of the following? STI LØC,2

(2) If $(L \not OC) = 21043072$ (TEMP) = 00140001

What will be the contents of L/ β C and TEMP after execution of the following?

LDA LØC
LDI TEMP, 2
STA TEMP
STI TEMP, 2

(3) If (TEMP) = 23002000, (BIG) = 77777772, and (HØLD) = 00000001, What will be contents of TEMP and BIG after execution of the following?

LDA TEMP STA HØLD MI BIG,3 STI HØLD LDI TEMP,3 STI BIG,3 LDA HQLD STA TEMP

3.3 ARITHMETIC, FIXED POINT, 24-BIT PRECISION

3.3.1 Add to A

LOCATION	OPERATION MODIFIERS ADDRESS FIELD
	ADA, I m, b
ه () بغاره و درغانا	\$

23	18	17	16 15	14	00
30)	а	b	m	

a = addressing mode designator

b = index designator

m = storage address

Description:

Adds the 24 bit quantity located at address M to the contents of Register A. The result is stored in A. $M = m + (B^b)$.

Examples:

(i) If $(100_8) = 10001010$

(A) = 00077777

What will be the contents of A after execution of the following instruction?

ADA 100B

Answer:

(A) = 10101007

(ii) If ØPR = location 100₈ in the block of memory shown, what will be the contents of A and index register 2 after execution of the following?

 $B_2 = 00014$

100	0	0	0	0	0	0	1	1
101	-0	0	1.	4	1	3	1	0
102	, 2	1	0	0	0	0	0	5
103	·. 1	4	0	1	4	0	0	0
1Q4	0	0	7	7	1	7	7	7
105	2	0	2	0	1	0	2	0
LDA	ØPR+2							
STIA	ØPR+-4							

LDA ØPR+5

ADA ØPR+2

LDI ØPR+1,2

Answer:

(A) = 55201034

 $(B_2) = 41310$

3.3.1 (cont.)

Exercise:

A block of memory is as shown:

- (a) Write a program segment which will add together the contents of locations 100, 102, 104 and 106 and store the result in 107.
- (b) Write a program segment which will add up locations 101 and 102 and store the result in 103, add 103 and 104 and store the result in 105, and add 105 and 106 and store the result in 107.

3.3.2 Subtract from A



a = addressing mode designator

b = index designator

m = storage address

 $\frac{\text{Description}\colon}{\text{from (A).}} \text{ Subtracts the 24-bit quantity located at address M} \\ \text{from (A).} \text{ The difference appears in A. M = m + (B^b).}$

Examples:

(i) If (A) = 10404040(100_{8}) = 10303030

SBA 100B

Answer: (A) = 00101010

(ii) If (A) = 04444444

(TEMP) = 02132132

SBA TEMP

Answer: (A) = 02312312

(iii)

TEMP 1 0 0 0 0 0 0 1 2 4 0 0 1 0 2 0 7 7 7 7 7 7 7 7 7 1 4 0 2 1 0 2 0 0 0 0 0 1 0 0 0 0 0 0 0 2 2 2 2 0 2 0 2 0 2 0 2

What will be in this section of memory after the following?

LDA	TEMP
ADA	TEMP+6
STA	TEMP+2
SBA	TEMP+4
STA	TEMP+5

Answer:

								-
1	0	0	0	0	0	0	1	TEM:
2	4	0	0	1	0	2	0	
1	2	0	2	0	2	0	3	
1	4	0	2	1	0	2	0	
0	0	0	0	1	0	0	0	
1	2	0	1	7	2	0	3	
0	2	0	2	0	2	0	2	

Exercises on Subtract from A

(a) LDA =D401 SBA =D30

What will then be the contents of A?

(b) If (CØDE) = 00000001

What will be the contents of HØLD after the following?

LDA	CØDE
ADA	CØDE
STA	нøld
ADA	нǿгр
STA	нøгр
ADA	нøгр
ADA	нфгр
STA	HØLD

(c) Write a program segment to multiply the contents of X by two and subtract from the answer, the contents of locations Y and Z. Store your answer in ANSWER.

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	MUA,I	m, b	
1	1	1	5.936;(); 28;(25;(0)3; <u>18</u> ;25;24;35;46;21;

23	18	17	16	15	14	00
50)	а	ŀ)		m

a = address mode designator

b = index designator

m = storage address

Description: Multiply the contents of A by the contents of Address M.

The 48-bit product appears in QA with the lowest order bits in A.

$$\mathbf{M} = \mathbf{m} + (\mathbf{B}^{\mathbf{b}})$$

Examples:

(i) What will be the contents of QA after execution of the following instructions? A contains 100₈, and TABLE contains 5.

(ii) If TABLE contains 5 and A contains 2000000008, what will be the contents of QA after execution of the following instructions?

Exercises on Multiply A Instruction

(a) If (A) = 10 , (TABLE) = 3 , (SUM24) = 5 , and (HØLD) = 0 what will be the contents of A after execution of the following instructions?

(b) A block of memory is as shown

100	00	00	00	01
	00	00	00	02
•	00	00	00	03
	00	00	00	04
	00	00	00	05
	00	00	00	06
	00	00	00	07
	00	00	00	10

Write a program segment to add the contents of 100 and 101, multiply the result by the contents of 102, add the contents of 103, 104 and 105, multiply the result by (106), and then add (107). Store the result in 100.

(c) What will be the contents of A after execution of the following sequence of instructions, if the initial contents of A = 0, (NE) = 6, (TWO) = 2, $(THREE) = 10_{10}$.

ADA	ØNE
MUA	TWØ
SBA	THREE
MUA	ØNE
MUA	ØNE
SBA	TWØ
ADA	THRE

3.3.4 Divide A

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD	
	DYA, I	m,b		
	<u> </u>	20 25 1 83 24	(*18) (8) (8) (8) (8) (8) (8) (8)	11/1/25/16 3-7

23 1	8 17	16 15	14 00
51	а	ь	m

a = addressing mode designator

b = index designator

m = storage address

Description:

Divide the 48 bit quantity in AQ by the quantity in storage at address M ($M = m + (B^b)$). The quotient appears in A, and the remainder with its sign extended appears in Q.

If a divide fault ccurs, the instruction halts and the program advances to P + 1. (The contents of A and Q are usually meaningless in this case.) A divide fault occurs whenever the number of leading sign bits (0 or 1, ie, + or -) in M is greater than or equal to the number of leading sign bits in AQ. A fault can also occur if the number of sign bits in M is one less than that in AQ; however, the actual number in M and in AQ now has to be considered. Since the number in AQ is usually achieved by shifting AQ 24 bits to the right, extending the sign thru A into Q, an overflow rarely occurs.

^{*}Quotient greater than 2^{23} -1

3.3.4 (cont.)

Example:

If
$$(AQ) = \boxed{00000000 \ 37777777}$$

and (D) =
$$00000001$$

What will be in A and Q after execution of:

DVA D

Answer: (A) =
$$\boxed{37777777}$$
 = Quotient (Q) = $\boxed{000000000}$ = Remainder

Divide Fault bit = 0, ie, 'No Divide Fault"

Note: Had the initial contents of AQ been just one number larger, a Divide Fault would have occurred.

Exercises:

(a) If (A) = 0000 0000

(Q) = 0000 4040

(TAG) = 0000 2000

What will be in A and Q after execution of the following instruction?

DVA TAG

(b) If (A) = 00000000

(Q) = 00000122

(LOC) = 000000005

What will be in A and Q after execution of the following instruction?

DVA LØC

(c) If (A) = 7777777

(Q) = 7777771

and Index Register 2 contains 00003

TAG

What would be in A and Q after the instruction:

DVA TAG, 2

(d) If Index Register 2 contains 4, TAG is as above, and (A) and (Q) are as shown:

What would be in A and Q after execution of the following instruction?

DVA TAG, 2

- (e) Draw diagrams of the machine instruction word which would be assembled from the following COMPASS instructions:
 - (i) DVA 474B,1
 - (ii) DVA 100B

3.3.5 Replace Add

LOCATION	ī	OPERATION, MODIFIERS ADDRESS FIELD
		RAD, I m, b
	Ι.	:

23	18	17	16 15	14	00
34	Ļ	а	b	m	

a = address mode designator

b = index designator

m = storage address.

Description:

Replace the quantity at address M with the sum of (M) and the contents of A register. $M = m + (B^b)$.

The A register remains unchanged.

Examples:

(i) If A =
$$67432136_8$$
 and (INC) = 100_8 STA LØC LDA INC RAD LØC

LØC now equals 67432236B.

(ii) If (A) =
$$200_8$$
 and (INC) = 500_8

RAD INC

Answer: (INC) = 700_8

Exercise:

If (A) =
$$100_8$$
 and (INC) = 200_8

RAD	INC
STA	TEMP
LDA	INC
STA	Øne
LDA	TEMP
RAD	INC
LDA	INC
STA	TWØ
LDA	TEMP
RAD	INC
LDA	INC
STA	THRE

What will be the contents of ONE, TWO and THREE?

3.4 REGISTER OPERATIONS WITHOUT STORAGE REFERENCE

3.4.1 Increase A

LOCATION	OPERATION.	MODIFIER	S ADDRESS	FIELD	
	INA,S		'y		بيلليا
12111-121111-1-1	<u>Lieurusueueu</u>	3 1:61-11:# [18 70 71 82 88 7-	Marita in 1841 Salas in 18	2122124120144351
	23 18	17	16 15 1	4	00
	15	1	b	У	

b = 0 if sign extension

LOCATION	OPERATIO	N, MODIFIERS	ADDRESS	FIELD	
	INA,	S	4		
	4	14 1 15 1 16 1 17 114 170 j.	49,24,172,23124	[22] \$6] \$7] \$2] \$6] \$6] \$6] \$7	BREED LYNCAS GERY
				ESTES CLESCOSISCIAL	[32] 35 [74] 35; 56;37;
		18 17	15 1	-	00
				-	00

b = 2 if no sign extension

			14	
1/21.4.515.1.1.1		 [18.14. 20131] N. 61		1-1-1-1-1-1-1-1 122[37](4)23/34 37]
	INA		***************************************	

Description:

Adds the amount "Y" to the contents of the A register.

If there is no sign extension specified, only the 15 bits of "Y" are added to A.

If sign extension is specified, the sign bit of y is extended before addition to A. (Note - if A is increased by a negative number, sign extension should be used.)

INA 12B

(A) = 00 00 00 13

INA, S 40000B

(y = 777 4 0000)

Answer : (A) = 77740001

Exercises: (ERRØRC) = 00004040B

(a) What will be the contents of ERRORC after the following?

LDA ERRØRC

INA 55565B

STA ERRØRC

(b) If the instructions had been

LDA ERRØRC

INA, S 55565B

STA ERRØRC

What would have been the final contents of A?

3.4.1 (Cont.)

- (c) If (ERRØRC) = 60_{10} , write the coding necessary to increase it to 100_{10} .
- (d) If (A) = 108, what will be the final contents of A after execution of the following?

INA,S 77776B

3.4.2 Increase Q



b = 1 if sign extension

1114,41315,1101	23	18		15 1	
	ING	L			4.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1
LOCATION	UPLES	ION, MO	DEFFERS	ADDRESS	RELS

b = 3 if no sign extension

	23	18	17	15	14	oc
12:3 *13[8]*18	[-]	<u> </u>	e din e	1481971577 6 91	24/17/84 (7/20	\$ (1.5140 41.138 33.149 33.138 3.11
	ING	7		y	خبلب	دانا غشاط الملك
196811011	UT ERR	188,03	BREENS	252417	3 8161.0	
LOCATION	OPERA	HON, MC	DIFFERS	400063	s field	

If sign extension is specified, the sign bit of y is extended before addition to Q. (note: if Q is increased by a negative number, sign extension should be used.)

Examples:

(i) If
$$(Q) = 00 00 00 20$$

INQ 60B

Exercises: (i) If (Q) = 5778, what will be the result in Q after the instruction INQ 547B is executed?

3.4.2 (cont.)

(ii) If (Q) = 50B, (STAGK) = 500B what will be the result in Q after the following sequence of instructions?

INQ	100B
STQ	TEMP
LDA	TEMP
RAD	STACK
LDQ	STACK
INQ, S	27711B

3.4.3 Increase Index

LOCATION	OPERA!	ION, MODIF	IERS	ADDRES	S FIELD		
	INI	1111	وِٰ ۔۔	, Ь			ناللك
1.17.41 *13 15 17 1 *	المتسته إلا إ	(\$114.115.116)+	7 [18 [19] 25	12:173.183	24(27) \$8 482	18 79 30 91 38 9	27247397887377
	23	18 1	7 16	15	14		00

0 Ь

15

b=index register designator

<u>Description</u>: Adds the 15-bit quantity "y" to the contents of the index register specified.

Examples:

- (i) INI 6,2 where $(B^2) = 12B$ What will be the contents of B^2 ? $(B^2) = 20B$
- (ii) LDI 100B, 3 INI 10B, 3 What will be the contents of B^3 ? (B^3) = (100B) + 10B.
- (iii) If a block of memory is as shown below, what will be in the index registers as a result of the following:

LDI 110B,1 LDI 111B,2 INI 20B,2 LDI 113B,3 INI 70B,3

Answer: B₁ = 21B B₂ = 21B B₃ = 110B

3.4.3 (cont.)

Exercises on Increase Index instruction


(i) A block of memory is as shown:

100	00	00	00	01
	00	00	00	10
	00	00	01	00
	00	00	10	00
	00	01	00	00
	00	10	00	00
	01	00	00	01

What will be the contents of the three index registers after execution of the following?

LDA	101B
RAD	100B
LDI	100B, 1
INI	100B, 1
LDI	104B,2
INI	17777,2
LDI	106B, 3
INI	100B, 3
STI	106B, 3
LDA	106B
RAD	106B
LDI	106B,3

(ii) If index 1 contains 1, write a program using this index to store the numbers 1, 3, 5, 7 and 8 in 5 consecutive locations beginning at location 100.



If b=0, this is a no-operation instruction.

Description: The 15-bit quantity "y" is entered in the specified register. The register is cleared before "y" is entered. If sign extension is specified, the sign bit of "y" is extended before "y" is entered into the register.

Examples:

- (i) ENA 14B
 - (A) = 00 00 00 14
- (ii) ENQ, S 40001B
 - (Q) = 777 40001
- (iii) ENI 77B,1
 - $(B^1) = 00077$

Exercises on the Enter Register Instructions

(1) If (Q) = 11025321, and location 708 contains 101018 what will be the contents of Q after execution of the following?

ENQ 70B

(2) AA ENA O
LDA *-1
INA 40
STA AA

What will be the contents of storage location "AA" after execution?

(3) If (FIELD) = 1010 1010

and FIELD = locaton 456B

What will be the contents of the A Register after execution of the instruction

ENA FIELD

What will be the contents of A, B^1 and B^2 after execution of the above?

3.5 JUMP INSTRUCTIONS

3.5.1 Unconditional Jump



23	18	17	16 15	14 0	0
01		а	b	m	

a = addressing mode designator

b = index designator

m = storage address

<u>Description</u>: Unconditionally jump to address M, where $M = m + (B^b)$.

Examples:

(i) EØF LDA 100B

UJP

EØF Control will jump back to statement EOF

(ii) AAA UJP (AAA = address 10)Program jumps to address 12.

Where the address to which control is to jump is not known at the time of assembly, but will be entered in during execution, the instruction is usually coded as follows, to enable easy recognition of the statement in assembled programs:


This causes 1 bits to be set in the address portion of the word, and this will be replaced during execution by the actual address to which control is to jump.

SCOPE entry to a program takes this form. (See section 2.2.4.3)

However, in such cases, the contents of the address portion of the word may be any legal address. Whatever the address is, it will be replaced by the correct address during execution. Thus:

> UJP UJP UJP *****+7 UJP START START

will all serve the same purpose, for they will all be modified as required in the program, during execution.



(a)
$$j = 0$$
, jump if $A = +0$ or -0

	23	18 17	15	14 00
	16:011210	41141131141-31	 	[24:33]t6:25:]88:[29:35:35:]36]37:15:36;36;37:
	AZJ	, EQ	m	
LOCATION	OPERAT	ION, MODIFE	ERS ADDRES	SS FIELD

(b)
$$j = 1$$
, jump if $A \neq +0$ or -0

LOCATION	OPERA	ION, MODIFIERS	ADDRESS FIE	ED .
	AZJ	, NE	**	
12.5141216;7;4	* *11/17	ing tie tie tie tie tie te	 	6] (*) 28 29 30 30 28 38 38 38 36 37
	23	18 17	15 14	oc

(c)
$$j = 2$$
, jump if $A \ge +0$ (-0<+0)

LOCATION	OPERATIO	IN, MODIFIER	S ADDRI	SS FIELD		
	AZJ,	GE	78			اللاللا
	3 1					
التا المالات المالة	بدريس والحل	14 15 15 -2 18	110,120,21,8218	315+152158 14:158	154186131185132	34[35]86]37]
1818:51218:718		18 17	15		1541361201 33 132	00

(d) j = 3, jump if A < +0 (-0<+0)

LOCATION	OPERATION, MO	DIFIERS ADDRES	S FIELD	
	AZJ,LT	m		خينيا
	7 (5 : : : : : : : : : : : : : : : : : :		3-122-24-14-158-15-130-13-13513-2-13	
	23 18	17 15 1	4	00
	03	3	m	

Description: (A) are compared with zero to establish test conditions as above. If the condition specified by the modifier is true, the program jumps to address "m". If the test condition is not true, RNI from address P + 1. (RNI = read next instruction).

3.5.2 (cont.1)

(x)

ENA,S

AZJ,LT

RNI =

32767

FINISH

If (A) = 1Example: (i) What will be the RNI address after execution of AZJ, EQ Answer: RNI at address P + 1 (ii) If the instruction had been AZJ,GE Answer: RNI at address LØØP Exercises: Given the information below, give the RNI addresses for each problem. (i) If (A) = 77777777AZJ,EQ 100B RNI = (ii) If (A) = 00020000AZJ,EQ STØRE RNI = _ _ _ ? (iii) If (A) = 00000000AZJ,NE CARRY+1 RNI = ___ ? (iv) If (A) = 77777776NEXT AZJ,LT RNI = (v) If (A) = 03675671AZJ,GE Øne _ _ _ ? RNI = (vi) If (A) = 00000000AZJ,GE L**øø**P ----? RNI = (vii) ENA,S 40001B AZJ, GE RNI = (viii) ENA 77777B AZJ,LT MAYBE RNI = ____? ENA,S (ix) 20741B AZJ,GE 200B RNI =

LØØP

LØØP


3.5.2 (cont.2)

(xi) Which Halt will be reached after execution of the following program segment?

LDA = \$\phi423\$
SBA = \$\phi424\$
AZJ,EQ HLT
UJP HLT+1
HLT 1
HLT 2

3.5.3 Compare A with Q, Jump

HLT



(a)
$$j = 0$$
, jump if $A = Q$ (+0 = -0)

			15 14		
	<u> </u>	3:4:5:5:5:5:5:3:5	 -	\$2;\$8[24]\$6;\$1;\$8]\$5]\$4;5	125/11
	AQJ	, EQ	m		
LOCATION	UTERXI	inau'manitiru?	ADDRESS FIELD)	

(b)
$$j = 1$$
, jump if $A \neq Q$ (+0 = -0)

	0	2 ·	_			_
	23	18	17	15	14	oc
12:1:4:23:15:7:18	# 10 po 1271	\$:* :5 :0	1 -1118195 4	13:182(2)	jandalise ist iss isolise:	\$1,28195114155164,251
	AQJ	, NE) ji	3		
LOCATION	OPERAT	ION, MOO	FIERS	ADDRE	SS FIELD	

(c) j = 2, jump if A > Q (+0>-0)

	0	3	6		
	23	18 17	15 1	4	00
التائية الألتانا	dalanini	13-114-17-17-17-17-18-11	 - - - - -	(DISCOUNTS) DOLLARIS	19 35 36 37 1
	AQJ	,GE	m		
LOCATION	OPERAT	ION, MODIFIERS	ADORESS	FIELD	

(d) j = 3, jump if A < Q (+0>-0)

LOCATION	OPERA	I ION, MODIFIERS	ABDRESS	FIELD	
	AQJ	,LT	m	1 1 1 1 1 1 1 1	
1211, • 1516 (7) *	y .a.j.11.21;	111141414141414141	: (AG_ANIRE)\$3(2*	25; 24; 7::28; 27:30:3:; 2	2[35]24[35]36]37]
		40.47	15.1		

23 18	17 15	14	00
03	7	m	

3.5.3 (cont.)

<u>Description</u>: The quantity in A is compared to the quantity in Q to establish a comparison or test - condition. If the test-condition is true, RNI from address "m".

If not true RNI = P+1.

Examples: (i) AQJ, EQ L ϕ P (A) = 00000000 (Q) = 77777777

RNI LØØP

(ii) AQJ,GE $L \not D P$ (A) = 00000000 (Q) = 77777777 RNI $L \not D P$ (+0 > -0)

Examples: Given the information below, supply the RNI's for each problem:

(a) AQJ,LT $L \not \! D P$ (A) = 07234567 (Q) = 044444444 RNI = ----? (b) AQJ,GE $L \not \! D P$ (A) = 50523417

(Q) = 23456733

RNI = ?

(c) AQJ, NE LØØP (A) = 00 00 00 01

(Q) = 10 00 00 01

RNI = ?

3.5.4 Return Jump

LOCATION	ŀ	OPERATION MODIFIERS ADDRESS FIELD	
41.41.11		RTJ m	
		 	l-mar is

23 18 17 15 14 00 00 7 m

<u>Description</u>: The address portion of the contents of address m is replaced by the return address P+1. The program jumps to m+1, i.e. RNI = m+1. This instruction is used for subroutine linkage.

Examples: (i) RTJ XSØRT

Here the address portion of XSØRT will be replaced by the address of the RTJ instruction + 1, and the program control will advance to XSØRT+1.

(ii)	RTJ	subrøu t	[100]
	-		
	-		
	_		
			[]
subrøut	UJP	**	[200]

	_		
	_	arran dam	[040]
	UJP	Subrøut	[210]

If the numbers in brackets indicate the addresses of the respective instructions, the assembled program before execution would appear as:

00100	00700200
	-
	-
	-
00200	01077777
	-
	-
	-
00210	01000200

After execution the contents of memory would appear as:

00100	00700200
	_
	_
	-
00200	01000101
	7-
	_
	-
00210	01000200


Note: ** is assembled as 777778 and is used where the value is to be changed at run time, such as the address portion of the instruction at address 00200.

Or, to say it another way, ** = TBC (To Be Clobbered.)

Use of the RTJ statement


There are two types of subroutines used in COMPASS - open and closed. An open subroutine is a series of instructions which is required more than once during a program, and is inserted where it is required.

e.g.



This method has obvious disadvantages and it is more usual to employ the closed subroutine method.

e.g.




What is the problem here?

It is that the program jumps to the subroutine from two or more points in the main program, and once the program is in the subroutine, how does it know to which main program instruction it should return?

It doesn't, since it doesn't know where the jump to the subroutine was located in the Main Program.

This problem is eliminated by using the RTJ (Return Jump) instruction in the Main Program when a jump to the subroutine is desired. The instruction stores the address of the instruction following the RTJ in the lower 15 bits of the first instruction of the subroutine. The first instruction is then skipped and the first instruction executed is actually the second instruction of the subroutine.

e.g.



Following is a section of a Compass Program that illustrates this latter method:

	ENI	0,1
	LDA	100B
	SBA	101B
	RTJ	SUB
	LDA	105B
	MUA	1 55B
	RTJ	SUB
	LDA	255B
	INA	21
	•	
	•	
	etc.	
	•	
	•	
SUB	UJP	**
	AZJ.LT	SUB
	INI	1,1
	UJP	SUB

When the RTJ instruction is encountered, execution jumps to SUB, and the address portion of SUB is replaced by the address of the RTJ instruction + 1. After execution of the instructions in the subroutine, a jump is made back to SUB, which instruction is now an unconditional jump to the instruction after the RTJ instruction. Execution of the Main Program then continues.

3.5.5 Unconditional Halt


LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	HLT
. [8] \$1 * : 5 [\$ 7 8	0 (0) 1/ 1/ 1/ 1/ 1/ 1/ 1/

23 18	17 1	5 14	00
00	0	m	

Description: Unconditionally stop at this instruction. Upon
restarting, RNI from address "m"

Example: LDA CTR.1 CTR.2 INA 100B STA TØM, 1 ISE 10,1 UJP CTR.1-3 HLT SEVEN SEVEN MASK LDQ END

3.5.6 Selective Jump



j = 1 - 6 = SELECTIVE JUMP switch number

j = 1, jump if "SELECT JUMP 1" switch is on

LOGATION	OPERATION MODELERS	ABARESS FIELD	Control of the Contro
	SJI	m	La Andreita de La
سنست ، ، ، ، ، ، السام	راييد د سليا المحاد ،	سفسل فالشبلد المأثأت	يهيل الشدة التلطط
141111121212121	<u>anteuniones en cuere</u>	CONTRACTOR CONTRACTOR	OR SHALLSHAR IN CREATING FOR

j = 2, jump if "SELECT JUMP 2" switch is on

LOCATION	OPERATION, MODIFIERS	ADDRESS	fills
	5J2	m	
1218 419 (6.7	i i Na i i i i i i i i i i i i i i i i i i i	- 	78. 4. 5. 100 marks 100 ma

j = 3, jump if "SELECT JUMP 3" switch is on

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
1	C 10		
tara a cara da A	503	1111	
			
		1	
<u> </u>	Line and the state of the state of	126 31 12 2 23 24	128 44 45 44 46 46 46 46 47 48 47

j = 4, jump if "SELECT JUMP 4" switch is on

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	SJ4 m
1121314141417111	3

j = 5, jump if "SELECT JUMP 5" switch is on

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	
	5J5 m	
12111111111111111	0 0 11 11/11/2 114 115 116 1-7 118 (16 12C-21 27) F31/24(75) F41/27 124 134 (46 13 130) NA 144 146 137	

j = 6, jump if "SELECT JUMP 6" switch is on

LOCATION	SPERATION, MODIFIERS ADDRESS FIELD
	5J6 m
1 2 5 4 5 5 7 4	TO THE PARTY OF THE PROPERTY OF THE PARTY PARTY OF THE PA

j = 0, see HLT instruction j = 7, see RTJ instruction

3.5.6 (cont.)

<u>Description</u>: Jump to address m if the jump key specified is set "on".

Otherwise RNI P+1.

Example:

	SJ4	BYPASS
CARDS	LDA	CARD, 1
	ADA	TEMP,1
	UJP	ENDING
BYPASS	LDA	TAPE,2
	ADA	støre,2
ENDING	HLT	LØC4
	•	
	•	
	END	

If jump switch 4 is set "on" jump to BYPASS otherwise RNI at address CARDS.

3.5.7 Index Jump (Incremental/Decremental)

23	18	17	16	15	14 00)
02		d	t)	m	

b = index register designator

d = 0, Index Jump Increment

LOCATION	OPERA!	ON MODIFIERS	ABDRESS	FIELD	
	IJI		m, b		
1814-1314/11		1 10 1 7 1 1 2 1 1 1 1 1 2 1			
		in the same and the same of th			
	23	18 17	15 1	4	0
	23	 	15 1	<u>4</u>	0

d = 1, Index Jump Decrement

LOCATION	OPERATION, M	ODIFIERS ADOR	ESS FIELD	
	IJD	m,b		1
<u> </u>	m - c l c l spine i se	<u> </u>	##_24_751#\$_;\$2.##1_5;\$61#12#135;\$91751	18,371
	23 18	17 15	14	00
	02	b + 4	m	

Description: Jump to "m" if $(B^b) \neq 0$ and increment (or decrement) index by 1. There are 3 possible conditions:

- (i) If b = 0, the instruction is a no-op. and RNI from P + 1.
- (ii) If $(B^b) = 0$ RNI from P + 1.
- (iii) If (B^b) ≠ 0, the jump test condition is satisfied. One is added or subtracted to (B^b); jump to address m and RNI.
- N.B. The counting is done in a one's complement adder.

 Negative zero is not generated because the count progresses77775, 77776, 00000, stopping at +0. If a -0 is initially in Bb, the count progresses 77777, 00001, etc.

3.5.7 (cont.)

9,2 Examples: ENI BUFFER,2 LØØP LDA DATA,2 STA LØØP,2 IJD HLT How many words will transfer? ¹⁰10 Answer: ENI -5,1 Exercises: тøм LØØP LDA LØØP,1 IJI

HLT

How many times will the loop be executed?

3.6 SKIP INSTRUCTIONS

3.6.1 Skip if Equal

23 18	17	16 15	14 00
04	d	b	у

(i)
$$d = 1$$

 $b = 0$

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ASE, S
12131477181718	4 0 to the figure is the higher to 150 missiestententententententententententententent

23 18	17 15	14. 00
04	4	у

(ii)
$$d = 1$$

 $b = 2$

LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD
	ASE	4

23 18	17 15	14 00
04	6	у

LOCATION	OPERATION, MODIFIERS	ABORESS FIELD
	QSE, S	Y
		, ,

23 18	17 15	14 (ю.
04	5	у	

(iv)
$$d = 1$$

 $b = 3$

LOCATION	OFFICE PROPERTY AND	
\$	OSE	
		-4
	To the control of the	571

23 18	17	15 14		00
04	7		у	

$$(v)$$
 $d = 0$
 $b = index designator$

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ISE 4, b
. 12 : 5 : 4 : 5 5 : 7 6	- 4

23	18	17	15	14		00
04			b		у	

b=index register designator (1-3)

If b=0, y is compared to zero.

from P+1.

> Note: To be equal to "y", the quantities must be exactly the same, thus if (A) or (Q) =xxx00000 or $(B^b) = 00000$, "y" must be 00000 to be equal. Or, if (A) or (Q) = xxx77777or $(B^b) = 77777$, "y" must be 77777 to be equal. If sign extension is specified, i.e. the instruction is ASE,S or QSE,S the sign of "y" (bit 14) is extended and the 24 bit quantity is compared with the quantity in the specified register.

Note: In this case, if (A) or (Q) = 77777777 or 000000000and "y" is 77777 or 00000, the quantities are considered to be equal. For all other values in A or Q the sign extended "y" value must be exactly the same to be considered equal.

Examples:

(i) ISE 300B, 2

If
$$(B_2) = 300_8$$
, RNI P + 2.

 $50,1 \quad (B^1) = 62_8$ (ii) ISE

What is the RNI?

$$RNI = P + 2$$

(iii) BEGIN LDQ FIELDA

64210B QSE

FIELDA ØCT 50964210

What is the RNI after QSE?

RNI = P + 2 (=BEGIN + 3)

(iv) Example of use of ASE instruction in a loop.

This will store numbers 0, 5, 10, 15 and 20 in consecutive locations, begining at location CIC.1. (iv) Use of Index skip-if-equal in a loop.

	ENI	0,1
L øø P	LDA	VALUE
	MUA	≔ D5
	DVA	=D8
	STA	RESULT
	LDA	LØØP
	INA	1
	STA	LØØР
	LDA	*-4
	INA	2
	STA	*-6
	INI	1,1
	ISE	100,1
	WP	L øø P
	HLT	
VALUE	ØCT	1

Exercises on SKIP-if-equal instructions

(a) How many times will the following loop be executed?

	enq	0
Løøp	LDA	ANS
	AUM	TW
	STA	ANS
	INQ	5
	QSE	100
	UJP.	LØØP
	HLT	

- (b) Write a program segment to move ten numbers in consecutive locations, beginning at STORE, to consecutive locations beginning at RESULT.
- (c) If CHECK contains 20100010, how many times will the following loop be executed?

	LDQ	CHECK
LØØP	LDA	TyÓM
	inQ	1
	QSE	12
	UJP	12 L øø P
	$\mathtt{H}\mathbf{L}\mathbf{T}$	

3.6.1 (cont.3)

(d) What will be the final contents of HOLD after execution of the following?

ENI 0,1 0 ENA HØLD STA INA 10 INI 1,1 ISE 10,1 UJP ***-**3 HQLD STA

3.6.2 Skip if Greater Than or Equal

23	18	17	16 15	14	00
0	5	d	b	у	

(i)
$$d = 1$$

 $b = 0$

LOCATION	OPERATION, MODIFIERS ABORESS FIELD	
	AS6,5	

23	18	17	15	14		00
05	i		4		у	

(ii)
$$d = 1$$

 $b = 2$

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ASG 4
	e nalinitalialialia kalielialialia kalialialiasikaliasikalianiasikaliasikaliania

:	23 18	17 15	14 00
ſ	05	6	У

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	Q\$6,5
	9 10

	23 18	17 15	14	.00
ſ	05	5	у	

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	QSG , , , , , y, , , , , , , , , , , , , ,
	a 10 11 2 2 11 a 112 - 16 - 17 - 18 - 12 12 12 12 12 12 12 12 12 12 12 12 12

23 18	17 15	14 00
05	7	у

$$(v)$$
 d = 0
b = index designator

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	15G
. :2151013151710	y 20

23	18	17	15	14	00
0!	5	b			у

3.6.2 (cont.)

Description:

If the instruction is ASG, QSG or ISG; ($A_{lower\ 15}$), ($Q_{lower\ 15}$) or (B^b) respectively is compared to "y". If greater than or equal, RNI from P+2, otherwise RNI from P+1.

Note: If the (A) or (Q) = xxx77777 or (B^b) = 77777, the instruction will skip if "y" is either 77777 or 00000. If the (A) or (Q) = 00000000 or (B^b) = 00000, the instruction will skip if "y" is 00000 but will not skip if it is 77777.

If sign extension is specified, i.e. the instruction is ASG,S or QSG,S the sign of "y" (bit 14) is extended and the 24 bit quantity is compared with the quantity in the specified register. If the sign bits are different the one with a sign bit of zero is larger.

Note: If the (A) or (Q) = 00000000, the instruction will skip if "y" is either 77777 or 00000. If the (A) or (Q) = 77777777, the instruction will skip if "y" is 77777 but will not skip if it

is 00000.

Examples:

(i) If (A) = 00002020

ASG 2020B

(A) is equal to y, skip next instruction, RNI at P+2

(ii) If (A) = 10000001

ASG,S 40002B

y = 77740002 with sign extended

(A) is greater than y, skip next instruction, RNI at P+2

Exercises in SKIP-IF-GREATER-THAN-OR-EQUAL Instruction

(a) To which STOP location will control jump?

ENA,S 40000B
INA 20B
ASG,S 40040B
UJP STØP1
ASG 40020B
UJP STØP2
UJP STØP3

(b) To which location will control jump?

ENQ 200B QSG,S 128 UJP ENDING UJP PAUSE1


(c) How many times will the loop be executed?

ENI 0,1 PERSØN,1 LDA MUA RATE1 SHAQ 24 DVA RATE2 STA TAX,1 INI 1,1 500,1 ISG *-7 UJP HLT

3.6.3 Index Skip Incremental/Decremental

23	18	17	16 15	14 00
10)	d	b	٧

d = 0, Index Skip Incremental



b=index register designator

d = 1, Index Skip Decremental

LOCATION	OPERATION, MO	DIFIERS ADDRE	SS FIELD	
	ISD	y,b	لللللللل	المسلمان
1211-15161-15	16 ; : [17 ; : 3 [14] : 5 [1	6;-: 8 6;-: 12 2	\$\J\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\\$\	5152 (54) 20 (46) (51)
	23 18	17 15	14	00
	10	b + 4	У	

b = index register designator

Description: If $(B^b) = y$ skip to P + 2 and clear the index register. If $(B^b) \neq y$ RNI from P + 1 and add 1 to (or subtract 1 from) the index register.

Examples:

What is this series of instructions doing?

Answer: Moving 10 words from BUFFER to DATA

(ii) How can the same problem be done using the ISD instead of the ISI?

ENI 9,1

LDA BUFFER,1

STA DATA,1

ISD 0,1

UJP *-3

HLT

Exercise:

Write a program segment to move 50 numbers from BUFFER to locations beginning at STORE. FIND the total of these numbers and store the answer in RESULT.

3.7 STORE WORD ADDRESS

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	SWA,I	m,b	

23 18 17 16 15 14 00 44 a b m

Description: Stores the lower 15 bits of (A) in the storage location M. The high - order 9 bits of (M) are unchanged.

What will be the contents of INST?

(INST) = 20077777 (Before)

(INST) = 20003216 (After)

(ii) INST LDA *+1 SWA *-1

Where INST = 76B, what will be the contents of words 76B and 77B?

(76B) = 20000076

(77B) = 44000076

Exercise: What, if any, is the difference between the modification achieved by the two program segments below?

	Progr	am A	Program B		
	LDA	F Ø UR06		LDA	INST
	SWA	INST		ENA	406
	•			STA	inst
	•			•	
TNOR	+ TORY A	.		•	
inst	ENA	**		•	
	•			•	
	•		INST	ENA	**
FØUR06	Øct	406			

3,8 SHIFT INSTRUCTIONS

3.8.1 Shift Instruction format

23 18 17 16 15 14 00


d = an operation designator, which is virtually an extension of the function code. It differentiates_between 2 instructions using the same f code.

> e.g. SHA d = 0SHQ d = 1

- b = index register designator
 The contents of the index register is treated as a
 15 bit signed number and is used as a shift direction
 and/or number-of-bits modifier.
- k = Shift count, base
 It may be positive or negative (in complement form)
 depending on the direction of the shift.

Left shift = positive
Right shift = negative

 ${\rm K}={\rm shift\ count},\ {\rm actual}$ ${\rm K}=({\rm B}^{\rm b})+{\rm k}$ if ${\rm b}\neq 0$ otherwise ${\rm K}={\rm k}$ if ${\rm b}=0$. If the sum is 777778 or larger, subtract 777778 to get the true sum, otherwise the sum is the true sum. If the true sum is between 00000 and 377778, the righthand two octal digits are the actual shift count for a left shift. If the true sum is between 40000 and 777778, the complement of the righthand two octal digits are the actual shift count for a right shift.



23	18	17	16	15	14		00
12		d	t)		k	

d = 0, Shift A

LOCATION	OPERATION. MODIFIERS ADDRESS FIELD
	SHA k, b

23	18	17	15	14	00
12			0	k	

b = index register designator

d = 1, Shift Q

	,		
LOCATION		OPERATION, MODIFIERS ADDRESS FIELD	
	-		-
		SHQ K.b	
	•		

23	18	17	15	14	00	
12		b	+ 4		k	l

b = index register designator

If K is +, instruction is left shift end around If K is -, instruction is right shift end off

- e.g. Shift left 6 positions: K = 00006
 Shift right 6 positions: K = 77771
- N.B. (i) During right shift, the sign bit is extended and the low order bits are discarded.
 - (ii) During left shift, the high order bits are brought end around.
 - (iii) (B^b) and k, with their signs extended, are added to give K. The computer then senses bits 00-05 and bit 23 to determine the size and direction of shift, respectively.

3.8.2 (cont.)

Examples of Shift A and Shift Q

- (i) SHA 6
- (A) = 10203040
- After Shift
- (A) = 20304010
- (ii) SHA -6
- (A) = 12345671
- After Shift
- (A) = ?
- (A) = 00123456
- (iii) SHA -6
- (A) = 50367123
- After Shift
- (A) = ?
- (A) = 77503671

Exercises on Shift A and Shift Q

- (a) If (A) = 20000010
 - What will be the contents of A after
 - SHA .
 - SHA -4
- (b) If (A) = 21354706
 - What will be the contents of A after
 - ENI 2001,1
 - SHA 8,1
- (c) If (Q) = 10000001
 - What will be the contents of Q after
 - SHQ 6
- (d) If (Q) = 12345670
 - What will be the contents of Q after each shift in the following?
 - ENI 307,2
 - SHQ 4,2
 - SHQ -13
- (e) If (LABEL) = 10421045
 - What will be the contents of LABEL after
 - LDA LABEL
 - SHA -15
 - STA LABEL
 - LDQ LABEL
 - SHQ 1404B
 - STQ LABEL

INSTRUCTION MODIFICATION

- 4.1 SIGN EXTENSION
- 4.2 ADDRESS MODES

Chapter 4

4.3 INDEX MODIFICATION OF WORD ADDRESSING INSTRUCTIONS

4.1 SIGN EXTENSION

Certain instructions offer the option of extending the sign of a 15 or 17-bit operand by putting a modifier "S" in the operation field.

e.g. ENA, S
$$06370B$$
 (A) = 00006370 ENQ, S $76432B$ (Q) = 77776432

Examples:

What is RNI address?

RNI from P + 2.

(A) = 77777771

(iii) ENQ, S
$$405B$$
 what will be (Q)?

(Q) = 00000405

(A) = 00000007

(Q) = 77743125

(vi) Where (Q) = 00054631B

QSE, S
$$54631B$$
 will result in the RNI being (a) P + 1 or (b) P + 2?

Answer : P + 1

(vii) ASG, S
$$43671B$$
 where A = 43671234

what is RNI?

(A) is not greater than or equal to "y",

because "y" is less negative.

$$(A) = -34106543$$

$$y = -00034106$$

RNI at P + 1

4.2 ADDRESS MODES

There are three address modes as follows:

(a) No address

e.g. Operand ENA 10B Shift count SHAQ 5

(b) Direct Addressing

a = 0

m - operand address


e.g. LDA 45B will load the contents of word 45B into the A register.


(c) Indirect Addressing

a = 1

e.g. LDA,I m the "I" specifies indirect addressing and generates a "1" bit in bit 17.

The best way to explain is with the following flow chart and examples.





Examples:

In the following examples use the contents of these 5 words

100	26000101	
101	37421623	$(B^1) = 2$
102	00000103	
103	76543214	$(B^2) = 4$
1.04	40500100	

(i) LDA 100B

What will be the (A) after execution? (A) = 26000101.

(ii) LDA, I 100B

What will be the (A) after execution? (A) = 37421673

(iii) LDA,I 100B,1

What will be the (A) after execution? (A) = 76543214

(iv) LDA, I 100B, 2

What will be the (A) after execution?

4.3 INDEX MODIFICATION OF WORD ADDRESSING INSTRUCTIONS

The 3200 has 3 Index Registers each of 15-bit capacity. These Index Registers can be used to modify the address fields of many instructions.

e.g. LDA STORE will load the contents of STORE into the A
Register. But LDA STORE, 1 will load the contents of
(STORE + (B')) into the A Register, (i.e. if (B') = 1,
it will load STORE + 1).
How is an indexed instruction assembled?
LDA STORE, 2 where STORE = 00142B will assemble as: 20200142
Why?

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	LDA m,b
	0.0000000000000000000000000000000000000

23 18	17	16 15	14	00
20	а	b	m	

a = addressing mode designatorb = index register designator

b = 00, means no index register

b = 012 means index register 1

b = 102 means index register 2

b = 11 means index register 3

<u>Example</u>

LDA TAG,1 where
$$(B^1) = 3$$
 100 111111111 and TAG = 100B 101 22222222 102 33333333 103 44444444 104 55555555

(A) = 44444444

Restrictions on Indexing

The following instructions cannot specify indexing.

LDI	ISE	INA
STI	ASE	INQ
INI	QSE	ENA
ENI		ENQ
		AQJ
		AZJ

Exercises on Index Modification *

1. A block of memory is as shown:

*Additional material on Index Modification is located in Chapter 8.3

4.3 (cont.)

What will be the contents of memory as a result of the following:

ENI 0,1 TABLE,1 LDA STA TABLEX,1 INI 1,1 TABLE,1 LDA STA TABLEX,1 INI 2,1 TABLE,1 LDA STA TABLEX,1

2. A block of memory contains the values shown

What will be contained in the block after execution of the following instructions:

ENI 0,1 LDA 100B, 1 INI 2,1 STA 100B, 1 ENI 3,2 LDA100B,1 STA 100B,2 ENI 5,3 LDA TAG-6,3 STA TAG,1 STA TAG,2

48-BIT OPERATIONS

- 5.1 LOAD AQ
- 5.2 STORE AQ
- SHIFT AQ 5.3

Chapter 5

LOCATION	OPERATION MODIFIERS ADDRESS FIELD	
. نــ د	LDAQ,I M,b	
1221242315 1 6		

23	18	17	16 15	14 00
_ 2	5	а	b	m


a = addressing mode designator

b = index designator

m = storage address.

<u>Description</u>: Loads Registers A and Q with the two words from address M and M + 1 respectively, where $M = m + (B^b)$.

Example:



Exercises: (i) A block of memory is as follows:

This has been set up by a subprogram, part of which was

ORGR 100B

FIELD BSS 3

What would be the contents of AQ after execution of:

LDAQ FIELD+3

Exercises: (Continued)

(ii) A block of memory is as follows:

77	11	11	11	11
100	22	22	22	22
101	33	33	33	33
102	44	44	44	44
103	55	55	55	55
104	66	66	66	66
105	77	77	77	77

A portion of a program reads:

	LDAQ	TABLE
	LDQ	TABLE+3
	STA	TABLE+2
	STQ	TABLE+1
	ORGR	100B
TABLE	BSS	10

What would be the contents of the block after execution of the above program?

COCATION	OPERATION MODIFIERS	ABURESS	FIELD
الماسد دسالسلا	STAQ,I	m,b	
يلامان عاصفتكيتنا			ENERGE ER ER EL REPORT DE L'ANTENIEN DE LE CO

2	3 18	17	16 15	14 00	,
L	45	а	b	m	1

a = addressing mode designator

b = index designator

m = storage address

<u>Description</u>: Store the contents of Registers A and Q in storage locations M and M + 1 respectively.

Example:

(i) If
$$(A) = 1111 1111$$

$$(Q) = 3333 3333$$

What will be the contents of locations 1000 and 1018 after execution of the following instruction?

STAQ 100B

(ii) If FIELD = location 204_8

(A) = 22334455

(Q) = 66006600

STAQ

FIELD

Exercise:

What will be the contents of the above after execution of the following instructions:

LDAQ 102B STAQ 105B LDAQ 100B STAQ 104B

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	
1 1 1 1 1 1 1	SHAQ k,b	
		1271

23	18	17	15	14		00
1	3		b		k	

b = index register designator

Description: The contents of A and Q are shifted as one 48-bit register (AQ).

Everything else is the same as for SHA and SHQ.

Examples:

(i) SHAQ
$$-12$$
 where (A) = 12345677

$$(Q) = 22223333$$

What will be the contents of A and Q?

$$(A) = 00001234$$

$$(Q) = 56772222$$

(ii) If (A) =
$$00010444$$
 and (Q) = 11335577

Answer:
$$(A) = 66774000$$

 $(Q) = 42220455$

48-BIT, FIXED POINT, ARITHMETIC

- 6.1 ADD TO AQ
- 6.2 SUBTRACT FROM AQ
- 6.3 MULTIPLY AQ
 - 6.4 DIVIDE AQ

Chapter 6

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	ADAQ, I	m, b	
1215101515 7 9 3	Totalian in in internation	 	[2] \$6 \$1 \$8 \$2 30 30 32 33 34 35 36 37

23 18	17	16 15	14	00
32	а	b	m	

a = addressing mode design

b = index designator


m = storage address

$$\mathbf{M} = \mathbf{m} + (\mathbf{B}^{\mathbf{b}})$$


Description: Add the 48-bit contents of two consecutive locations M and M + 1 to the contents of AQ. The sum appears in AQ.

Examples:

(i) If



and




What will be the contents of AQ after execution of the following instruction?

ADAQ

ØP48

Solution:



(ii) If
$$(A) = 0000 0123$$

77 1004 0404 100 0000 0200 7000 0000

(Q) = 7000 0000

101 102

7777 7713

(Index register 1) = 1


What will be the contents of A and Q after execution of the instruction:

ADAQ

77B,1

Solution:

AQ =



Exercises:

(i) What will be the contents of AQ after execution of the following section of a program?

ENI	0,1
ENA	24314B
STA	100B,1
INA	14741в
INI	1,1
STA	100B,1
ENA,S	34567B
ENQ,S	15677B
ADAQ	100B

(ii) If (TAG) = 0202 0303

(TAG+1) = 0404 0505

(A) = 2662 6626

(Q) = 1457 1406

What will be the contents of A and Q after execution of the following instruction?

ADAQ TAG

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	SBAQ,I m,b
121314:31417 +	# 111 112 112 112 112 112 112 112 112 11

23	18	17	16 15	14	00
	33	а	ь		m

a = addressing mode indicator


b = index designator

m = storage address

$$\mathbf{M} = \mathbf{m} + (\mathbf{B}^{\mathbf{b}})$$

Description: Subtract the contents of 2 consecutive locations M and M + 1 from the contents of AQ. The difference appears in AQ.

Examples:



(Q) = 0000 0003

(TAG) = 0


(TAG+1) = 0000 0004

What will be in A and Q after execution of the following instruction?

SBAQ

TAG

Answer:



(using end around borrow in the subtraction)

6.2 (cont.)

Exercise:

(i) (A) = 00057777

(Q) = 7777 0000

(TAG) = 0000 0234

(TAG+1) = 5670 0000

What will be in A and Q after execution of the following instruction?

SBAQ TAG

(ii) A block of memory is as shown:

21	21	21	21
00	00	01	35
21	64	16	45
14	14	21	21
00	00	00	27
77	77	77	77
56	56	57	57
	00 21 14 00 77	00 00 21 64 14 14 00 00 77 77	00 00 01 21 64 16 14 14 21 00 00 00 77 77 77 56 56 57

What will be the contents of AQ after execution of the following instruction?

enq, s	0
ena, s	2222B
SBAQ	101B
SBÀQ	104B

6.3 MULTIPLY AQ

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	MUAQ,I m,b
	1

23	18	17	16 15	14	00
56		а	b	m	


a = addressing mode designator

b = index designator

m = storage address

<u>Description</u>: The instruction uses the 48-bit E register to extend the precision of AQ (by forming AQE). Muliply the contents of AQ by the 48-bit operand in two consecutive locations M and M + 1, where M = $m + (B^b)$ The 96-bit product appears in AQE, with the least significant bits in E.

Example:



MUAQ

TAG

The final results in AQE =

A	<u>Q</u>	<u>E</u>
0000000	00000000	00000001 74000000

Exercise:

A block of memory is as shown 400 00 00 01 11 401 00 00 00 00 00 00 402 00 07 403 25 37 32 10 404 24 24 42 44 405 00 00 17 07

What will be the contents of AQE after execution of the following instructions?

LDA	404 B
SBA	405B
STA	404 B
LDQ	404 B
LDA	400 B
MUAQ	401B

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
111111	DVAQ, I m, b
- 12 5 4 5 6 7 8	a alin int lighte in the intig ine ine the protection to the factor of t

23	18	17	16 15	14	00
	57	а	ь	m	

a = addressing mode designator

b = index designator

m = storage address

$$M = m + (B^b)$$

(Sign extended)

Description: Divide (AQE) by the 48 bit contents of two consecutive addresses, M and M + 1. The answer appears in AQ, and the remainder, with sign extended, in E.

Note: If a divide fault occurs, this operation halts, and the program advances to the next instruction.


The final contents of AQ and E are meaningless if this occurs.

0 0 0 0 0 0 0 0

2 0 0 0 0 0 0 0

LOGICAL OPERATIONS

- 7.1 LOGIC TABLES
 - 7.1.1 Logical "AND"
 - 7.1.2 Inclusive "OR"
 - 7.1.3 Exclusive "OR"
 - 7.1.4 Examples of Logical Operations Using Octal Numbers
- 7.2 LOAD A LOGICAL



- 7.3 LOAD COMPLEMENTS
 - 7.3.1 Load A Complement
 - 7.3.2 Load AQ Complement
- 7.4 LOGICAL "AND" OPERATIONS
 - 7.4.1 Logical Product A
 - 7.4.2 AND of A and y
 - 7.4.3 AND of Q and y
 - 7.4.4 AND of Index Register B^b and y
- 7.5 EXCLUSIVE "OR" OPERATIONS
 - 7.5.1 Selectively Complement A
 - 7.5.2 Exclusive OR of A and y
 - 7.5.3 Exclusive OR of Q and y
 - 7.5.4 Exclusive OR of Index Register B^b and y
- 7.6 SELECTIVELY SET A

7.1 LOGIC TABLES

7.1.1 Logical "AND" (Logical product)

A	В	С
0	0	0
0	1	0
1	0	0
1	1	1

Note: C is only a "1" if both A and B are "1's".

Example: AND of 1001 and 1010 (binary numbers)

1001 1010 1000

7.1.2 Inclusive "OR" (Selective Set)

	A	В	С
	0	0	0
-	0	1	1
-	1	0	1
	1	1	1

Note: C is a "1" if either or both A and B are "1's".

Example: Inclusive OR of 1001 and 1010

1001 1010 1011

7.1.3 Exclusive "OR" (Selective Complement)

A	В	С
0	0	0
0	1	1
1	0	1
1	1	0

Note: C is a "l" only if A and B are different.

Example: Exclusive OR of 1001 and 1010

1001 1010 0011

7.1.4 Examples of Logical Operations Using Octal Numbers

- (i) What is the logical "AND" of 43B and 62B?

 Answer: 42B
- (ii) What is the exclusive "OR" of 7021B and 33B?

 Answer: 7012B
- (iii) What is the inclusive "OR" of 361B and 403B?

 Answer: 763B
- (iv) What is the exclusive "OR" of 361B and 777B?

 Answer: 416B

7.2 LOAD A LOGICAL

	c		the man are a second to a		
1904	[168	OPERATION.	MODIFIERS I	UDDRESS FAELD	
		LUL. I	199	. h	
				الساسخ خساسا	المساسل المساسط مقساسة
l	and the same	. Jan Janes	11.511251	na isanata ata	Parisa elementationes (

23	18	17	16	15	14		00
27		а	k)		m	

a = addressing mode indicator

b = index designator

m = storage address

 $M = m + (B^b)$

<u>Description</u>: A is loaded with the logical product (AND) of Q and the contents of location M. In this instruction, Q serves as a mask.

Q	M	A
0	0	0
0	1	0
1	0	0
1	1	1

Note: The bit in A is a "l" only if both of the corresponding

bits in Q and M are "l's".

Examples:

100 32470235 101 12345670 102 24601357

$$(A) = 30470230$$

(ii) If index register 3 contains 00002

LDL 100B,3

M = 00100 + 00002

= 00102

octal

binary

$$(00102B) = 24601357_8$$

010 100 110 000 001 011 101 1112

$$(Q) = 70770770_8$$

111 000 111 111 000 111 111 0002

$$(A) = 206003508$$

010 000 110 000 000 011 101 0002

Answer: (A) = 20600350

7.3 LOAD COMPLEMENTS

7.3.1 Load A Complement

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	LCA, I m, b
. 2 : 5 4 : 5 5 7 : 5	. 10 julijuljuljuljuljuljuljuljuljuljuljuljuljulj

23	18	17	16 15	14	00
24		а	b	m	

a = addressing mode indicator

b = index designator

m = storage address

Description: The instruction load A with the complement of the 24-bit word located at M, where $M = m + (B^b)$

Examples:

(ii) If index register 2 contains 00003

LCA 100B, 2
$$M = 00100 + (B^2) = 00103$$

(A) = 05647562

7.3.2 Load AQ Complement

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	LCAQ,I m,b
. & & * * * * *	n meter lit ite lie lie lie lie le le lec'hi i selse fan kalasian la la se lec'hi i se le se lec'hi i se lec'hi se lec'hi i se lec'h

23	18	17	16 15	14	00
26	3	а	b	m	

a = addressing mode indicator

b = index designator

m = storage address

Description: The instruction loads A with the complement of M, and Q with the complement of M + 1, where M = m + (B^b)

Examples:

(i) LCAQ 100B (using example above)

(A) = 41301256

(Q) = 10234567

(ii) If index register 3 contains 00002

LCAQ 100B, 3
$$M = 00100 + (B^3) = 00102$$

(A) = 35323526

(Q) = 05647562

7.4 LOGICAL "AND" OPERATIONS

7.4.1 Logical Product A

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
1.1	LPA,I
. 12 3 4 5 5 7 4	C in intilp in the legitum in legituissikajis diaalku kalikesis ajam ar imaja ja

23	18	17	16	15	14	00
37		а	t	,	m	

a = addressing mode designator

b = index register designator

m = storage address

Description: Replace (A) with the logical product of (A) and (M) (logical AND)

Examples: (i) LPA 100B where (100) = 55555555

(A) = 52525252

What will (A) be after execution?

(A) = 50505050

(ii) LDA MASK where (MASK) = 77777777 LPA CIØX and (CIØX) = 43752016

Answer (A) = 43752016

(iii) ENA,S 20301B where (MASK) = 77777777 LPA MASK

Answer (A) = 00020301

(iv) LDA STATUS where (STATUS) = 10203040

LPA STATMASK (STATMASK) = 76543210

Answer (A) = 10003000

7.4.2 AND of A and y

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ANA,S
::0;>;0;6;6;7;0	

23	18	17	16	15	14		00
17		1.	b			у	

b = 0, if sign extension

LOCATION		OPERATION, MODIFIERS ADDRESS FIELD
		ANA,S y
1121514151415141714	,	(\$ 11 12 14 18 18 18 18 18 18 18

23 18	17	15 14	00
17	4		у

b = 2, if no sign extension

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ANA y
: \$ > 4 5 6 7 0 6	

2	3 18	17	15	14	00
Ţ	17	6		У	

Description: Enter the 24 bit logical product of (A) and y (with sign extension if specified) into A. If sign extension is not specified, zeros are extended rather then the sign of y.

o II	0
1	0
0	0
1	1
	O 1 O 1

Note: The bit in A is a "1" only if both of the corresponding bits in A and y are "1's".

Examples:	(;)	A TAT A	23456B
examples:	111	ANA	2 54 700

(ii) ANA,S 23456B

(iii) ANA,S 43456B

(iv) ANA,S 70707B

7.4.3 AND of Q and y

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	
1111111	ANQ,S y	
	* 0 KT 12 10 14 12 16 14 17 18 14 120	30:3:[92/3 3 :34]35:84]37:
	23 18 17 16 15 14	00

b = 1, if sign extension

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ANQ,S
112121010161710	· CELEBRIA DE PATRIO DE RESPUENTENTENTA DE L'ARRENTE DE L

23 18	17 15	14 00
17	5	у

b = 3, if no sign extension

LOCATION		OPERATION MODIFIERS ADDRESS FIELD
		ANQ
-17124*161*271*	*	C [- 17 2 4 15 16 1 18 18 18 18 18 18

23	18	17	15	14		00
1	7	7			у	

Description: Enter the 24 bit logical product of (Q) and y (with sign extension if specified) into Q. If sign extension is not specified, zeros are extended rather then the sign of y.

Examples:

As for ANA,S

7.4.4 AND of Index Register Bb and y

GCATION	opination, Modifies	AGURESS FIELD	
	ANI	بنيني فرو	
44.1.234.1.4	4,,,17,,18,,,,18,,18,,18	 	e:3:122135;13 4 [35:34:17]

23	18	17	16 15	14	00
1	7	0	b	У	

b = index register designator (1-3)

Description: Enter the logical product of (Bb) and y into index register b.

Examples:

77B, 3 (i) ENI

> ANI 12B, 3

Index 3 contents = 00077

"AND" with 00012

00012

Answer: 00012 in index register 3

7.4.4 (cont.)

Examples: (Continued)

(ii) ENI 12345B,2

ANI 25252B, 2

(Index 3) = 12345

"AND" with 25252

00240

Answer: 00240 in index 2

7.5 EXCLUSIVE "OR" OPERATIONS

7.5.1 Selectively Complement A

L004540#	OPERATION, MODIFIERS	ADDRESS	FIELD
	SCA, I	m,b	
	1 Name of the last		Amerikan and Ameri

23 18	17	16 15	14 00
36	а	b	m

a = addressing mode designator

b = index register designator

m = storage address

<u>Description:</u> Selectively complements corresponding bits in A for all 1-bits at address M. (Exelusive OR)

Examples: (i) SCA

100B

where (100) = 70707070

(A) = 52525252

What will (A) be after execution?

Answer: (A) = 22222222

(ii) ENA,S 77777B where (MASKS) = 10203040 SCA MASKS

Answer: (A) = 67574737

(iii) ENA, S 40001B where (SIGN) = 40000001 SCA SIGN

Answer: (A) = (37740000)

(iv) LDA TAG where (TAG) = 77777777
SCA SETBIT (SETBIT) = 52525252

Answer: (A) = 25252525

(v) LDA GTRC where (GTRC) = 40000001 SCA GTRC

Answer : (A) = 0000 0000

7.5.2 Exclusive OR of A and y

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	XØA,S 4
(2 : 3 : 4 6 : 6 (7 : 5	* *** (

23	18	17	16 15	14	00
16	;	1	b	у	

b = 0, if sign extension

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	XØA,S
152333455145718	5 - 40 11 12 12 14 15 14 17 10 10 20 21 22 25 24 25 26 27 27 26 26 25 25 26 26 27 27 27 26 27 27

_	23 18	17	15 14	00
	16	4		у

b = 2, if no sign extension

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	XPA
: :7:3:4:0:4:7:4	

23	18 17	15 14	00
16		6	у

Description: Enter the 24 bit exclusive OR of (A) and y (with sign extension if specified) into A. If sign extension is not specified, zeros are extended rather then the sign

of y.

A	у	A
0	0	0
0	1	1
1	0	1
1	1	0

Note: The bit in A is a "1" only if the corresponding bits in A and y are different.

Examples: (i) XØA 44444B A = 33333333

$$38 = 011_2$$

$$48 = 100_2$$

$$OR = 7_8 = 111_2$$

(ii) XØA,S 44444B if A = 33333333

44444 is a negative number since $4_8 = 100_2$; therefore, find exclusive OR of (A) and 77744444.

$$3_8 = 011_2$$

$$7_8 = 111_2$$

$$OR = 4_8 = 100_2$$

(iii) XØA,S

40001B

Where A = 20117070

40001 is negative and equals 77740001 with sign extended, therefore

20117070 77740001 57657071

Answer: (A) = 57657071

7.5.3 Exclusive OR of Q and y

LOCATION	OPERAT	ION, MODIFIER	S ADDRESS	FIELD
	XØQ	,5	ું વ	11111111111
. 2 5 4 5 6 7 8	v (0)::1121	(8):415 (8):-210	رم در (۱۲۵) ۱۲۵ (۱۲۵) ۱۳۶	[85]26]87]28;34[36;5:[38]95]34;50[36]87;
	23	18 17	16 15 14	4 00

16

b = 1, if sign extension

LOCATION	OPERATION MODIFIERS ADDRESS FIELD
	XØQ,S 4
. [2]3]4]3[6]7]3	* 20 lin ing lantine lantine ban ing lantine lantine lantine lantine lantine lantine lanting indian indian indi

:	23	18	17	15	14		00
I	16			5		у	

b = 3, if no sign extension

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	XØQ	9	
13277,730161714	errore par erecentre pe	1	

23	18	17	1	5	14		00
16	}		7			у	

Description: Enter the 24 bit exclusive OR of (Q) and y (with sign extension if specified) into Q. If sign extension is not specified, zeros are extended rather then the sign of y.

Examples:

As for XØA,S

7.5.4 Exclusive OR of Index Register Bb and y

LOCATION	OPERATION, MODIFIERS ABORESS FIELD
	XØI 4,b
. 12:314:3:4:7;8	2 - 0 11 12 13 14 15 16 15 18 18 14 15 12 12 12 12 12 12 12

23 18	17	16 15	14	00
16	0	b	У	

b = index designator (1-3)

Description: Enter the exclusive OR of (B^b) and Y into B^b
No sign extension is possible on either (B^b) or y.

Examples:

(i) XØI 77B,1

where index 1 contains 32B

00032 = 000 000 000 011 010 00077 = 000 000 000 111 111 $000 000 000 100 101_2 = 00045_8$

Answer: Index register 1 will contain 45B

(ii) XØI 77777B,2

Where index register 2 contains 74321B 74321 = 111 100 011 010 001 77777 = 111 111 111 111 111 000 011 100 101 110₂ = 034568

Answer: Index register 2 contains 3456B

7.6 SELECTIVELY SET A

LOCATION	OPERATION, MODIFIERS ABBRESS FIELD
	SSA, I m, b
. :215:4:5:4:7:4	2

23 18	17	16 15	14 00
35	а	b	m

a = addressing mode designator

b = index register designator

m = storage address

Description:

Selectively set 1-bits in A for all 1-bits in M

N.B. This instruction leaves "l" bits which were already present in the register; i.e. it does not clear A before execution.

This instruction is performing an "inclusive OR" operation.

Examples:

- (i) SSA
- 100B

where (100) = 70707070

(A) = 52525252

What will (A) be after execution,

$$(A) = 72727272$$

(ii) ENA, S O where (ABIT) = 76543210 SSA ABIT

Answer: (A) = 76543210

(iii) ENA,S 21010B where (MØD) = 111111111 SSA MØD

Answer : (A) = 11131111

(iv) ENA, S 44444B where (MØD) = 111111111 SSA MØD


Answer: (A) = 77755555

CHARACTER MODE OF OPERATION

8.1 INTRODUCTION

8.2	CHARACTER	ADDDECC	INSTRUCTIONS
0.2	CHARACTER	MUNKEGO	TROTKOCH LONG

- 8.2.1 Load A Character
- 8.2.2 Load Q Character
- 8.2.3 Store A Character
- 8.2.4 Store Q Character
- 8.2.5 Store Character Address
- 8.2.6 Enter Character Address into A



8.3 INDEX MODIFICATION OF CHARACTER ADDRESSING INSTRUCTIONS

Data may be stored in two ways in the 3200. It may be stored in full words - that is, the information stored in 24 bits. Or, it may be stored in character form.

Each word in the 3200 may be broken up into four 6-bit characters, which are called characters 0, 1, 2 and 3 in the particular word, as shown:

23	18	17 12	11 06	05 00
	0	1	2	3

Information may be stored in characters, instead of in words, for convenience and economy. For instance, if we wish to store fifty digits, it could be more convenient to store them as 50 characters, to take up only 12½ words of storage, rather than put each digit into a separate computer word.

The computer is able to address any character in any word in storage. To find the character address of any particular character, the word address of the word containing the character is multiplied by 4; and the character position is added on.

The process is simpler if the arithmetic is done in binary. To multiply by 4 in binary you suffix two zeros to the righthand end of the number. The character positions are (in binary) 00, 01, 10 and 11. Therefore to find the character address:

- (i) Change the word address to binary
- (ii) Add the character position in binary as 2 extra low order bits
- (iii) Convert back to octal

Example: Character 2 in word 104

- (ii) Add on character position=001 000 100 10

 After regrouping bits •=00 100 010 010
- (iii) Convert to octal = 422B = Character Address

Exercise: Find the character addresses of the following characters.

Word Address	Character Position	Character Address
100	3	
405	1	
1 021	0	
477	2	
4001	1	
2664	0	
17777	3	

Similarly, if we know a character address, we can determine the word address in which the character is contained, and its position in the word.

8.1 (cont.1)

The steps are:

- (i) Convert to binary
- (ii) Remove the last two binary digits. (These are the character position)
- (iii) Convert the remainder to octal.

Example: Character address 422

- (i) Binary = 100 010 010
- (ii) Divide by 4 = 100 010 0_2 Remainder = 10_2 = 2_8 = Character Position
- (iii) Regrouped = 1 000 100_2 Octal = 104 = word Address


Answer - Character 2 in word 104

<u>Exercise</u>: (i) Find the word address and character position of the following character addresses:

- (a) 201
- (e) 2110
- (b) 3
- (f) 4231
- (c) 417
- (g) 16524
- (a) 555
- (h) 66666
- (ii) What is the smallest character address?
- (iii) What is the largest character address in an 8K computer?
- (iv) What is the largest character address in an 32K computer?

Character Address Instruction Format

The instruction format enables the address of a particular character in a word to be specified.



Character-Addressed Instruction Format

(i) Function Code (f)

6 bit code of action to be carried out.

(ii) Operation Designator (d) - 1 bit

If d = 1, modify address "m" by contents of a set index for the particular instruction.

If d = 0, no modifications.

(iii) Storage Address (17 bits)

The address of the character required is specified. This may be broken up into the module, field and co-ordinate address, as for word addressing, plus two bits to indicate the character position in the word.

8.1 (cont.2)

Exercise:

Assume that the following block of memory is in Field 1 of an 8K computer. What will be the character addresses of the characters marked x? The co-ordinate address of the first word in the block is 31248.

	l	 	X
	x		l
x	 	· · · · · · · · · · · · · · · · · · ·	1
		x	}
	x		! !
		x	
x			
	1		x

8.2 CHARACTER ADDRESS INSTRUCTIONS

8.2.1 Load A Character

LOCATION	OPERA	IION, MODIFIERS	ADDRESS	FIELD
	LAC	Н	707, /	
1215;*1515;7:	6 cm W	[4]:*:P[:F[:F]:*]	1	n[25:88]5:]28[25:30]5:[38]35[39]30:[36]47.
	23	18 17 1	16	00

22 b m

m = 17 bit character address

b = index designator - but can be only one bit, so has special use. See section on indexing(section 8.3).

Clears (A) and loads into bits 00-05 of A, the Description: contents of the character specified by M. (m + (B1))

Examples:

(i) LACH 403B

- (A) = 40012431
- (100) = 01020304
- (400) = 05060701
- (403) = 02030405

What will be the contents of the A Register?

- (A) = 00000004
- since 403B (char.)
 - = 100B (word) pos. 3.
- (ii) LACH 5B

What will be the contents of the A Register after execution?

0	01234567
1	. 12345670
2	23456701
3	34567012
4	45670123
5	5670 1234

(A) = 00000034

(iii)

LACH HRTABLE+3 HRTABLE BSS

HRTABLE	01 23	45	67	
	12 34	56	70	
	11 1.22	33	44	
	55 1 66	77	00	

What will be the (A) after execution?

- (A) = 00000067
- (iv) In (iii) what would be the (A) if the instruction was LACH HRTABLE+13B (A) = 00000044

8.2.2 Load Q Character

LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD	
	LQCH	m,2	
1211413141712	s <u>erio incindira incindira na</u>	(10:3:18:183)34(83/84/83)84(13:8:24(30)	31 [22] 93 [34] 35 [34] 97 [

23 18	17	16	00
23	b	m	

Same as LACH except substitute Q Register for A Register, Description: and it uses a different index register (which also is

different from SQCH)

8.2.3 Store A Character

LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD
	SACH	m,2
	10 11 11 11 11 11 11 11 11 11 11 11 11 1	

	23	18	17	16 00
-	42		b	m

m = 17 bit character address

b = index designator - but can be onlyone bit, so has special use. See section 8.3 on indexing.

Description: Store the contents of bits 0-5 of the A Register in the specified character address.

N.B. The contents of A and the remaining 3 characters in the storage word, are unchanged.

Examples:

(i) SACH 43B if (A) 20012345

> Which character position of which word is affected, and what will be the contents of the character position?

Answer: (1) Word 10

- (2) Position 3
- (3) 45B
- (ii) SACH $L \not C + 3$ (A) = 11560133

LOC BSS 5

LØC 00 11 22 01 02 03 04 05 06 07 **00**

What changes will be made to the 5 words shown?

 $(L \not O C) = 00112233$

i.e. no change!

8.2.4 Store Q Character

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	SQCH	m, l	
- 12:5.4:5[6:7.	* - - - - - - - - -	40:31:72:88/74	(TY: #8 (T) P# (2 + 30 X) 22 35 Y 4 25 36 17

23 1	8 17	16	00
43	b	m	

Description: Same as SACH except substitute Q register for A register, and it uses a different index register (which also is different then that used by LQCH)

8.2.5 Store Character Address

LOCATION	_	OPERATION, MODIFIERS	ADDRESS	FIELD	
		SCHA	m,b	السلسة	
			! 	1771841	E: 24 75 30 51 32 35 144 30 36,37

23 18	17	16 15	14 00
46	а	b	m

a = addressing mode designator

b = index register designator

m = storage address

Description:

Stores the lower 17 bits of (A) in the lower 17 bits of word M. The upper bits of M and the whole of A are unchanged. The instruction is used for character address modification. Compare with SWA instruction.

Examples:

(i) SCHA 50B (A) =
$$10747021$$

$$(50) = 23064513$$

What will be the contents of 50 after execution?

$$(50) = 23347021$$

If (A) = 11117643 when 100 is executed, what will be the contents of 101 after execution?

Answer: (101) = 22117643

8.2.6 Enter Character Address into A

LOCATION	OPERATION, M	ODIFIERS	ABBRESS	FIELD	
11111111111	ECHA,S	لـــــــــــــــــــــــــــــــــــ	9	: : :	14:35:36:37:1
	23 18	3 17 1	16		oc
	11	d		y !	

d = 0, if no sign extension

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ECHA 4
: ₹ > × 5 6 7 6	o Et linter tratter tratter in the control of the c

23	18	17	16 00
1	1	0#	У

d = 1, if sign extension

LOCATION	OPERATION MODIFIERS	ADDRESS FIELD	
	ECHA, S	9	
1	1	Committee of the second of the	

23 18	17	16 00
11	4+	У

 $\frac{\text{Description:}}{\text{When d}} \quad \text{Enters the 17 bit quantity "y" into the A register.} \\ \text{When d} = 1, \text{ the sign of the quantity } (2^{16} \text{ bit) is}$ extended in A. When d = 0, the upper 7 bits of the A register are set to zero. "y" is usually a character address. If "y" is a symbolic word address, the actual machine address is multiplied by 4 before it is assembled in the instruction.

Examples:

(i) It ØUTBUF is character position 3 in the word at word address 100, what would be the contents of A after:

> ECHA **ØUTBUF**

Answer:

(A) = 00000403

(ii) What would be the contents of A after execution of:

ECHA 117640B

Answer:

(A) = 00117640

(iii) If TABLE starts at word address 40000, what would be the contents of A after:

ECHA TABLE

Answer:

(A) = 00200000

ECHA, S TABLE

Answer:

(A) = 77600000

8.3 INDEX MODIFICATION OF CHARACTER ADDRESSING INSTRUCTIONS

Character address instructions have limited indexing ability.

1			
1	f	h	m (17 bits)
1	-	١ ٠	1 " (1, 2163)

b is only one bit, therefore it can only indicate whether a specific index is used or not used.

i.e. If the "b" bit is set, the address is modified by either (B^1) or (B^2) depending on the particular instruction.

LACH m,1
LQCH m,2
SACH m,2
SQCH m,1

Also, if the 'm' address is at one or the other end of a table, the table is limited in length to 16383_{10} characters.

i.e. If TABLE equals word address \$0000B (character address =
100000B) and the instruction is:

LACH TABLE, 1

(i) and $(B^{\frac{1}{2}}) = 40000B$ 77740000 the character address referenced = $\frac{00100000}{040001}$

(ii) or (B¹) = 77776B 77777776 the character address referenced = $\frac{00100000}{0777777}$

(iii) or $(B^1) = 00000B$ 00000000 the character address referenced 00000000

(iv) or $(B^1) = 00001B$ 00000001the character address referenced 00100000

(v) or $(B^1) = 37777B$ 00037777 the character address referenced 00100000

Note: If the index register contains 40000 thru 77776 the reference is backward in memory, whereas if the index register contains 00001 thru 37777 the reference is forward in memory. This means that when writing programs in COMPASS, FORTRAN, ALGOL or COBOL one should be careful not to exceed 1638310 when defining character arrays.

Examples: In the following examples assume the contents of the index registers to be:

$$(B^1) = 5$$

$$(B^2) = 2$$

$$(B^3) = -3$$

(i) LDA LABEL+1,3

STA	LABEL,2		-11111111
	ŕ		22222222
LDQ	LABEL,2		33333333
	rill be the contents	LABEL	4444444
•	m segment above?		55555555
(Q) =	2222222		66666666
(w/ =	~~~~~~~		דררדרד

(ii) LACH LABEL, 1

What will be the contents of A?

Answer (A) = 00 00 00 55

Exercises:

- A block of memory (maximum length = 100 words) contains numbers stored one to a word. The end of the list is indicated by a word containing BCD blanks. Write a routine which will add the numbers in the list. (Use indexing.)
- Transfer 57 words located 4 memory locations apart, into 57 consecutive memory locations.
- 3. Transfer 17 words located 5 memory locations apart, into 17 words located 10 memory locations apart.
- 4. Calculate the sum of the octal numbers 0-14.

INTER-REGISTER TRANSFERS

- 9.1 TRANSFERS BETWEEN THE A REGISTER AND INDEX REGISTERS
 - 9.1.1 Index Register to A Register
 - 9.1.2 A Register to Index Register
- 9.2 TRANSFERS BETWEEN THE A REGISTER AND THE REGISTER FILE
 - 9.2.1 Register File to A Register
 - 9.2.2 A Register to Register File

Chapter 9

- 9.3 TRANSFERS BETWEEN THE Q REGISTER AND THE REGISTER FILE
 - 9.3.1 Register File to Q Register
 - 9.3.2 Q Register to Register File
- 9.4 TRANSFERS BETWEEN INDEX REGISTERS AND THE REGISTER FILE
 - 9.4.1 Register File to Index Register
 - 9.4.2 Index Register to Register File
- 9.5 INTER-REGISTER ADDITION
 - 9.5.1 Add Contents of Q to Contents of A
 - 9.5.2 Add Contents of Index Register to Contents of A
 - 9.5.3 Add Contents of A to Contents of Index Register

9.1 TRANSFER BETWEEN THE A REGISTER AND INDEX REGISTERS

9.1.1 Index Register to A Register



23	18	17	16	15	14	12	11	00
53		0		b		0		

b = index designator (1-3)
bits 0-11 are not used

Description: Transfer the 15-bit contents of index register Bb to A. (A Register is cleared before the transfer is done.)

Example:

TIA 2

- (a) clear A = 0000 0000
- (b) transfer 15 bits in ${\ensuremath{\mathsf{B}}}^2$ to lower 15 bit positions of A

$$(A) = 0005 4321$$

9.1.2 A Register to Index Register

LOCATION	OPERATION, MODIFIERS ABORESS FIELD
	TAI
1715 4:518 1718	5 :- 1:: 3:14 15 6 1:: 4 6 15 2: 7: 4 24 24 4 21 4 24 40 3 4 4 4 4 4 4 4 4 4 4 4 4

b = index designator (1-3)
bits 0-11 are not used

Description: Clear index register B, and transfer the lower 15 bits of (A) to it.

Example: If B3 contains 21B and A contains 7643 1000

TAI 3

- (a) Clear Index 3
- (b) Load it with lower 15 bits of A

$$(B^3) = 31000$$

9.2 TRANSFERS BETWEEN THE A REGISTER AND THE REGISTER FILE

(The Register File is a special high speed memory of 100_8 locations numbered from 00_8 - 77_8 .)

9.2.1 Register File to A Register

LOCATION	OPERATION, MODIFIERS	APPRESS	FIELD
	TMA	יי עו	<u> </u>
	\$101071414151515101419,	49:11171,88124	25/88 (K: 188/24/2015/195/32/14/97/36/27/1

23	18	17	16	15	14	12	11	06	05	00
53		0			2	!			ı	n

m = Register File Address (00-77)

Bits 6 - 11 and 15 - 16 are not used.

Description: Transfer the contents to Register file m to A A is cleared prior to the transfer.

Example: If A = 0000 0006, and Register file 20 = 0000 0014, what will be in A after execution of the following instruction?

TMA 20B

Answer: (a) A is cleared

(b) Contents of Reg. File 20 put in A

(A) = 00000014

9.2.2 A Register to Register File

LOCATION	_	OPERATION, MODIFIERS ADDRESS FIELD
		TAM
12:5,*1>16:17:8	_	

m = Register File Address (00-77)Bits 6 - 11 and 15 - 16 are not used.

<u>Description</u>: Register file m is cleared, and the contents of the A register are transferred to m.

Example: If (A) = 0000 1000

Register file 30 = 0000 0777

TAM 30B

Answer: (a) Register file 30 is cleared

(b) Contents of A placed in Reg. file 30

(Reg File 30) = 00001000

9.3 TRANSFER BETWEEN THE Q REGISTER AND THE REGISTER FILE


9.3.1 Register File to Q Register



23 18 17 16 15 14 12 11 06 05 00 53 0 1 m

Description: As for TMA except uses Q register

9.3.2 Q Register to Register File



. Description: As for TAM except uses Q register

9.4 TRANSFER BETWEEN INDEX REGISTERS AND THE REGISTER FILE

9.4.1 Register File to Index Register

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	TMI m,b

23	18	17	16	15	14	12	11	06	05	00
53	3	0		b	3	3			Į n	n

b = index register designator
m = register file address (00-778)
bits 06-11 are not used

Description: Transfer the lower 15 bits of Register m to Index B. Index is cleared before transfer.

Example: Index register 3 contains 00010, and Register file 25 contains 0000 2000.

What will be in ${\bf B}^3$ after execution of the following statement?

TMI 25B,3

- (a) Index 3 is cleared
- (b) Lower 15 bits of Register file 25 are put in it. $B^3 = 02000$

9.4.2 Index Register to Register File

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	TIM , , , , , , , , , , , , , , , , , , ,
1 12 14 14 15 15 17 18 5	0 (d. 175 (d.

23	18	17	16	15	14	12	11	06	05	00
5	3	1	t	,	- 3	3			[r	n

b = index register designator
m = register file address (00-778)
bits 06-11 are not used

Description: Clear Register file M, and transfer to it the contents of index register B^b.

Example: (i) Index 3 contains 22B

TIM 26B,3

 $(M_{26}) = 0000 0022$

9.5 INTER-REGISTER ADDITION

9.5.1 Add Contents of Q to Contents of A

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	AQA
. 12 5 5 5 5 5 7 7	

23 18	3 17 15	14 12	11	00
53	0	4		

Description: Transfer the contents of A plus the contents of Q to A. No information is given in the address field in this instruction.

Example:

If (A) = 0000 1000

(Q) = 0000 4104

What will be A after execution of the following instruction?

AQA

Answer:

(A) and (Q) are added together and put in A

(A) = 00005104

9.5.2 Add Contents of Index Register to Contents of A

LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD
	ALA	b
	 - -	

23	18	17	16	15	14	12	11	00
53		0	b	,	T .	4		

b = index register designator (1-3)

Description:

Transfer the contents of A plus the contents of B^b to A. The contents of B^b is sign extended to perform the addition.

Example:

If(A) = 0000 0100

 $(B^2) = 01404$

What will be in A after execution of the following instruction?

AIA

Answer:

(A) and (B2) are added and the result stored in A

(A) = 00001504

9.5.3 Add Contents of A to Contents of Index Register

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	
	IAI	2
		37:

23	18	17	16	15	14	12	11	00
53		1	t	,	4	1		

b = index designator (1-3)

Description:

The contents of A are added to the contents of Index Register (B^b) and the result stored in B^b . The sign of the original B^b is extended prior to addition, and only the lower 15 bits of the answer are placed in B^b .

Example:

$$(B^2) = 00006$$

$$(A) = 0000 0007$$

What will be the contents of index register 2 after execution of the following statement?

IAI 2

Answer: $(B^2) = 00015$

Exercises:

(i) If
$$(B^3) = 40001$$

$$(A) = 0000 0007$$

What will be the contents of B³ after execution of the following instruction?

IAI 3

(ii) If
$$(B^1) = 40001$$

$$(A) = 1000 0007$$

What will be the contents of B^1 after execution of the following instruction?

IAI

SEARCH AND MOVE OPERATIONS

- 10.1 BLOCK CONTROL
- 10.2 SEARCH OPERATIONS
 - 10.2.1 Search for Character Equality
 - 10.2.2 Search for Character Inequality
- 10.3 MOVE INSTRUCTION
- 10.4 PAUSE INSTRUCTION

(as used with SEARCH/MOVE Instructions)

Chapter 10

10.1 BLOCK CONTROL

Block control is an auxiliary control section within the 3200 processor. In conjunction with the register file (see section 1.2.5) and program control (see section 1.2.4), it directs the following operations:

- (a) External equipment Input/Output
- (b) Search and Move operations
- (c) Real time clock
- (d) Console typewriter Input/Output
- (e) High speed temporary storage in the register file.

Block control is called in to initiate Search/Move operations. When the operation is initiated, it then hands control back to program control, allowing program execution to continue while the Search/Move operations are being carried out.

Note that only one operation at a time can take place under Block control. An attempt to initiate, say, a Move operation while a Search operation is in progress, will cause the Move operation request to be rejected, and Program control will skip to the reject address following the instruction.

10.2 SEARCH OPERATIONS

10.2.1 Search for Character Equality

LOCATION	OPERATION, MO	DIFIERS	ADDRESS FIELD	
	SRCE, I	NT,	C, F., M.	بينين
لفرد بغنفره بفيفيه		·F;-7]/#1/	\$ (\$00 \$1 \$2 \$2 \$2 \$2 \$3 \$2 \$4 \$2 \$2 \$2 \$2 \$2 \$2	132/24/22/36/32/
	23 18	17	16	00
P	71	INT	^m 2	
	23 18	17	16	00
P + 1	С	0	ml	

INT = Interrupt designator

"1" = Interrupt at completion of search

"O" = Do not interrupt at completion of search

= 008-778, BCD character to be looked for in memory

 m_1 = First character address to be checked

 m_2 = Last character address plus 1 to be checked

Description: This instruction attempts to INITIATE a search through a block of characters in storage, looking for a character equal to character ${}^{\shortparallel}C^{\shortparallel}$ (specified in the instruction.)

> SEARCH INITIATE POSSIBLE, i.e., the search/move section of block control is not busy. The instruction transfers the lower 18 bits of the first word of the instruction to register file address 30 and transfers all of the second word of the instruction to register file address 20. The hardware then sets flags in the upper 6 bits of register file address $30\,\mathrm{_{k}}$ the search is started and the computer RNI's from P+3. (During the search, register file addresses 20 and 30 are not to be disturbed, also the upper six bits of register file address 30 cannot be counted on to be any particular combination of bits).

SEARCH INITIATE NOT POSSIBLE, i.e., the search/move section of block control is busy. The instruction in this case executes as if it were a NOP (no operation instruction). It has no effect on the search/move section of block control, the register file or the interrupts if a search cannot be initiated. P+1 will be bypassed and RNI will be from P+2. This latter location is usually filled by the programmer with

> *-2 UJP


to cause the computer to loop until the previous search/ move operation is complete and the search can be started.

BUFFERED SEARCH. The search progresses while other instructions following the search initiate instruction are executed. The search is made, beginning at character address m_1 and continues character by character through memory until a character equal to "C" is found or until the address to be processed is equal to m2. The programmer can find out that the search is complete at the instant it terminates or when he is ready to check. The first is achieved with the interrupt designator, the second by using a sense instruction (both of which are to be covered later).

Assuming that the programmer knows the search has completed, he can now determine if he found a character equal to character "C". If the lower 17 bits of register file address 20 and 30 are equal, no match was found. However, if they are unequal, the lower 17 bits of register file address 20 will contain the exact character address where the match with character "C" occurred. No ambiguity is possible, since register file address 30 (lower 17 bits) contains the last character address to be searched plus one; if the lower 17 bits of register file address 20 is equal to this address, the hardware has checked all addresses to be checked and is beyond the block of characters.

Example:

Given the block of data shown



SRCE

73B, CDIMAGE, CDIMAGE+80

what address will be in the lower 17 bits of register file address 20 at the termination of the search?

Answer: The address equal to CDIMAGE+8. If CDIMAGE is equal to word address 1000g (character address 40008), then (register file 20, Lower 17) = 004010_{8}

Special Note: When checking for a no-find condition at termination of the search, the checking is easier if the block to be searched is less then $32768_{\mbox{\scriptsize 10}}$ characters. If this is the case, one of the following two methods can be used:

 $(m_2 \text{ address fixed and lower two bits} = 00_2)$


20B TMA SHA -2 ASE endaddr UJP find


 $(m_2 \text{ address variable or lower two bits } \neq 00_2)$

30B TMA *+2 SWA TMA 20B ** ASE UJP find

10.2.2 Search for Character Inequality

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	SRCN, INT c, m, m2
, , , , , , , , , , , , , , , , , , , ,	





INT = Interrupt designator

"1" = Interrupt at completion of search

"O" = Do not interrupt at completion of search

 $C = 00_8 - 77_8$, BCD character to be checked against

m₁ = First character address to be checked

 m_2^- = Last character address plus 1 to be checked

Description:

This instruction attempts to INITIATE a search through a block of characters in storage, looking for the first character not equal to the charater "C" (specified in the instruction.)

SEARCH INITIATE POSSIBLE, i.e., the search/move section of block control is not busy. The instruction transfers the lower 18 bits of the first word of the instruction to register file address 30 and transfers all of the second word to the instruction to register file address 20. The hardware then sets flags in the upper 6 bits of register file address 30, the search is started and the computer RNI's at P+3. (during the search, register file addresses 20 and 30 are not to be disturbed, also the upper six bits of register file address 30 cannot be counted on to be any particular combination of bits.)

SEARCH INITIATE NOT POSSIBLE, i.e., the search/move section of block control is busy. The instruction in this case executes as if it were a NOP (no operation instruction). It has no effect on the search/move section of block control, the register file or the interrupts if a search cannot be initiated. P+1 will be skipped and RNI will be from P+2. This latter location is usually filled by the programmer with


to cause the computer to loop until the previous search/move operation is complete and the search can be started.

BUFFERED SEARCH. The search progresses while other instructions following the search initiate instruction are executed. The search is made, beginning at character address \mathbf{m}_1 and continues character by character through memory until the first character not equal to "C" is found or until the address to be processed is equal to \mathbf{m}_2 . The programmer can find out that the search is complete at the instant it terminates or when he is ready to check. The first is achieved with the interrupt designator, the second by using a sense instruction (both of which are to be covered later.)

Assuming that the programmer knows the search has completed, he can now determine if there were any characters other then the character "C" and where the first of those occurred. If the lower 17 bits of register file address 20 and 30 are equal, no characters others then "C" exist in the block. However, if they are unequal, the lower 17 bits of register file address 20 will contain the exact character address where the first character other then "C" occurred. No ambiguity is possible, since register file address 30 (lower 17 bits) contains the last character address to be searched plus one; if the lower 17 bits of register file address 20 is equal to this address, the hardware has checked all addresses to be checked and is beyond the block of characters.

Example:

Given the block of data shown



(word address of this last word is CDIMAGE+19) (character address of this last character is CDIMAGE+79)

and the instruction

SRCN

60B, CDIMAGE, CDIMAGE+80

what address will be in the lower 17 bits of register file address 20 at the termination of the search?

Answer: The address equal to CDIMAGE+9.

If CDIMAGE is equal to word address 10000_8 (character address 40000_8), then the contents of register file address $20_{1ower\ 17\ bits}=040011_8$

Special Note: See the Special Note for the SRCE instruction (Section 10.2.1) for techniques in determining type of termination.

LOCATION	OPERATION MODIFIERS ADDRE	SS FIELD	
	MOVE, INT young	F	
12:5:4:5:5:7:18	- 10 1-12 11:14 14 14 14 14 14 14 14 14 14 14 14 14 1	[24,[3] 86,[3] 81,28,30 31,28]):	ijs <u>+;30]86 37</u> ;
	23 18 17 16		00
Р	23 18 17 16 72 INT	^m 2	00

INT = Interrupt designator

 m_1

"1" = Interrupt at the completion of the Move "0" = Do not interrupt at the completion of the Move

y = Number of characters to be Moved

If $y = 001-177_8$, $001-127_{10}$ characters are Moved If y = 000 , 128_{10} characters are Moved

m₁ = First character address of data source

 m_2^1 = First character address of data destination

Description:

This instruction attempts to INITIATE the copying of a block of "y" characters in one area in storage into a second area of storage. "y" is specified in the instruction.

MOVE INITIATE POSSIBLE, i.e., the search/move section of block control is not busy. The instruction transfers the lower 18 bits of the first word of the instruction to register file address 31 and transfers all of the second word of the instruction to register file address 21. The hardware then sets flags in the upper 6 bits of register file address 31, the move is started and the computer RNI's at P+3. (During the move, register file addresses 21 and 31 are not to be disturbed, also the upper six bits of register file address 31 cannot be counted on to be any particular combination of bits.)

MOVE INITIATE NOT POSSIBLE, i.e., the search/move section of block control is busy. The instruction in this case executes as if it were a NOP (no operation instruction). It has no effect on the search/move section of block control, the register file or the interrupts if a move cannot be initiated. P+1 will be skipped and RNI will be from P+2. This latter location is usually filled by the programmer with

UJP *-2

to cause the computer to loop until the previous search/move operation is complete and the move can be started.

BUFFERED MOVE. The move is made beginning at character address m_1 (source) and m_2 (destination) and continues through memory until "y" characters have been moved. If both m_1 and m_2 are character addresses that represent character position 0 and the number of characters to be moved is a multiple of four, the data is copied a word at a time. If all three conditions are not met, the copying proceeds a character at a time. The word move only takes one-fourth the time of a character move for the same number of characters, so should be used when possible. As soon as the "y" characters have been moved, the move operation terminates and the search/move section of block control reverts to the not busy status.

Exa	mp	1	8	8

Given the block of data shown,

MOVE	6,410B,424B	_	Γ_			
UJP	*- 2	101	21	14	16	32
	_	102	60	60	60	60
		103	21	31	41	21
		104	60	60	60	60
		105	17	01	17	01
	in storage at end E Operation?	106	25	25	25	25
Anawane						
Answer		101	21	14	16	32
		102	60	60	60	60
		103	21	31	41	21
		104	60	60	60	60
		105	60	60	60	60
		106	21	31	25	25

Special Note: If "y" is set by the programmer, he should remember that it is 7 bits. A SACH (or SQCH) into the upper 6 bits of "y" represents a character move of twice the number represented by $(A_{1ower\ 6})$ or $(Q_{1ower\ 6})$ (or is twice+1 depending on the least significant bit of the original "y").

Techniques for changing "y":

Word Move, "y" originally set to 0, number of words to be moved in A register (right justified).

SHA 1 SACH Moveinst+4

Word Move, "y" current contents unknown, Number of words to be moved in A register (right justified).

SHA 2 LDQ Moveinst+1 SHQ 7 SHAQ 17 STA Moveinst+1

Character Move, Number of characters to be moved in A register(right justified).

LDQ Moveinst+1 SHQ 7 SHAQ 17 STA Moveinst+1

Also if the source and destination blocks overlap, be sure that the source address is the higher address in memory or some of the source data will be destroyed.


LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD
111111	PAUS	4000B
. : 2 : \$: 4 : 5 : 5 : T : 5	v (0::::::::::::::::::::::::::::::::::::	

23 18	17 15	14 12 11	00
77	6		4000

Description: Once the main program has begun a Search/Move operation, it hands over control of that part of the program to the Search/Move section of Block Control. The main program is then resumed at P + 3. If it is necessary to find the result of the Search/Move operation before the main program goes on with further calculations, etc, the PAUS instruction is used.

> This instruction senses the status of the Search/Move section of Block Control. If it is busy, the machine main control pauses for 40 msec., or until the Search/Move section becomes not busy. If it stays busy for 40 msec., the computer RNI's at P+1. If it was originally not busy or becomes not busy during the 40 msec. interval, the computer RNI's at P + 2.

> At the completion of a Search/Move operation, Register File Location 20 contains the final current word address for a Search operation and Register File Location 21 contains it for a Move. The contents of that word is generally not useful to the programmer in the case of a Move, but is quite important in the case of a Search. Here is how the word at Register File Location 20 is divided:



Examples: i) The instructions to be performed are:

The block of characters to be searched is:

SRCN UJP	21B,400B,414B *-2	100	21 21 21 21
PAUS U.IP	4000B *-1	101	21 21 21 21
TMA HLT	20B	102	21 21 20 21

What will be the contents of the A register when the computer halts on the HLT instruction?

		23	18	17	16		00
Answer:	(A) = 21400412 =	2	1	1		000414	

ii) Given the block of data shown, where the word address of RHT = 17714_8 , what will be the contents of A after execution of:

SRCE UJP	21B,RHT,RHT+33 *-2	RHT	00	00	00	25
PAUS	4000В	i	00	00	00	31
UJP *-1 TMA 20B		00	00	00	46	
			00	00	00	27
			03	21	60	60
			00	00	00	41
			00	00	00	31
			77	77	77	77

Answer: (A) = 21077501

iii) If the word address of STØRE is 17717 $_8$, and the character address of CEASE is 77514 $_8$, given the block of data shown, what will be the contents of A after execution of:

SRCN UJP	, ,	STØRE	60	60	60	60
PAUS	4000В		60	60	60	60
TMA	JJP *-1 TMA 20B		60	60	21	60
			60	60	60	6Ö

Answer: (A) = 60477506

STØRE = word addr
$$17717_8 = 001 \ 111 \ 111 \ 001 \ 111_2$$
 = char position $0_4 = 00_2$ = char address 001 111 111 001 111 00_2 regrouped = 00 111 111 100 111 $100_2 = 77474_8$

iv) If the word address of INBUFF is 17000_8 and the word address of ØUTBUFF is 17400_8 and the number of characters to be moved is 8, what will be the contents of the A register after the move is complete?

```
MØVE 8,INBUFF,ØUTBUFF
UJP *-2
PAUS 4000B
UJP *-1
TMA 21B
```

Answer: (A) = 00074010

At the start of the Move, the contents of Register file location 21 was:

- Exercises: i) INBUFF currently contains a card image. Somewhere in the card image is a comma. Write the code that will search for the comma and then copy all the information up to the comma into an output area called ØUTBUFF. ØUTBUFF is large enough to contain all of INBUFF.
 - ii) ZUP currently contains a twelve digit BCD number with leading zeros. Using the Search Instruction, find the most significant digit and replace all leading zeros with 60B codes.
 - iii) Using the Search instruction, check the character in the A register against a table of characters, seven characters long. The table is as follows:

FTNØP 13 20 34 40 54 61 74 00

If the character is equal to any of these characters, transfer control to location WAS \emptyset P, otherwise continue to the next section of code.

STORAGE TESTS

- 11.1 MASKED EQUALITY SEARCH
- 11.2 MASKED THRESHOLD SEARCH
- 11.3 STORAGE SHIFT
- 11.4 COMPARE (WITHIN LIMITS TEST)

Chapter

LOGATION	OPERATION, MODIFIERS	AUDRESS FIELD
	MEQ	# <u>}</u>


2	3 18	17 15	14	00
	06	i	m	

i = 0 thru 7 = interval designator

m = storage address (of first word)

Description: (A) is compared with the logical product of (Q) and (M) where $M = m+(B^1)$

NOTE: This instruction uses B¹ exclusively.



N.B. i = 1 means interval 1

Examples: (i) Given the following conditions:

$(B^1) = 5$	100	00674320
(Q) = 777777778 (A) = 606060608	101	21314367
(11)	102	60606060
	103	67676767
	104	47532167

and the following program section:

ENI	5 ,1
ENQ,S	-0
MEQ	100B,1
UJP	NØFIND
INI	100B,1
STI	FIND.1

do the following:

Answer:

(a) Decrement B by 1 and calculate M.

$$M = m + (B^1)$$

$$= 100 + 4$$

$$= 104$$

(b) Compare (A) with logical product of (Q) and (104)

which is not equal to A.

(c) Decrement B1 by 1 and repeat

(d) Decrement B¹ by 1 and repeat

(e) Contents of FIND = 102.

11.2 MASKED THRESHOLD SEARCH


LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	MTH	w,i	\
121313131313	* ::::::::::::::::::::::::::::::::::::	1	1271 FF 127 128 124 132 11 122 12 12 12 12 12 12 12 12 12 12 1

23	18	17	15	14		00
07	7	i			m	

i = 0 thru 7 = interval designator

m = storage address (of first word)

<u>Description</u>: This instruction is similar to the MEQ; the only differences being that RNI from P+2 occurs when $(A) \geqslant (Q) \times (M)$, and that index B² is used exclusively.



Example: Given the following conditions and program section:

MTH	100B,2
UJP	NØFIND
INI	100B,2
STI	FIND,2

- a) What will be the contents of FIND after this program section is executed?
- b) What locations will have been checked?


Answers: a) $(FIND) = 00000102_8$

b) Locations checked = 104B and 102B

INCATION	OPERATION, MODIFIERS ADDRESS FIELD
LUCHIUR	GLEXT. CO. PROFITE A
	SSH M M M M M M M M M M M M M M M M M M

23	18	17_	15	14		00
1	0	()		m	

<u>Description</u>: Sense bit 23 of (m). Shift (m) one place left, end around, and replace it in storage. If bit 23 of (m) was a 1-bit, RNI from P+2, if O RNI from P+1.



Examples:

First time through (100) = 101 010 101 010 101 010 101 010 which is negative, so RNI at P + 2.

Second time through (100) = 010 101 010 101 010 101 010 101 which is positive, so RNI at P+1 and jump to Halt.

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	CPR, I m, b
. (2.1.*.5)\$ (*.18);	\$ -0.1-11-1-15-1

23 18	17	16 15	14 00
52	а	b	m

a = addressing mode designator

b = index designator

m = storage address

Description:

The Compare, within limits test, instruction, is a two phase instruction. The first phase compares the contents of the M address against the contents of the A register. If the contents of memory is larger, the computer RNI's at P+1. If the contents of memory is less than or equal to the contents of the A register, the instruction proceeds to the second phase of the test. This phase compares the contents of the Q register against the contents of the M address. If the contents of Q is larger, the computer RNI's at P+2. If the contents is less than or equal to control passes to P+3.

Summarized: If (M) > (A), RNI at P + 1 otherwise, next test

If (Q) > (M), RNI at P + 2 otherwise, RNI at P + 3

Expanded these relations become:

All possible relationships between A, ${\bf Q}$ and ${\bf M}$ are shown.

Normally, the value in the A register is greater than or equal to the value in the Q register. If this is the case, the following indicates the action of the instruction.

(M) > (A)
$$\frac{}{}$$
 RNI at P + 1
(A) \geqslant (M) \geqslant (Q) $\frac{}{}$ RNI at P + 3
(Q) \geqslant (M) - RNI at P + 2

While the instruction is almost always used in situations where the contents of A is greater than or equal to the contents of Q, occasionally it is not. Following is a discussion of the instruction in these alternate uses.

Stated in shorthand form, where the contents of the A register is less than the contents of the Q register, the instruction behaves as follows:

(M) > (A) RNI at P + 1 otherwise, RNI at P + 2

Note: RNI at P + 3 is not possible because if $(M) \leq (A)$ then (M) < (Q) as (A) < (Q).

Reversing positions of A and M, the branching conditions become:

(A) \langle (M) RNI at P + 1 (A) \rangle (M) RNI at P + 2

This then is nothing more then an ASG with a full 24 bit operand. However, one value that A can take on is troublesome and that is 37777777. When this is the contents of A, (A) < (Q) is not possible as 37777777 is the largest possible positive number.

While this form of the instruction looks useful, it rarely is used as it can usually be replaced by a load Q and an AQ test. The coding that way ends up shorter and executes faster.

Another possible use of the instruction exists where the contents of the A register is set to 377777778 or the contents of the Q register is set to 4000000088.

In the case where (Q) is set to 40000000_8 , the instruction acts as follows:

(M) > (A) RNI at P + 1 otherwise, RNI at P + 3

This looks very much like the previous form except for the RNI's. It is essentially an A skip greater than or equal to where the skip is two words rather than one. Since P+2 is unused, M can be set equal to it with (M) equal to the test value.

e.g. LDQ = \$\psi40000000\$

CPR *+2

UJP less-than-routine

\$\psiCT\$ test-value

greater-than-or-equal-condition-next-instr.

In the case where (A) is set to 377777778, the instruction acts as follows:

(Q) > (M) RNI at P + 2 otherwise, RNI at P + 3

This is essentially a Q test. Also since P+1 is unused, M can be set equal to it with (M) equal to the test value.

e.g. LDA =\$37777777

CPR *+1

\$\phi\$CT test-value

UJP greater-than- routine

less-than-or-equal-condition-next-instr.

Note in both of the two previous forms that A or Q must be set prior to the execution of the instruction and both A and Q are in use. Here as with the condition earlier, a load A or a load Q coupled with an AQ test usually produces shorter code which executes faster.

Still another possible use of the instruction exists where the contents of the A register is set equal to the contents of M or the contents of the Q register is set equal to the contents of M_{\bullet}

Where (Q) = (M), the instruction executes as indicated:

(M) > (A) RNI at P + 1 otherwise, RNI at P + 3

This is similar to the case where the contents of Q is set to $40000000_{\rm R}$. As in that case, P + 2 is unused. Therefore, M can be set equal to P + 2 with (M) set equal to (Q) during execution.

e.g. STQ *+3
 CPR *+2
 UJP less-than-routine
 BSS 1
 greater-than-or-equal-to-next-instr.

Where (A) = (M), the instruction executes as follows:

(Q) > (M) RNI at P + 2 otherwise, RNI at P + 3

This is similar to the case where the contents of A is set to 37777777_8 . As in that case, P + 1 is unused. Therefore, M can be set equal to P + 1 with (M) set equal to (A) during execution.

e.g. STA *+2
CPR *+1
BSS 1
UJP greater-than-routine
less-than-or-equal-to-next-instr.

Note: In the case where (Q) is set equal to (M), the same thing could have been achieved by:

AQJ,GE *+2

Likewise, in the case where (A) is set equal to (M), the following instruction serves the same purpose:

AQJ,GE *+2

Since *+1 will almost certainly be a UJP, these can be replaced by a:

AQJ,LT address-in-UJP-instruction

Obviously, the forms of the instruction where (Q) = (M) or (A) = (M) are not useful.

About the only useful form of the instruction other then the one where it is known that $(A) \geqslant (Q)$, is where the (Q) is totally unknown and of no concern. When this is the case, the instruction is applied as follows:

(M) > (A) RNI at
$$P + 1$$
 otherwise, RNI at $P + 2$ or $P + 3$

When used in this manner, it is nothing more then an ASG where the test value is a 24 bit operand and (P+2) must be a NOP.

No matter how the CPR instruction is applied, the following is always true:

$$00000000 \neq 77777777$$
 and, $00000000 > 77777777$

Example:

Assuming the following initial conditions, what does this program do?

$$(A) = 100B$$

 $(Q) = 50B$

(100) = 00000064 (101) = 00000104 (102) = 70000000 (103) = 00000700

```
Answer: RNI sequence = BEGIN

BEGIN+3

BEGIN+4

BEGIN+6

BEGIN+7 (Halt)
```

Exercise:

Table IQ contains 100 IQ values. Count all the IQ's in the following ranges 0-79, 80-119, 120-up. Use the CPR instruction, then do it without the CPR instruction.

FLOATING POINT OPERATIONS

12.1 INTRODUCTION

- 12.1.1 Storage of Floating Point Numbers
- 12.1.2 Normalizing the Coefficient
- 12.1.3 Exponent
- 12.1.4 Conversion Procedures
- 12.1.5 Unpacking Floating Point Numbers

12.2 EXECUTION OF FLOATING POINT OPERATIONS

- 12.2.1 Addition
- 12.2.2 Subtraction
- 12.2.3 Rounding of Floating Point Numbers
- 12.2.4 Multiplication
- 12.2.5 Division

12.3 FLOATING POINT INSTRUCTIONS

- 12.3.1 Floating Point ADD
- 12.3.2 Floating Point SUBTRACT
- 12.3.3 Floating Point MULTIPLY
- 12.3.4 Floating Point DIVIDE

Chapter 2

12.1 INTRODUCTION

12.1.1 Storage of floating point numbers

Any number can be expressed in the form kBn

when k = coefficient

B = base


n = exponent

Floating point is always packed into 2 words in the 3200, making a 48-bit representation of the number.

The lower 36 bits = the coefficient

next 11 bits = exponent and sign of exponent

Upper bit = sign of the coefficient



12.1.2 Normalizing the coefficient

The coefficient is a 36-bit fraction, which is adjusted before packing, so that the fraction lies between $\frac{1}{2}$ and 1.

i.e.
$$1 > FRACTION \ge \frac{1}{2}$$

The coefficient is always adjusted so that a binary 1 follows the radix point, and nothing is in front of the radix point. The adjustment is made by shifting the radix point and multiplying the answer by the required power of 2.

e.g.
$$4_8 = 100.0$$
 in binary
= .100 x 2^3 in binary
= .4 x 2^3 in octal
 $101_8 = 1 000 001$. in binary
= .100 000 100 x 2^7 in binary
= .404 x 2^7 in octal
.06₈ = .000 110 in binary
= .110 x 2^{-3} in binary
= .6 x 2^{-3} in octal
.00001₈ = .000 000 000 000 001 in binary
= .100 x 2^{-16} in binary
= .4 x 2^{-16} in octal
-16 exponent = -16₈ = -14₁₀

12.1.3 The Exponent

lies in the range 0000 - 37778. However 17778 is not possible as it implies an exponent of -0 which will never result when performing a floating point operation. If one of the operands has 1777 for an exponent, it will be used as though it were 2000.

12.1.3 (cont.)

It is always biased before packing to enable comparison with other Floating point numbers.

This biasing ensures that the exponent is always positive.

If positive, 2000g is added to it. If negative, 1777_8 is added to it.

Thus if the biased value lies in the range 0000_8 - 1776_8 , it is a negative exponent. 1777_8 does not normally occur as it = -0.

But if the biased value lies in the range 2000_8 - 3777_8 , it is a positive exponent.

e.g. k x 24 Exponent is positive, therefore 2000 added. = 2004

 $k \times 2^{407} = 2407$

e.g. k x 2⁻⁴ Exponent is negative, therefore 1777₈ added $= 1777_8 + (-4)$ $= 1773_{8}$ $k \times 2^{-407} = 1370_{8}$ and

12.1.4 Conversion Procedures

- (1) Convert the number to binary
- (2) Normalize the number
- (3) Bias the exponentt
- (4) Assemble the number
- (5) If negative, complement the result

4.0 Example:

(1) Binary = 100.
(2) Normalize = .100 x
$$2^3$$
 = .48 x 2^3

= 2003= 2003 4000 0000 0000

(4) Assemble Leftmost octal number = 2 = 010 in binary

Sign bit = 0 = POSITIVE NUMBER

e.g. Pack 5638

- = 101 110 011 (1) Binary
- (2) Normalize = .101 110 011 x 2^{11} = .563 x 2^{11}
- (3) Exponent = 11 + 2000 = 2011

12.1.4 (cont.)

e.g. Pack -563₈

Steps (1) to (4) as above

Then, because it is negative, complement the result.

Note: Bit 47 (top bit) = 1, because 5 = 101 in binary.

e.g. Pack -1463₈

- (1) Binary = 001 100 110 011.
- (2) Normalize = .110 011 001 100 x 2^{12} octal.exponent = .6314 x 2^{12}
- (3) Exponent = 12 + 2000 = 2012
- (4) Assemble = 2012 6314 0000 0000

Complement because number is negative

e.g. Pack -. 358


- (1) Binary = .011101
- (2) Normalize = .111010 x 2^{-1} = .72 x 2^{-1}
- (3) Exponent = 1777 + (-1) = 1776
- (4) Assemble = 1776 7200 0000 0000

Number is negative, so complement the number

12.1.5 Unpacking Floating Point Numbers

Rules:

- (1) If upper bit is a one, number is negative. Complement, and note that sign of the final answer must be negative.
- (2) If exponent is less than 1777₈, exponent is negative. Subtract 1777 from exponent.
- (3) If exponent is greater than 2000₈, exponent is positive. Subtract 2000 from it.



- (1) Number is positive (the upper bit = 0)
- (2) Exponent is positive (> 2000)

$$= 2000 - 2000 = 0$$

(3) Number = $.4 \times 2^0$

e.g. <u>UNPACK</u> 6002 0777 7777 7777

- (1) Upper bit is 1 number is therefore negative, so first complement it
 - = 1775 7000 0000 0000
- (2) Exponent is < 1777, and is negative

= -2

Shift coefficient to right 2 places

(3) Coefficient = .7

- .111

Shift = .001 110

- .16

Answer = -0.16_8 or -0.21875_{10}

12.2 EXECUTION OF FLOATING POINT OPERATIONS

12.2.1 Addition

- (1) Equalize exponents by shifting coefficient of the algebraically smaller number to the right.
- (2) Add coefficients, and normalize

e.g.
$$10_8 + 100_8$$

 $10_8 = 2004 | 4000 | 00000000 | 100_8 = 2007 | 4000 | 000000000 | Shift coefficient of $10_8$$

$$.1_2 \times 2^4 = .0001_2 \times 2^7$$

$$= .04_8 \times 2^7$$

$$= 2007 0400 000000000$$

Add coefficients and normalize

$$= .4400\ 0000\ 0000\ x\ 2^{7}$$

this is normalized already

= 1001000.

= 001 001 0002

= 1 1 0₈

12.2.2 Subtraction

- (1) Equalize exponents
- (2) Subtract coefficients and normalize

e.g.
$$43_8 - 6_8$$

 $43_8 = .100011 \times 2^6 = 2006430000000000$
 $6_8 = .110 \times 2^3 = 2003600000000000$

Equalize exponents, ie, 2003 6000 0000 0000 (.110 $_2$ x $_2^3$)

becomes


2006 0600 0000 0000 (.000110 $_2 \times 2^6$)

Subtract coefficients and normalize

.4300 0000 0000
$$\times$$
 2⁶
(-).0600 0000 0000 \times 2⁶
.3500 0000 0000 \times 2⁶
.7200 0000 0000 \times 2⁵ after being normalized

12.2.3 Rounding of Floating Point Numbers

In floating point operations, the E register is joined to the AQ register, to form a 96-BIT REGISTER AQE (the uppermost bit is the sign).



To carry out rounding, the sign of AQ is compared with the sign of E. If sign of AQ is not equal to sign of E, number in AQ is rounded.

Example:

(i) If $AQ_{\Lambda7} = 0$, number is positive.

The number in AQ is therefore rounded up by adding one to AQ.

or 111 = 7

(ii) If $AQ_{A7} = 1$, number is negative.

If
$$E_{47} = 0$$
, number in E must begin with either a 0, 1, 2 or 3

which is -7, -6, -5, and -4.

The number in AQ is therefore rounded down by subtracting one from AQ.

Positive number is rounded.

No rounding is necessary.

Rounded down because negative number.

Summary: If the sign of AQ is different from the uppermost bit of E, one is added to AQ if AQ is positive or one is subtracted from AQ if AQ is negative.

12.2.4 Multiplication

- (i) Unbias the exponents by subtracting 2000₈ or 1777₈, as the case may be.
- (ii) Add the unbiased exponents.
- (iii) Multiply the coefficients.

12.2.4 (cont.)

- (iv) Normalize the coefficient resulting and adjust the exponent.
- (v) Assemble the number.
- e.g. Multiply 100_8 by 10_8

$$100_{8} = 001000000$$

$$= .100000 \times 2^{7} \text{ (Binary)}$$

$$= .4 \times 2^{7} \text{ (Octal)}$$

$$= 2007 | 4000 | 000000000$$

$$= .100 \times 2^{4} \text{ (Binary)}$$

$$= .4 \times 2^{4} \text{ (Octal)}$$

= 2004 4000 00000000

(i) Unbias exponents

2007 becomes 7

2004 becomes 4

(ii) Add unbiased exponents

(iii) Multiply coefficients

 100_8 becomes $.4_8$ when normalized

$$10_{8} \quad \text{becomes} \quad .4_{8} \quad \text{when normalized}$$

$$\text{product} = \overline{.20_{8}}$$

(iv) Normalize resulting coefficient

.20 x
$$2^{13}$$
= .010 x 2^{13} (Binary)
= .100 x 2^{12}
= .4 x 2^{12} (Octal)

(v) Assemble answer

(vi) Checking

$$100_8 \times 10_8 = 1000_8$$

$$= 001 000 000 000_2$$

$$= .100 \times 2^{12} \quad \text{(Binary - exponent in octal)}$$

$$= .4 \times 2^{12} \quad \text{(Octal - exponent in octal)}$$

12.2.5 Division

- (i) Unbias the exponents
- (ii) Subtract the unbiased exponents
- (iii) Divide the coefficients
- (iv) Normalize the coefficient resulting and adjust the exponent
- (v) Assemble the numbers
- e.g. Divide 100₈ by 10₈

$$100_{8} = 001 000 000$$

$$= .1 \times 2^{7} \quad (Binary)$$

$$= .4 \times 2^{7} \quad (Octal) = 2007 4000 00000000$$

$$10_{8} = 001 000$$

$$= .1 \times 2^{4} \quad (Binary)$$

$$= .4 \times 2^{4} \quad (Octal) = 2004 4000 00000000$$

(i) Unbias the exponents

2007 becomes 7

2004 becomes 4

(ii) Subtract unbiased exponents

(iii) Divide coefficients

 100_8 becomes $.4_8$ when normalized

10₈ becomes
$$.4_8$$
 when normalized quotient = 1.0_8

ie, .4
$$\frac{1.0}{3.4}$$

(iv) Normalize resulting coefficient

1.0 x
$$2^3$$

= .1 x 2^4 (Binary)
= .4 x 2^4 (Octa1)

(v) Assemble answer

(vi) Checking

$$100_8 \div 10_8 = 10_8$$

 $10_8 = 001\ 000 \quad (Binary)$
 $= .100 \times 2^4$
 $= .4 \times 2^4 \quad (Octal)$

12.3 FLOATING POINT INSTRUCTIONS

12.3.1 Floating Point ADD

LOCATION	OPERATION, MODIFIERS	ABDRESS	FIELD
	FAD,I	m,b	
1 12 15 14 14 15 17 14 7	\$115,155,158,041,151,141,171,141,16	 20 2: 22 83 20	[25;26;2];pa;24[30;5:;22;35];34;35;36;37;

23	18	17	16 1	5 14	00
60)	а	b		m

a = addressing mode designator


b = index designator

m = storage address


Description: Add the contents of two consecutive locations $(M \text{ and } M + 1) \text{ to the contents of AQ, where } M = m + (B^b)$ The normalized and rounded sum appears in AQ.

Example:

FAD FPSUM



Final result of AQ



Exercise: If contents of Registers and a part of memory are:

(A) = 20014500

(Q) = 00000000

6060	6060
2007	3621
00000	0000
2004	4000
0000	0000
	2007 00000 2004

Index register 3 contains 3, and

Index register 1 contains 1,

What would be AQ after execution of

(a) FAD

FPSUM, 3

(b) FAD

FPSUM,1

12.3.2 Floating Point SUBTRACT

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	FS8,I m,b
	0 :::

23	18	17	16 15	14	00
61		а	b	m	

a addressing mode designator

b = index designator


m = storage address

12.3.2 (cont.)


Description: Subtract the contents of two consecutive locations (M and M + 1) from the contents of AQ, where $M = m + (B^b)$



FSB FPØP



Final result of AQ:



12.3.3 Floating Point MULTIPLY

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
انتلنتا	FMU,I m,b
1 2 2 2 2 2 2 2	

	23 18	17	16 15	14	00
ı	62	а	b	m	

a = addressing mode designator

b = index register

m = storage address

Description: Multiply the contents of AQ by the contents of 2 consecutive locations, M and M + 1,

where
$$M = m + (B^b)$$
.

The product appears in AQ normalized and rounded.

Example:

FMU

and the instruction = EPØP FMU

12.3.4 Floating Point DIVIDE

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	FDV,I m,b
	0:::::::::::::::::::::::::::::::::::::

23	18	17	16	15	14	00
63		а	t)		m

a = addressing mode designator

b = index designator


m = storage address

Description:

Divide the contents of AQ by the contents of 2 consecutive location , M and M + 1, where $M = m + (B^b)$. The result appears in AQ, normalized and rounded.

Example:

If (AQ) are as shown below, FPØP contains 20044000, and FPØP+1 contains 0, what would be the contents of AQ after execution of the instruction.



48-BIT REGISTER OPERATIONS

- 13.1 48-BIT E REGISTER
 - 13.1.1 Introduction
 - 13.1.2 Trapped Instructions for the E Register
- 13.2 TRANSFERS BETWEEN A AND $\mathbf{E}_{\mathbf{U}}$
 - 13.2.1 Transfer $E_{\mbox{\scriptsize U}}$ to A
 - 13.2.2 Transfer A to $\mathbf{E}_{\mathbf{U}}$
- 13.3 TRANSFERS BETWEEN Q AND $E_{\rm L}$
 - 13.3.1 Transfer $\mathbf{E}_{\mathbf{L}}$ to \mathbf{Q}
 - 13.3.2 Transfer Q to $\mathbf{E_L}$
- 13.4 TRANSFERS BETWEEN AQ AND E
 - 13.4.1 Transfer E to AQ
 - 13.4.2 Transfer AQ to E
- 13.5 SCALE AQ
- 13.6 USE OF THE SCALE AQ INSTRUCTION



13.1.1 Introduction

The E register is a 48-bit, octal register* used as a supplement to AQ in floating point and 48-bit precision operations. It extends the size of AQ to 96 bits by forming AQE.

All 3200 computers do not contain the hardware for the E register, which therefore cannot be displayed on the console of these machines. (Where the full hardware is available, the contents of the E register can be displayed on the console in the displays usually containing A and Q.)

13.1.2 Trapped Instructions for the E Register

Floating point and 48-bit precision operations are handled on the 3204 basic processor by a special software package. The instructions are detected by the hardware, and "trapped". They are then processed by the special software programs OPTBOXS and FDPBOXS. OPTBOXS examines each trapped instruction to see if it is a Floating point/48-bit instruction or a BCD instruction (see Section 14.3). If it is a BCD instruction, the program BCDBOXS is used to process it. If it is a Floating point or a 48-bit precision instruction, the program FDPBOXS is used.

FDPBOXS simulates the hardware for the E register so that the instructions can be executed without the hardware being present.

^{*} The E register is the lower 48 bits of the 52 bit + sign E_D register. The upper 4 bits of E_D and the sign of E_D are not affected by Floating point, 48-bit multiply or divide, or inter-register operations.

13.2 TRANSFERS BETWEEN A AND EU

13.2.1 Transfer Eu to A


LOCATION	OPERA	HON, MODIFIERS	ABORESS	FIELD
	EUA		: ' ! ! ! ! ! !	
12[5]*17[5]		19114123161111919	13015:153168154 }	[25 \$6 \$3 \$6 \$5 \$6 31 \$8\$35 \$4 35 \$6 37]
	23	18 17	15 1	4 00

Description:

This instruction transfers the contents of $E_{\mbox{upper}}$ (bits 47-24) to the A register. The E register is not disturbed by the transfer.

Example:

Suppose \emptyset P48 contains 0, and \emptyset P48+1 contains 2. If A contains 0, and Q contains 76000000, what will be in A as a result of:



Transferring E_{II} to A, (A) = 00000001

13.2.2 Transfer A to $E_{\mbox{U}}$

LOCATION	OPERA	llion, Modifiers	ADDRESS FIELD	
	AEI	1	:	
- 2 5 * 5 4 7	* - - - -	11211412514141414		3: [22]23]34:30[36]27.
	23	18 17	15 14	00

Description:

This instruction transfers the contents of the A register to E (bits 47-24). E register bit positions 51 thru 48 upper and 23 thru 00 are not disturbed by the transfer. Also the A register remains unchanged as does the sign of E.

Example:

What will be in $\mathbf{E}_{\overline{\mathbf{U}}}$ after execution of the following instructions:

ENA 20321B AEU

Answer: $E_{U} = 00020321$

13.3 TRANSFERS BETWEEN Q AND E_L

13.3.1 Transfer E_L to Q

LOCATION	OPERATION, MODIFIERS A	DORESS FIELD
	ELQ	
1	1	

23 18	17	15 14	00
55	.1		

the end of the transfer.

Example:

In the EUA example, if the instructions had been:

MUAQ ØP48 EUA ELQ

What would be in Q after execution?

Answer: (Q) = 74000000

13.3.2 Transfer Q to E_{L}

LOCATION	OPERATION, MODIFIERS	ADDRESS FIEL	0
المال المناد	GEL		
.1213, (131611	* [

23	18 17		15 14	00
55	i	5		

Description: The contents of the Q register is transferred to E_{10} (bits 23-00). Bit positions 51 thru 24 and the sign of E are not disturbed by the transfer. Likewise the Q register remains unchanged.

Example:

In the following example:

ENQ 20321B QEL

What will be in $\mathbf{E}_{\mathbf{L}}$ after execution of the instructions?

Answer: $(E_{L}) = 00020321$

13.4 TRANSFERS BETWEEN AQ AND E

13.4.1 Transfer E to AQ

LOCATION	OPERATION, MODIFIERS	ABBRESS FIELD
	EAQ	
		10) 2:: 22 23 20 25 26 21 20 25 20 31 12 35 35 30 36

23 1	8 17		15 14	00
55		3		

Description: Transfer the 48 bit contents of E (bits 47-00) to AQ. E_U (bits 47-24) is transferred to A and E_I (bits 23-00) is transferred to Q. The contents and sign of E is not disturbed by the transfer.

Example:

In the EUA example, if the instructions had been:

What would be in AQ after execution?

Answer:
$$AQ = \begin{bmatrix} A & Q \\ 00000001 & 74000000 \end{bmatrix}$$

13.4.2 Transfer AQ to E

LOCATION	OPERAT	ION, MODIFIERS	ADDRESS FIELD	
	AQE	111111		
[2]3[4]5[6]7]	9 10 11 177		 10	30:3:(27)33:34:30:36:37:

Description: Transfer the 48 bit contents of AQ to E (bits 47-00). A is transferred to $E_{\rm U}({\rm bits}~47\text{-}24)$ and Q is transferred to $\rm E_L(bits~23-00)$. $\rm E_0(bits~51-48)$ and the sign of E are unaffected by the transfer. The contents of A and Q are not disturbed and remain after the transfer.

Example:

Divide the 48 bit operand in AQ by P48. Write the appropriate coding. $(\emptyset P48) = 2$.

Answer:	•	-4 7 ØP48	Set AQ to s	mber to E for Div. ign of E ient,(E) = remainder
A. C	A	Q		
At Start AQ =	7777777	77777765		
After AQE _r	A	Q	E _U	$\mathtt{E}_{\mathtt{L}}$
AQE =	77777777	77777765	7777777	77777765
After SHAQ r	A	Q		
AQ =	7777777	7777777		
After DVAQ r	A	Q	E _U	$\mathtt{E}_{\mathbf{L}}$
ACE =	7777777	7777772	00000000	00000000

LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD
	5CAQ	k, b
. 12 (5) * (5) \$ 17 (5)	10 107 112 114 114 119 119 1 F 1 7 114 119 1	

23 18	3 17	16 15	14	00
13	1	b	k	

b = index designator

k = shift designator

<u>Description</u>:

AQ is shifted left, end around, until the upper two bits (46 and 47 are unequal.)


During the operation, the computer makes a shift count. A quantity K = k minus the shift count.

If b = 0, this residue is discarded

If b = 1-3, the residue is placed in index register B^b .

Example:

AQ initial contents



SCAQ 24,2

Top bits of A = 000 011 000 etc.

To get top 2 bits unequal, shift left 3 places

= 011 000 etc.

AQ becomes

2000000	0 0 0 0 0 0 0
30000000	00000000

$$k = 24_{10}$$

K = k - shift count

$$= 30_8 - 3$$

= 25_8 , which is placed in Index Reg. 2.

Exercise:

If A contains 100B, and Q contains zero, what would be in A, Q and Index register 1 after execution of the following instruction?


SCAQ

2027B,1

13.6 USE OF THE SCALE AQ INSTRUCTION


It is used to pack floating point numbers.

Example:



In previous example (using 1008)


and Index Register 1 = 2007



(a) Then shifting AQ to right 11 places

•			
	=	00004000	00000000

- (b) by storing AQ elsewhere, Reading Index Register 1 into A, and shifting it left 12 places, we have the exponent at the top of the AQ.
 - $A = \begin{bmatrix} 0 & 0 & 0 & 0 & 2 & 0 & 0 & 7 \\ & & & & & & & & \\ & & & & & & & \\ & & & & & & & \\ & & & & & & & \\ & & & & & & & \\ & & & & & & & \\ & & & & & & & \\ & & & & & & & \\ & & & & & & \\ & & & & & & \\ & & & & & & \\ & & & & & & \\ & & & & & & \\ & & & & & & \\ & & & & & & \\ & & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & \\ & & \\ & & & \\ & \\ & & \\ & & \\ & \\ & & \\ & \\ & & \\ & & \\ & \\ & & \\ & & \\ & \\ & & \\ & & \\ & & \\ & & \\ & \\ & & \\ & \\ & & \\ & \\ & & \\ & \\ & & \\ & \\ & \\ & & \\$
- (c) By then adding back to AQ the stored value previously in AQ, (the normalized exponent) we have the packed floating point number



- (d) This will only work with positive numbers.
- (e) For negative numbers, complement the number first. Then pack the number, as above and complement the packed number.

Alternate method for packing floating point numbers:

If the computer has floating-point hardware and if the number to be packed is a single precision integer (24-bit operand), then the following method is used instead of the one just illustrated:

	SHAQ SCA FAD	-24 K2044 K2044	FØRM 48-BIT SIGNED ØPERAND MERGE WITH PRØPER EXPØNENT NØRMALIZE THE F.P. NUMBER
	•		
	•		
	•		
	•		
	UJP		
*			
K2044	ØCT	20440000,0	F.P. $CØNSTANT = 20440000000000000$

Here the FAD instruction is used to do the normalizing instead of the SCAQ. Also the normalizing is done after forming the floating point number rather then before. If the operand to be packed is larger than 24-bits or if the computer doesn't have floating point hardware, the number can be packed faster using the SCAQ instruction.

BCD DIGIT OPERATIONS

14.1 INTRODUCTION

- 14.1.1 BCD Digits
- 14.1.2 Field
- 14.1.3 Sign Bits
- 14.1.4 E_D Register (In Machine)
- 14.1.5 ED Register (On Console)
- 14.1.6 BCD Fault

14.2 BCD INSTRUCTIONS

- 14.2.1 Shift E_D Register
- 14.2.2 Ep Equal to ZERO Jump
- 14.2.3 ED Less Than ZERO Jump
- 14.2.4 E_D Overflow Jump
- 14.2.5 Setting Field Length in D Register
- 14.2.6 Load ED
- 14.2.7 Store E_D
- 14.2.8 Add to $E_{\mbox{\scriptsize D}}$
- 14.2.9 Subtract From ED

Chapter 4

14.3 BCD TRAPPED INSTRUCTIONS

14.1 INTRODUCTION

14.1.1 BCD Digits

The BCD instructions handle 4-bit BCD DIGITS. These digits are the decimal digits 0-9 represented as follows:

0000 = 0 0001 = 1 0010 = 2 0011 = 3

Each 24-bit word of storage is divided into 4 BCD Digit characters of 6 bits, as shown:

23	18 17	12 11	06 05	00

The lower 4 bits in each character are the BCD Digit. The upper 2 bits in the least significant character is used to represent the sign of the field.

14.1.2 Field

A field is a group of BCD Digits, of a maximum length of 12 digits. The length of the field is stored in the <u>D register</u>, which consists of a 4 bit register within the hardware. It is not displayed on the Console.

14.1.3 Sign Bits

This represents the sign of the <u>field as a whole</u> - not of the individual BCD digit. It is stored in the least significant digit in the field. The signs bits of the other digits in the field must be 00, or a fault is generated.

If the sign bit stored is 10, the field is negative.

For all other combinations, it is positive

Example:

L				00 1000	, , , ,
	00 0110	00 0010	00 1001	00 0000	= 6290

If the Field is 7 digits long, the sign is stored with the least significant digit (i.e. the rightmost of the field, = 9). It is 00. so the number in memory is positive = 1,438,629.


14.1.4 The En Register (in machine) - where hardware is available.

This is a $\underline{\text{decimal}}$ register, consisting of 12 BCD decimal digits and 1 overflow BCD decimal digit.

14.1.5 The En Register (on console) - where hardware is available.

Displayed in the AQ register as decimal numbers. Displays the full ${\bf E}_{\rm D}$ register plus 3 additional characters, as shown.

Sign of digit being currently accessed + or -



Max number in $E_D = 999,999,999,999$

If one more is added, the digit in the overflow position will become a one.

14.1.6 BCD Fault

Programmer can arrange for an interrupt to occur if a BCD fault is discovered. He can also arrange to keep sensing for a fault without an interrupt.

- 3 conditions will produce a fault.
- (a) If the upper 2 bits of any digit (except those of the least significant digit in the field) are not 00.
- (b) If an illegal digit is presenti.e. any four bit combination greater than 9.e.g. 1011 = 11 is illegal
- (c) If the contents of the D register are greater than 12 (148)

 BCD fault is sensed by the SENSE Internal Status Instruction:

INS 4000B

If BCD fault, RNI P + 1

If no fault, RNI P + 2

14.2 BCD INSTRUCTIONS

14.2.1 Shift E. Register

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	SFE k,b
1 2 3 4 5 6 7 4	11 5 :: 17 : 18 : 18 : 5 : 5 : 7 18 : 18 : 20 21 : 22 28 28 28 28 28 28 28

23	18	17	16 15	14	00
70)	0	b		k

k = shift count

b = index designator

Description:

The E $_{D}$ register is shifted in one character steps (i.e. 4 bits at a time)

 $K = k + (B^b)$ with sign extension

(The instruction senses bits 0-3 and 23 only of the sum of k and (B^D) .

If bit 23 = 0, Shift is left, end off, zero fill.

If bit 23 = 1, Shift is right, end off, zero fill.)

N.B. : BOTH SHIFTS ARE END OFF.

Example:

SFE

Shifts $\mathbf{E}_{\!D}$ 1 character to left (i.e. shifts one digit to the left.)

		1			·
0	000	0 (0 0 0	01 829	Before Shift

							t	
10	1000	1 0	ימס	0 1	2 1 2 (ח ב	After	G1 . G1
L		; •	• •	0 1	0 ! 2 :	, ,	Alter	Shift
							,	

Exercises:

(i) If the ED register contains

	r		
0	678	437 921	698
L	_		- 1

What will it contain after the following instructions

ENI 1,1

SFE 3,1

(ii) If the above result is followed by

SFE -8,1

What will be the final contents of $\mathbf{E}_{\mathbf{D}}$?

14.2.2 ED equal to ZERO Jump

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	EZJ,EQ m
1 12 1 5 1 • 1 5 1 6 1 7 1 •	

23 18	17 15	14 00
70	4	m

m = storage address

If $(E_D) = 0$, RNI address m

If $(E_D) \neq 0$, RNI P + 1

Example: EZJ, EQ

ENDLØØP

endløø p

SFE

1,2 *+5

UJP LDA

144B

etc.

14.2.3 E_{D} less than ZERO Jump

LOCATION .	OPERATION, MOD	IFIERS ADDRESS	S FIELD	
1 1 1 1 1 1 1	EZJ, LT		2-(25) 74) 27) 28 (25) 70) 71	12111111
	23 18			00

m = storage address

 $\underline{\underline{\text{Description:}}} \quad \underline{\underline{\text{The contents of the 52-bit E}_{D} \text{ register are compared}}} \quad \underline{\underline{\text{with zero}}}$

If $(E_D) < 0$ RNI address m

If $(E_D) \ge 0$ RNI P + 1

14.2.4 ED Overflow Jump

LOCATION	OPERA	TION, MODIFIERS	ADDRESS	FIELD			
11.11	EØJ) 100				
. 12 5 4 5 6 7		ga je je je jiho j	 - 20 2: 22 89 2:	122160161	[20]25]	10 31 32]35;34;35 <u>[34]37</u>]
	23	18 17	15 1	4			00

m = storage address

70

Description: If the upper 4 bits of the \mathbf{E}_{D} register contain anything but zero, control jumps to address \mathbf{m} .

If Upper 4 bits contain zero, RNI P + 1

14.2.4 (cont.)

Examples:

0	4 2 1	3 5 7	619	8 7 8	- no overflow, jump RNI P + 1
4	0 0 0	000	000	2 4 1	- O/flow, jump RNI Address m.

14.2.5 Setting Field Length in D Register

MOITAGE	OPERA	ION, MOD	IFIERS	ADDRE	SS FIELD			
	SE1	- 	اللنا	y		للنلن		
18:11:12:14:14:14:1	1			·				
and the same the same to the s	and or desired rate	3314 1211	10.13-20.097	(4018:143)6	11441251291211	\$1 [24] \$6 \$1 18 \$	21×4:32	36 3
emiliari ballarana den en e de manarana lassa sas ere e dar								
emotel Milliones de en en d'austragens lancaux avec en de	23			15 1			03	

y = field length indicator

Description:

The instruction takes the lower 4 bits of y and puts them in the D register. Maximum length of field is 14B for all operations except STE, when maximum length of the field is 15B. The D register remains at the value set until it is set again.

It is not cleared in Master Clear operations.

Example:

SET 14B

Sets D register to 148 for field length

14.2.6 Load En



23 18 17 16 00 64 b m

 $b = index \ designator$ If b = 0, m is the unmodified address
If b = 1, m is modified by (B^1) sign extended

m = storage address (character address)

Description:

The instruction loads the E_D register with a field of up to 12 numeric BCD characters. The field length is specified by the D register. Characters are put in the lower end of E_D , with zero fill to the left.

Example:

SET 7

LDE 400B

-				100	3	6	8	9
Find	least	significant	digit	101	4	5	6	8

14.2.6 (cont.)

$$= M + (D - 1)$$

$$= M + (6) = 406$$

Loads this character into \mathbf{E}_{D} first, into leftmost bits of En. The R shifts one character, adds in next digits, shifts, etc. When loaded D characters, zero fills rest of ED from left.

14.2.7 Store ${\rm E}_{\rm D}$

IGCATION	OPERATION, MEDIFIERS	ABORESS FIEL	0
	STE	m,2	
ومند فلف فيدرنانا	Charles Sale In Land the	. 151. 113. 114.1517 (1)	271281741891741877718477714 311

ONLY INDEX REGISTER 2 CAN BE USED

23 18	17	16 00
65	b	m

b = index designator

If b = 0, m is the unmodified address

If b = 1, m is modified by (B^2) only m = storage address (character address)

Description: The instructions stores a field of up to 13 decimal digits (3.C.D. numeric characters), beginning at address M (the address of the most significant digit in the field). The length of the field is determined by the D register.

The least significant digit is stored first, and the register is then Shifted right one digit. The next digit is stored, and the register shifted right again, and so on. NOTE THAT STORING DESTROYS THE CONTENTS OF En.

Example:

SET 14B

STE 400B

Field = 12 characters

= (D-1) + MAddress of least significant character = (13) + 400

= 100 001 011

= 001 000 010 11 Character address =

= Word 102

character 3

12 digits in E stored as follows:

100	7	4	6	8
101	7	1	2	6
102	4	7	8	9

NOTE:

DUMP OF MEMORY:

If an area of memory containing BCD numeric characters is dumped out, the 6 bits for each character (2 sign bits, and 4 bits for the digit) will be dumped in octal numbers:

e.g.
$$00\ 1000 = 8$$
 in BCD digit

But would be 001 000 = 10 in octal during dump.

Example: A block of memory is as follows (Characters are BCD Digits)

100	4	7	8	9
101	6	4	3	1
102	8	7	4	9
103	6	2	1	3

A program working on this is as follows:

What would be contained in En at the end of the operations?

14.2.8 Add to E_{D}

LOCATION	OPERATION,	MODIFIERS	ADDRESS FIELD	=a.	
	ADE		10 . 3	_L 	MODIFIED BY INDEX REGISTER 3 ONLY
	23 18	17 1	<u>6</u>	0	
	66	ь		7	

b = index designator If b = 0, m is the unmodified address, i.e. M = m If b = 1, m is modified by (B^3) only, M = m + (B^3) m = storage address (character address)

Description:

This instruction adds 'D' numeric BCD digits to the E_D register. The 'D' digits are lined up with the lower 'D' digits of the E_D register before they are added. The E_D register has a maximum capacity of 13 digits, i.e., 12 digits plus overflow digit. The maximum number of digits in the number to be added is 12, i.e., D may not be greater than 12. M is the most significant digit of the number to be added. M + D = 1 is the least significant digit.

14.2.8 (cont.)

Example:

If $(E_D) =$

0	0 0 0	000 87	6	5 4 3

And a block of memory is

100	7	2	4	9
101	1	5	8	2
102	6	1	3	6
103	2	0	8	4

What will be the contents of \mathbf{E}_D after the following instructions are executed?

ENI 1,3
SET 10B
ADE 400B,3

Answer:

(a)
$$M = m + (B^3)$$

Add to \mathbf{E}_{D} 8 character — the least significant of which will be

$$M + (D-1)$$

$$= 401 + 7$$

$$E_D = 0 000 000 876 543$$

14.2.9 Subtract from E_D

EDCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	SBE	" ,3	
1: : : : : : : : : : : : : : : : : : :	\$ (-1.112.11 4.114.) \(\frac{1}{2} \) \(\frac{1} \) \(\frac{1}{2} \) \(\f	 - - -	[22]46 [4:]54 [54:40] 2:[32] 17:[32] 17:[34] 36 [47]

23 18	17	16	00
67	ь	m	

b = index designator

If b = 0, m is the unmodified address, i.e., M = mIf b = 1, m is modified by (B³) only, $M = m + (B^3)$

m = storage address (character address)

 $\frac{\text{Description:}}{\text{As for ADE, except that the field of up to 12 BCD digits}} \\ \text{is subtracted from the E}_{\text{D}} \\ \text{register.}$

14.3 BCD TRAPPED INSTRUCTIONS

All BCD instructions may be used in any 3200 Computer, regardless of the model of the processor. Where the processor lacks the BCD hardware package necessary for direct processing of BCD instructions, the implementation of these instructions is carried out by a special software package. The instructions are then known as "trapped" instructions.

(It should be noted that where the software package is used, the contents of the Ed register cannot be displayed on the console, because the Ed register hardware does not exist.)

The B.C.D. instructions are detected by a translator as they appear in the Function register, and trapped. They are processed like interrupts, and the following action takes place

- (a) P + 1 is stored in the lower 15 bits of address 00010
- (b) The upper 6 bits of the Function register are stored in the <u>lower</u> 6 bits of 00011 the upper 18 bits of 00011 remain unchanged.
- (c) Program control is transferred to 00011, and a RNI cycle is executed.

COMPASS PSEUDO INSTRUCTIONS

- 15.1 CONCEPTS OF PSEUDO INSTRUCTIONS
- 15.2 PROGRAM DEFINITION
 - 15.2.1 IDENT Instruction
 - 15.2.2 END Instruction
 - 15.2.3 FINIS Instruction
- 15.3 ASSEMBLY AREAS
 - 15.3.1 Introduction
 - 15.3.2 DATA Area
 - 15.3.3 Return Assembly Control to Subprogram PRG Area
 - 15.3.4 COMMON Area
 - 15.3.5 ORGR Instruction
- 15.4 STORAGE RESERVATIONS
 - 15.4.1 Word Block
 - 15.4.2 Character Block
- 15.5 ENTRY AND EXTERNAL INSTRUCTIONS
 - 15.5.1 ENTRY Pseudo Instruction
 - 15.5.2 EXTERNAL Pseudo Instruction
 - 15.5.3 SCOPE Loading of Subprogram
- 15.6 SYMBOL DEFINITION BY EQUIVALENCING
 - 15.6.1 Introduction
 - 15.6.2 Word Equating
 - 15.6.3 Character Equating
- 15.7 COMPASS OUTPUT LISTING CONTROL
 - 15.7.1 REMarks
 - 15.7.2 NO LIST Instruction
 - 15.7.3 Resume LISTing Instruction
 - 15.7.4 SPACE Instruction
 - 15.7.5 New Page EJECT Instruction
 - 15.7.6 TITLE Instruction
 - 15.7.7 Comments



15.1 CONCEPTS OF PSEUDO INSTRUCTIONS

A better name would be "Assembly-Control" instructions. They are simply instructions from the programmer to the assembler.

They will be used during assembly only. Program execution can make no use of them.

e.g. BSS 4 is an instruction to the assembler to set aside 4 words of storage somewhere in the storage area. The 4 words are set up during assembly and then the function and usefulness of the BSS instruction is finished.

15.2 PROGRAM DEFINITION

15.2.1 IDENT Instruction

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
1 1 1 1 1 1 1	IDENT M
	# 1111 A. W. W. G. PIECK, Mr. 1117 BE 24-75 BG P. M. P. BIN 4-815 (4-55) M. IV.

<u>Description</u>: The Location field is blank. However if a symbol is written in it, COMPASS will ignore it. COMPASS picks up 8 or less alphanumeric characters from the address field, the first of which must be alphabetic. The Address field terminates at the first blank or the eighth alpha-numeric character, whichever is the first encountered. A period may appear in m.

m = PROGRAM NAME

This will appear on the top of each page of the assembly listing. The IDENT card must be the first card in the program or the job will be terminated.

Examples: (a) IDENT

TEST FØR ILLEGAL SYMBØLS

END

Program name will be TEST

(b) IDENT

CONTINUOUS TESTING OF TAPES

END

Program name will be CONTINUO

15.2.2 END Instruction

LOCATION	OPERATION, MODIFIERS ADDRE	SS FIELD
	END M	
· [2]\$[*]\$[\$[*]	\$\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	2 m 22 22 22 22 23 24 25 25 25 25 26 26 27

Description: The location field should be blank. If a symbol is present, it is ignored by COMPASS. The END instruction terminates the sub program. The final instruction in a COMPASS Sub-program must be an END instruction.

Symbolic Transfer Address

The "m" signifies a symbol in the address field of some subroutine which has declared it to be an entry point. This address is called the Symbolic Transfer Address and need not be in the subroutine terminated by this END card.

Examples: (i) A program of one subprogram.

The symbolic transfer address must appear, and the symbol must be defined within the subprogram as an entry point.

e.g.		IDENT	TEST
_		ENTRY	FIRST
	FIRST	UJP	**
		•	
		• END	FIRST
		CIND	LIKOI

(ii) A program of more than one Compass subprogram

The symbolic transfer address must appear in $\underline{\text{one}}$ of the END statements, and be defined as an entry point as before.

Note that this program could have appeared as follows:

(iii) A program of COMPASS and FORTRAN subprograms.

A symbolic transfer address should <u>not</u> appear in any END statement in the program, if the FORTRAN program is the main program.

15.2.2 (cont.2)

PRØGRAM TEST Example: CALL ØNE CALL TWØ END IDENT

ØNE END

TWØ IDENT END

If the FORTRAN is a subroutine of a COMPASS subprogram a transfer address should appear in the END statement in the COMPASS subprogram.

TRA Card diagnostic

Where an error occurs in using symbolic transfer addresses, the error is flagged by the Loader when the program is loaded, and execution is not attempted.

The flag "TR" is shown (after the Load card is listed) on the standard output unit.

15.2.3 FINIS Instruction

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	FINIS
1 [4] \$ [* [*] \$] \$] *	

Description: Symbols in the location and address fields are ignored. The instruction tells the assembler that it has reached the end of the assembly, and that all sub-programs have been assembled. If the FINIS card is put in out of order, the assembly will be terminated when it is reached. Control is returned to SCOPE when the FINIS card is read.

Example:

IDENT TYPØUT END SØUT IDENT END IDENT TYPIN

END FINIS

15.2.3 (cont.)

Where FORTRAN and COMPASS subprograms are used in the one subprogram, the FINIS card is used to indicate the end of each group of subprograms.

Example:

END FINIS

15.3 ASSEMBLY AREAS

15.3.1 Introduction

There are 3 areas in any sub program assembly

(a) Subprogram Area.

In this area all normal parts of the subprogram are assembled.

(b) COMMON Area

Parts of the program declared to be in common are assembled in this area.

(c) DATA Area.

Parts declared to contain Data are assembled in this .. rea.

Three counters are used at assembly time to put parts of program in sequential places in the areas above. These counters are incremented to give the current address of the instruction being assembled in the particular area in which the assembly is taking place.

15.3.2 DATA Area

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	DATA		
12:31:413:43:41	· · · · · · · · · · · · · · · · · · ·	_e0,7151.2183124	11 27 (414) 25 (411) 21 (41)

Description: Information may be put into the Data area at assembly time.


> There may be no reference to an external symbol, nor can any symbol in the DATA area be an entry point for the subprogram in which it occurs. The instruction specifies that all information following is to be stored or identified as part of the DATA area, until PRG or COMMON or END occurs. Any instruction or pseudo instruction may follow DATA. The DATA area is shared by all subprograms at execution time.

> The Location and Address fields should be blank.

Example:		IDENT	BINBCD
		•	
		•	
		DATA	
		BSS	2
	DATA	ØCT	273

NOTE: The total DATA area must be defined in the first subprogram loaded.

15.3.2 (cont.)



15.3.3 Return Assembly Control to Subprogram PRG Area

LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD
	PRG	
. 12.11.4.2.14.17.14		

<u>Description</u>: All instructions that follow are to be assembled in the subprogram area.

The PRG instruction may be used to signal the end of the DATA or the COMMON areas.

Example:		IDENT	BLØCKER
		DATA	
	SCALEF	Øct	273
		Ø CT	-0
		cømmøn	
	INBUFF	BSS	100
		PRG	
		•	
		•	
		•	
		end	

LOCATION		OPERATION	, MODIFIERS	ADDRESS	FIELB
		СФИНЦ	dn ,		
. 1211.012	6 Y 8 V	16 per 1 d p 3 p 1	131/41/1181/8	(20 21 YI 2 3 24	[25] 24 [5] [26 [26 [30] 31 [32] 35 [39] 30; 36 [37]

Description:

The instruction labels and reserves space in the common area.

No information can be put into the area at assembly time. If this is attempted, an error listing is given. COMPASS assumes that a PRG card had been included before the instruction and resumes assembly in the subprogram area.

The COMMON area is shared by all subprograms at execution time.

Note: COMMON is the same for all subprograms. If it is desired to have separate areas, ORGR instructions must be used to separate them.

Example:

IDENT TEST

COMMON

WORKAREA BSS 100

END

IDENT SUBEDIT


COMMON

LØC BSS 60

END

In this program, the common area will be overlapped by the two subprograms.

COMMON



This can be used to reference the same words in common in two subprograms.

15.3.4 (cont.1)

Example:

Setti	ng up common	area in 2 subprograms
	IDENT	MAX
	СФММФИ	
TEMP	BSS	10
CTABLE	BSS, C	6
	PRG	
	•	
	•	
	END	
	IDENT	SUBPRØG
	•	
	•	
	•	
	cømmøn	
QTØTAL	BSS.	12
FLAGS	BSS, C	4
	PRG	
	•	
	•	

The area will be set up as follows:

END

TEMP					QT Ø TAL
TEMP+1					QTØTAL+1
TEMP+2					QTØTAL+2
TEMP+3					QTØTAL+3
TEMP+4					QTØTAL+4
TEMP+5					QTØTAL+5
TEMP+6					QTØTAL+6
TEMP+7					QTØTAL+7
TEMP+8					QTØTAL+8
TEMP+9					QTØTAL+9
	CTABLE	CTABLE+1	CTABLE+2	CTABLE+3	QTØTAL+10
	CT ABLE#	CTABLE+5	not use	d by MAX	QTØTAL+11
	FLAGS	FLAGS+1	FLAGS+2	FLAGS+3	FLAGS

15.3.4 (cont.2)

Note: The only instructions which can be used in the COMMON area are as follows,

BSS	ØRGI
BSS, C	IFT
equ	IFN
EXT	IFF
ENTRY	IFZ

COMMON is terminated by PRG

or END

15.3.5 ORGR Instruction

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ØRGR M
	# # +++

Description: This instruction controls the relocatable address for storage of instructions, constants, or the reservation of space in any of the three storage areas. The location field is ignored by COMPASS, but printed on the listing.

Any symbol used in the address field must have been previously defined in the storage area being referenced. If COMPASS is assembling into one area, and an ORGR occurs with a different area relocatable symbol in the address field, an error results. COMPASS ignores the ORGR, but puts an error flag on the listing.

Example:

	IDENT	ØRGRT
	DATA	
	BSS	2
DTAG	ØCT	227
	•	
	•	
	•	
	PRG	
	•	
	•	
	•	
A	ørgr	DTAG+1
	•	
	•	
	•	
	END	

Note: the error flag "A" set to show the error in the address field. DTAG is in the DATA area, and cannot be used in an ORGR statement in the SUBPROGRAM area.

15.3.5 (cont.)

ii)	IDENT	HARRY
	ØRGR	100В
	LDA	CIT
	•	
	•	
	•	
	END	

The first instruction (LDA cIT) will be assembled in Location 100, and the rest will be stored following it.

iii)	IDENT	Ørgrtest	
	ENTRY	START	STØRAGE ADDRESS
	ØRGR	50	
START	UJP	**	00062
	LDA	CIØ	
	STA	CIØBLØCK	
	•		
	•		
	UJP	02010B	
CØNTABLE	ØCT	0,-1	00076 and 77
	ØRGR	*+50	
INPFLAG	ØCT	0	00162
	ØRGR	INPFLAG+20	
Øne	ØCT	1	00206
	END	START	

15.4 STORAGE RESERVATIONS

This is made in the area currently being used. The address field will determine the number of words or character positions to be reserved.

15.4.1 Word Block

LOCATION	OPERATION, MODIFIERS	ADDRESS	FIELD
	B SS	m	
		 	(25 26 23 28 24 36 3(32 33) 34 35 36 35

m = a constant, a symbol, or an address expression.

- Description: (i) The instruction reserves and labels a block of word storage. A symbol in the location field is the 15-bit, relocatable word address of the first word in the block of storage.
 - (ii) The address field specifies the number of locations to be reserved. It may be
 - (a) a constant

Example: STATUS BSS 2
DISKBUFF BSS 745

(b) a symbol

Example: VARINP EQU 5
INPAREA BSS VARINP

Note that the symbol must not be a relocatable address, or an error results:

VARINP ØCT 5
INPAREA BSS VARINP

(The "A" indicates the address field error.)

(c) An address expression which results in a non relocatable value.

Example: VARINP EQU 5
INPAREA BSS VARINP+7

If the symbol is a relocatable address, an error results.

VARINP ØCT 5
INPAREA BSS VARINP-2

(The "A" indicates the address field error).

(iii) The double asterisk is illegal

i.e. PRINTBUF BSS **

Description: (Continued)

(iv) If an address field is zero or in error, the symbol is defined, but no storage is reserved.

 Example:
 TAG1
 BSS
 1

 TAG2
 BSS
 **

 TAG3
 BSS
 1

 TAG4
 BSS
 2

The second instruction is illegal, and no location will be reserved for TAG2, but TAG2 is defined. It will reference the same word as TAG3.

i.e. m.c.	
TAG1	
TAG2 and TAG3	
TAG4	
TAG4+1	

(v) All symbols used in the subprogram must have storage allocated to them:

IDENT MATRIX
LDA CØUNT
INA
STA CØUNT

CØUNT

CØUNT
BSS 1

CØUNT

CØUNT
BSS 1

(vi) NOTE: Where no symbol is used, storage is reserved but not labelled. It may be referenced from other labelled locations.

Example: TAG1 ØCT 4

BSS 3

TAG2 ØCT 27

BSS 3

TAG3 ØCT 14

15.4.1 (cont.2)

Description: (Continued)

The block of storage set up will be:

00	00	00	04
00	00	00	27
00	00	00	14
	00	00 00	00 00 00 00 00 00 00 00 00

The location marked *** may be referenced as:

TAG1+2

or TAG2-2

or TAG3-6

15.4.2 Character Block

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	
	855,C, , , , , , , , , , , , , , , , , ,	٠.
	10 111 112 114 115 118 115 118 115 118 119 150 1921 550 158 158 158 158 158 158 158 158 158 158	1

Description: Reserves and labels a block of character storage
 in the area currently in use.

- (i) A symbol in the location field is the 17 bit, relocatable character address of the first character in the block.
- (ii) The address field specifies the number of characters to be reserved. It may contain
 - (a) a constant

Example: CTAG1 BSS, C 6
CTAG2 BSS, C 2

Storage will be reserved as follows:

CTAG1	CTAG1+1	CTAG1+2	CTAG1+3
CTAG1+	CTAG1+5	CTAG2	CTAG2+1

(ii) Continued

(b) a symbol

A

Example: SIZE EQU 5
PARLIST BSS,C SIZE

Note that the symbol must not be a relocatable address or an error results.

SIZE OCT 5
PARLIST BSS,C SIZE

(The "A" indicates the address field error).

(c) an address expression which results in a non-relocatable value.

Example: SIZE EQU 15
PARLIST BSS,C SIZE-3

(iii) If a BSS,C instruction is followed by a BSS 0 instruction, it forces any following character reservation to a new word, even if the last character word is not filled.

Example: INPWLAGS BSS,C 6
BSS 0

OUTFLAGS BSS,C 2

Storage is reserved as follows:

INPFLAGS	INPFLAGS+1	INPFLAGS+2	INPFLAGS+3
INPFLAGS+4	INPFLAGS+5	Not Used	
ØUTFLAGS	ØUTFLAGS+1	Not Used	

15.5 ENTRY AND EXTERNAL INSTRUCTIONS

15.5.1 ENTRY Pseudo Instruction

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	ENTRY m, m, m,m,
112151415141714	# 17 12 12 17 18 17 18 17 18 17 17

Description

The location field should be blank, but if a symbol does appear, it will be ignored by COMPASS. The address field contains one of more location names separated by commas. No blanks may occur. The field terminates at the first blank, or at Column 73. If there are more entry points to be defined than will fit on one card, a second card can be used.

Each of the address field location names contains a symbol defined as a subprogram relocatable word address by appearance in a location field elsewhere in the subprogram.

Example:

	IDENT	øne
	ENTRY	start, intø
START	UJP	**
	ENA	0
	•	
	•	
intø	· UJP	**
	•	
	•	
	• END	START

Note that more than one entry card can be used.

	IDENT	Twø
	ENTRY	START
	ENTRY	intø
START	WР	**
	•	
	•	
	•	
intø	UJP	**
	•	
	•	
	•	
	END	START

15.5.2 EXTERNAL Pseudo Instruction

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	
	EXT m, m, m, m,	
+ 2 5 4 5 4 7 A		4:30:3:(3t)35:X4:35:36;37:

Description:

The location field should be blank. Any symbol appearing there will be ignored by COMPASS. The address field contains one or more location names up to Column 73. These must be separated by commas. No blanks may occur. A symbol in the address field may not be defined in the subprogram in which the EXT instruction appears. The EXT instruction can only reference location names in the subprogram area of another subprogram. It cannot reference DATA or COMMON areas.

Example:

	IDENT	MAIN
	ENTRY	NUMBER
	•	
	•	
NUMBER	øст	37
	•	
	•	
	• man	
	END	
	IDENT	SUBPRØG
	EXT	NUMBER
	•	
	•	
	•	
	LDA	NUMBER
	•	
	•	
	•	
	END	

All subprograms within a main program are assembled independently, and all symbols in a subprogram are local to that program only, unless declared as external symbols in another subprogram, and as entry points in the former program.

Example:		I DENT	DRIVER01
		•	
		LDA	TAG
		•	
		•	
	TAG	ØСТ	14
		END	
		IDENT	DRIVER02
		•	
		•	
		•	
		LDA	TAG
		•	
		•	
	TAG	øст	27B
	1210	<i>p</i> 01	2 3

The two Symbols (TAG) are not linked in any way. Each will be referenced only by the subprogram in which it appears.

BUT: If they refer to the same symbol, the Program could appear as follows:

	IDENT	EDIT
	EXT	CARDBUFF
	•	
	•	
	L DA	CARDBUFF
	•	
	•	
	•	
	END	
	IDENT	READ
	ENTRY	CARDBUFF
	•	
	•	
	LDA	CARDBUFF
	11DA	GARDBOI I
	•	
CARRITTE	·	
CARDBUFF	ØCT	24
	•	
	•	
	END	

Address arithmetic is not permissible with external symbols

e.g. LDA CARDBUFF+2

But, address modification is permissible

e.g. LDA CARDBUFF,3

15.5.3 SCOPE Loading of Subprograms

The Assembler establishes links between the subprogram as directed by the EXT and ENTRY instructions. These linkages are then set up by the Loader (a part of the SCOPE monitor) when the assembled program is loaded prior to execution.

If an external is referenced in a subprogram, but there is no ENTRY for it in any other subprogram, SCOPE will look through the Library Tape to see if it can find a Library Routine to enter.

IDENT	QUAD
EXT	SQRTF
•	
•	
•	
ŔŢĴ	SQRTF
•	
•	
• END	
IDENT	DISC
•	
•	
• 13NT)	
END	

If it can find no Library routine of the same name, it will give an error symbol, and terminate the run. (This is done at Load Time, not in Assembly). The error symbol appears on the listing after the LOAD card print out e.g. LOAD, 56

DISC UD SQRTF

The COMPASS assembly listing of a subprogram containing external symbol references will have the usual format, except that the address field will be prefaced by an X.

Example:

00010 00 1 X00003

The digits following the X are the reloctable word address of a previous instruction in the subprogram area which references the external symbol. The first (or only) reference to the external symbol will contain X77777 in the address field. COMPASS thus produces a "threaded list" of instructions referencing the external symbol.

Example:		Program	Listi	.ng	
	IDENT	TEST			
	EXT	cıø			
	•				
	ENA	10B	00000	14 6	00010
	•				
	RTJ	ciø	00010	00 7	X77777
	•				
	RTJ	cıø	00030	00 7	X00010
	RTJ • END	cıø	00050	00 7	X00030

The address of the last instruction referencing the external is placed by COMPASS into the XNL Loader Card to begin the backward threaded list. When the loader loads the program, it enters the actual address of the external symbol into the address portion of each instruction referencing the external. It does this by saving the address portion of the last instruction referencing the external symbol, it then replaces the address with the actual address of the external symbol. The loader then, repeats the process using the saved address as the new last instruction address referencing the external symbol. The process continues until the address of the next instruction in the list is 77777, which indicates all instructions referencing this external symbol have been modified.

Thus, if $CI\emptyset$ is loaded at address 00106, the program will be loaded into storage as:

00000	14600010	(ENA	10B)
	•		
	•		
00010		/	
00010	00700106	(RTJ	CIØ)
	•		
	•		
00030	00700106	(RTJ	CIØ)
	•	(1120	0147
	•		
	•		
00050	00700106	(RTJ	CIØ)

15.6 SYMBOL DEFINITION BY EQUIVALENCING

15.6.1 Introduction

A symbol may be defined by equivalencing it to another symbol, a constant, or an expression. The symbol may be defined as an absolute value, a relocatable word or relocatable character address. The symbol in the location field is equivalenced to the value of the address field. A symbol which is declared an entry point must not be equated to a symbol which is declared external. When symbols are equivalenced they are identical and interchangeable.

All symbols in the address field of an equivalence must have been previously defined by the appearance in the location field of a preceeding instruction, or in an EXT pseudo instruction.

15.6.2 Word Equating

LOCATION		OPERATION, MODIFIERS ADDRESS FIELD
		EQU
11314,4,515(7)4	Ų,	-0.11-1-11-11-1-1-1-1-1-1-1-1-1-1-1-1-1-

Description: The symbol is equivalenced to another symbol, a 15-bit word address, or a 15-bit value. The symbol in the location field will be non-relocatable or relocatable, as determined by the address field.

> If the location field is blank, an error occurs. The address field may contain

- (i) An integer, modulo 2¹⁵-1(15 bits or less)
- (ii) A symbol, previously defined(iii) An address expression containing symbols previously defined.

If a symbol in the address is defined as relocatable in a given area, the symbol in the location field will also be relocatable in that area.

Examples:

SYMBØL	EQU	57641B
DATE	e qu	27B
TEMP	BSS	1
SYM	E ⊋U	TEMP
TEMP2	EQU	SYM+6

Assembled as follows:	symbøl	57641
	DATE	00027
00165	TEMP	Storage reserved
	SYM	00165
	TEMP2	00173

TEMP, SYM and TEMP2 are relocatable.

15.6.3 Character Equating

LOCATION	OPERATION, MODI	FIERS ADDRESS	FIELD
	EGU, C	, 111	
		::::::::::::::::::::::::::::::::::::::	[25]20[27]28[24]26:5:[32]35]14[35]56;37:

Description:

The symbol is equivalenced to a 17-bit address, a 17-bit value or another symbol. The symbol will be nonrelocatable, or relocatable, as determined by the address field. If the location field is blank, an error occurs.

The address field may contain

(i) An integer, Modulo 2¹⁷-1(17 bits or less)

Example: ABADD EQU, C 372B

ABADD is equivalenced to the 17-bit character address 372, which is word 76, character 2. This word address is shown on the listing:

000762 ABADD EQU,C 372B 00027 DATE EQU 27B

(ii) A symbol previously defined

Example: SYM BSS, C 1

NDFLAG EQU, C SYM

If the address of SYM is 00013, the value of NDFLAG will be 13 also.

(iii) An address expression, containing symbols already defined.

Example: NDFLAG EQU,C SYM-4

If the address of SYM is OOD13, the value of NDFLAG will be 50.

Word address 13 = character address 54 $-\frac{4}{50}$ NDFLAG = character address 50

15.7 COMPASS OUTPUT LISTING CONTROL

The programmer can control output listings under CØMPASS with these instructions. They are written in the same way as any other instruction.

15.7.1 REMarks

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	REM

Description:
Any remark may be inserted into the source program, to appear on the output listing. All columns except 9-13 may be used.



15.7.2 NO LIST Instruction

LOCATION	OPERATION, MODIFIERS ADDRESS FIEED
1.1 1 1 1 1 1	NØLIST

<u>Description:</u> The instruction suppresses listing of the subprogram until the instruction LIST is encountered.

However, if lines containing errors are encountered, they will be printed out, regardless of the NØLIST instruction.

The instruction will not appear on the output listing.

15.7.3 Resume LISTing Instruction

LOCATION	1	OPERATION, MODIFIERS AUDRESS FIELD
		LIST
/ (2 * 1 · * · * 1 \$: f : #		2 - 1 111 111 11 11 11 11 11 11 11 11 11

Description: The instruction resumes output listing after a

NOLIST instruction

If LIST occurs without a proceeding NØLIST statement

it is ignored.

15.7.4 SPACE Instruction

· · · · · · · · · · · · · · · · · · ·		
LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	
	SPACE M	
121101011	TO A STATE OF THE PROPERTY OF	

Description:

The instruction instructs the printer to skip m
lines of print, or go to the top of the next page,
whichever is the less.
m is an unsigned decimal integer.

Examples:

(i) SPACE 2

2 lines are skipped on the printer

(ii) If only 3 lines remain in the page,

SPACE 10

will cause the printer to skip to a new page and begin in line 1 of the page.

15.7.5 New Page EJECT Instruction

LOCATION	Ī	OPERATION, MODIFIERS ADDRESS FIELD
		EJECT
:	v	

Description: The page being printed is fed through the printer, and the line following the EJECT instruction will be the first line of listing on the new page. The address field must be blank or an error will occur, although comments may be inserted from column 41.

15.7.6 TITLE Instruction

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	TITLE title to be used
112:314:314:2	10

Description: Normally the name of the subprogram will appear at the top of each page of listing of the subprogram. If another title is required instead, it can be inserted using this instruction. The heading obtained from the IDENT or previous TITLE instruction is replaced, and the first page following the TITLE instruction will have the new heading. If the new heading is to be inserted immediately, the instruction EJECT should immediately follow TITLE. If the new title is to be used on the first page of the listing, the TITLE instruction must immediately follow IDENT.

The title must be contained in columns 20-72 of the address field.

Examples:

(i) IDENT TEST

> TITLE TEST FOR ILLEGAL CHARACTERS

This will cause the full title to be printed on the first and subsequent pages of the listing of the subprogram.

(ii) IDENT TEST

> TITLE TEST FØR ILLEGAL CHARACTERS

TITLE PRINT OUT CHARACTERS FOUND

EJECT

END

The first title will be printed on all pages until the second TITLE instruction is found. A new page will be begun by the EJECT instruction, and it will bear the new title.

15.7.7 Comments

When COMPASS detects a card with an asterisk in column 1, it prints the content of the card as a comment. No other action is performed. Note: The asterisk itse f is not printed. (See also Section 2.2.3.1)

SCOPE ORGANIZATION OF INPUT/OUTPUT

16.1 INTRODUCTION

- 16.1.1 Programmer Units
- 16.1.2 Scratch Units
- 16.1.3 Systems Units

16.2 CENTRAL INPUT/OUTPUT ROUTINE

- 16.2.1 Introduction
- 16.2.2 Calling Sequences
- 16.2.3 Input/Output Operations
- 16.2.4 Tape Control Operations
- 16.2.5 Unit Status Requests
- 16.2.6 Format Selection
- 16.2.7 Page Control of the Line Printer

16.1 INTRODUCTION

Under SCOPE, Input/Output devices are specified by Logical Unit Numbers (LUN's) which are organized according to function. The programmer or operator assigns the logical unit to a particular type or unit of hardware, through SCOPE control.

Logical Units may be specified as

- (i) Programmer units,
- (ii) Scratch units,
- or (iii) System units.

16.1.1 Programmer Units

They are for general purpose use by the programmer, and they are unrestricted as to use in any run in a job.

Once defined, the definition of the programmer unit is fixed for the whole job. They are released by SCOPE at the end of the job, unless <u>saved</u> by the programmer by the use of a SCOPE unload card.

Programmer units are numbered 1-49.

16.1.2 Scratch Units

Scratch units must be defined for each run, and are released at the end of the run. They are assigned and used by Library programs, and may be accessed by the programmer for temporary use.

Scratch units are numbered 50-55.

They cannot be saved by the programmer.

16.1.3 Systems Units

Systems units are assigned to specific physical equipment within SCOPE, but these assignments may be altered by the operator. They are used for certain common functions, and may be protected by SCOPE from input-output requests which might destroy their contents.

Systems units are numbered 56-63, as follows:

- 56 Load and Go (for storage of object decks from assembly, prior to Loading and Execution)
- 57 Accounting
- 58 Comments from operator (only read requests allowed)
- 59 Comments to operator (only write requests allowed)
- 60 Standard Input (protected against writing, etc.)
- 61 Standard Output holds listable output
- 62 Standard punch output from COMPASS, etc.
- 63 Library.

16.2 CENTRAL INPUT/OUTPUT ROUTINE

16.2.1 Introduction

Input/Output requests in COMPASS programs are written as calling sequences for monitor routines controlled by a central Input/Output routine called CIO.

CIO performs the following functions:

- (i) Selects an available channel
- (ii) Rejects requests if
 - (a) the unit is not available (e.g. due to an operator error).
 - (b) no access channel is available
 - (c) an illegal instruction (function code) is given.
- (iii) Provides the current status for all requests.
- (iv) Initiates all I/O operations, and then returns control to the main program so that processing may continue while the I/O operation is carried out.
- (v) Responds to external interrupts, and transfers control to a routine specified by the programmer.

16.2.2 Calling Sequences

Input/Output operations are specified by entering an octal function code and other parameters into a calling sequence. The function codes are $\frac{1}{2} \int_{-\infty}^{\infty} \frac{1}{2} \int_{-\infty}^{\infty} \frac$

Function Code	Request
01	Read
02	Write
03	Read backwards
04	Rewind
05	Unl oad
06	Ba ck spa ce
07	Space forward past 1 EØF
10	Space backwards past 1 EØF
11	Write EØF
12	Erase
13	Status
14	Format

There are 4 operations performed with CIO

- (i) I/O operations
- (ii) Tape control operations
- (iii) Unit Status operations
- (iv) Format selection operations.

16.2.3 Input/Output Operations

The function codes used by Input/Output operations are:

- (a) 01 READ n words, starting at FWA (First word address)
- (b) 02 WRITE n words, starting from FWA
- (c) 03 READ BACKWARDS, n words, and store backwards, starting at FWA+n-1.

Calling Sequence:

 $\label{eq:loss_equations} \mbox{Input/Output operations are requested by the following sequence of instructions.}$

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD	COMMENTS
112:314 5 6 7 8	 	39 40 41 42 43 44 45 46 47 46
	RTJ $CI\phi$)
(L+1)	function Code Logical Unit Number, Enterrupt Indicate	•
(L+2)	UJP Reject Address	
(4+3)	Mode First Word Address	
(44)	Number of Words	
(4+5)	Interrupt Address	
(L+6)	FIRST INSTRUCTION EXECUTED UPON RETURN I	ROM CIG
	Note: CIP must be declared external somewhere in	the subprogram
	2/50 if Interrupt Indicator = 0	
	no Interrupt Address is specified and	
	from CID should be located at L+5 in	steed
	of L+6.	
		1

- Notes: (a) The logical unit number (LUN) is defined by an EQUIP card, and may be 1-63, depending on function code.
 - (b) The function code is an octal number, 1-14 as defined previously.
 - (c) The interrupt indicator selects an interrupt on normal or abnormal end of operation when set.
 - 0 = no interrupt
 - $1 = \text{interrupt on } \underline{\text{ABNORMAL}}$ end of operation only (end of tape, EOF mark, load point, parity error, lost data for mag. tape.)
 - 2) interrupt on an end of operation, whether normal
 - 3) or abnormal.
 - (d) JUMP is any legitimate jump to the reject address.
 - (e) <u>Interrupt address</u> is the address of a closed subroutine to which control goes when the specified interrupt occurs.
 - (f) Reject address is a symbolic address to which control goes in the event of CIO rejecting the calling routine. In the event of a reject because a channel or a unit is not available the A register will contain zero. If the reject is due to an illegal function code, the A register will contain a non-zero quantity. For both types of rejects, the Q register will contain the status of the unit.

(g) The mode designates the method of recording, and is given as an octal number.

If no mode is designated, binary mode is assumed and density is under the control of the operator.

Density	Parity
Do not select a new mode	
none	even
none	odd
low	even
low	oda
medium	even
medium	odd
high	even
high	odd
	Do not select a new mode none none low low medium medium high

- (h) First Word Address (FWA) is the symbolic address of the first word in the input or output area.
- (i) Number of words (n) is the decimal number of words to be transmitted.
- (j) If no interrupt is specified, the normal return is written in location L+5.
- (k) On interrupt, before control is passed to the interrupt address, SCOPE saves A, Q and the 3 index registers. On completion of the interrupt subroutine, the programmer must return control to SCOPE, which will then restore the A, Q and Index registers to their original values. Note that no values obtained in the subroutine can be returned to the main program in these registers.

Example:

Write at 556 bpi in BCD on ${\bf a}$ magnetic tape that has previously been defined as LUN 20, a 27 word block of data commencing at the symbolic address ORIGIN.

 $\label{lem:after successfully initiating the write operation, jump to the symbolic address PROCESS and continue the execution of the program.$

In the event of an abnormal end of operation, go to the symbolic address ABANDON; and if the write request is rejected, jump to PAUSE.

Answer:

***************************************	OPERATION, MODIFIERS	ADDRESS FIELD
7 6	5 (0)(: 12 13 14 35 15 17 16 17	
L	RTJ.	c I Ø
	0.2	20,1
	UJP	PAUSE
	60	ØRIGIN .
		27
		ABANDON
	U JP	PROCESS
		the standard of the standard o

Use of interrupt facility (See also Section 21.3)

 $If \ an \ interrupt \ address \ is \ specified, \ and \ the \ interrupt \ indicator \ is \ non \ zero, \ control \ transfers \ to \ the \ interrupt \ address \ at \ the \ end \ of \ the \ operation, \ or \ upon \ an \ abnormal \ condition \ interrupt.$

Before giving control to the interrupt address, SCOPE saves the contents of the A, Q and three index registers. It then enters the current condition and status of the unit in the A and Q registers respectively.

C = Condition of unit

0 = dynamic

1 = static

LF = Last function code (other than 13) given
 for the unit

TCA = Terminating character address of data transmission contained in the Buffer Control Register.

LS = Logical Status of the Unit

00 = (a) if a status request, unit is static, channel is available

(b) for reject return, hardware reject

(c) for normal return, unit is dynamic

01 = Channel is not available for any requests

10 = previous operation is incomplete

11 = previous operation is complete, but an
 interrupt request is being processed.

LC = Last channel to which the unit was connected (or is still connected).

R = Retention code (from standard 3200 tape label)

0 = tape may be used for output

1 = contents of tape should not be destroyed.

STATUS See following chart.

UNIT STATUS TABLE

STATUS BIT	MΤ	CR	CP	PR	PT	TY
00	Ready	Ready	Ready	Ready	Ready	Ready
01	Busy	Busy	Busy		Busy	Busy
02	Write enable					
03	File mark	ЕØF				
04	Load point					
05	ЕØТ	Hopper empty			Tape supply low	
06	DENSITY OO = low					
07	01 = med. 10 = high					
08	Lost data	Fail to read	Fail to feed			
09	End of operation					
10	Parity error	Reader error	Compare error			Parity error
11	Binary mode	Binary card	Binary mode		Binary mode	
12		Stacker full or jammed				
13						
14						
15						
16						

 $\underline{\text{NOTES}}$: (a) Density is signified by combinations of 2 bits - bits 6 and 7 - as shown.

(b) Bits 13-16 are not used.

Control transfers to the interrupt address by a return jump instruction established by $SCO\!\!\!/\!\!\!/ PE$ within the CIO routine.

The interrupt address should therefore be an unconditional jump instruction to enable control to return to CIO after the interrupt has been processed

e.g. INTERUPT UJP **

The programmer must transfer control to SCOPE from the interrupt routine by returning through linkage established by the return jump instruction

Upon regaining control, SCOPE restores the A, Q and Index registers, and then returns control to the running program.

Note that values placed in A, Q or the index registers in the Interrupt routine will be lost when the return to CIO is made. Values to be returned should therefore be stored before the transfer of control is carried out.

An example of this appears on the following page.

16.2.3 (cont.5)

Example:

Read 500 words from tape LUN 3 into a buffer commencing at BUFF. When the Operation has been initiated, continue program execution. When the operation is complete, set location FLAG to a non-zero value. If the read request is rejected because of an illegal code, jump to ABANDON. If it is rejected due to channel or unit not being available, jump to PAUSE.

Answer:		RTJ	CIO
		01	3,2
		01	REJ
		51	BU F F
			500
			INTER
		LDA	
		۰	
		٠	
		•	
	INTER	UJP	**
		ENA	1111B
		STA	FLAG
		UJP	INTER
	REJ	AZJ, EQ	PAUSE
		UJP	ABANDON

16.2.4 Tape Control Operations

The codes used in tape control calling sequence are

- 04 REWIND
- 05 UNLOAD
- 06 BACKSPACE
- 07 SPACE FORWARD PAST ONE EØF MARK
- 10 SPACE BACKWARDS PAST ONE EOF MARK
- 11 WRITE EXF
- 12 ERASE

The calling sequence:

Location L	R TJ	CIO
L+1	function code	LUN, INTERRUPT INDICATOR
L+2	JUMP	REJECT ADDRESS
L+3		INTERRUPT ADDRESS
L+4	NORMAL RETURN	

- Note: (a) If no interrupt is requested, the normal return is written in Location L+3.
 - (b) The notes for I/O control apply here also.

16.2.4 (cont.)

Examples:

(i) To rewind logical unit 56

RTJ CIO 04 56 UJP *-2 normal return

(ii) To write an end-of-file on LUN 20

RTJ CIO 11 20 UJP *-2 normal return

(iii) To space forward past an end-of-file mark on LUN 17

RTJ CIO 07 17 UJP *-2 normal return

Notes: (i) The direction of tape motion following a BACKSPACE request depends upon whether the last operation was a READ or a READ BACKWARDS operation -

- (a) If the last operation was a READ operation, the tape will move backwards.
- (b) If it was a READ BACKWARDS operation, the tape will move forward one record.

Other motion requests indicate the true direction of the tape and are not affected by READ BACKWARDS.

(ii) Tape control operations require the channel only during initiation of the function. They do not cause the channel to be busy while the function is carried out. However, if an interrupt at the end of operation is requested, CIO considers the channel to be busy until the interrupt occurs.

16.2.5 Unit Status Requests

For codes returned as status replies, see table on (cont.3) of section 16.2.3.

The calling sequence:

Location L RTJ CIO

L+1 13 LUN, Dynamic flag
L+2 NØRMAL RETURN

NOTES: (a) The function code in L+1 is always 13.

- (b) SCOPE provides the status in the Q register, and the current condition in the A register (A is negative if the unit is static, positive if it is dynamic).
- (c) Dynamic flag:

If this is non-zero, the unit is interrogated for status unconditionally. (Status is given if unit is busy or not). If the flag is zero:

- (i) If it is not busy, the status of the last completed operation is given.
- (ii) If the unit is busy, the current status is returned.

16.2.6 Format Selection

The codes used in this sequence are -

1 = BCD

2 = BINARY

3 = LOW

4 = MEDIUM

5 = HIGH

The calling sequence:

RTJ CIO

14 LUN, FORMAT CODE (as above)

JUMP REJECT ADDRESS

NØRMAL RETURN

16.2.7 Page Control of the Line Printer

The first character of the output buffer is used to position the paper prior to and after printing. This is accomplished by the following sequence of events.

- (a) The first character is removed and replaced with a blank.
- (b) The corresponding function code is found and selected.
- (c) The output buffer is printed.

16.2.7 (cont.1)

The character codes used in Page Control are:

User Character	Action Before Print	Action After Print
1	Skip to channel 8	Space 1 line
2	Skip to channel 7	Space l line
3	Skip to channel 6	Space 1 line
4	Skip to channel 5	Space 1 line
5	Skip to channel 4	Space 1 line
6	Skip to channel 3	Space 1 line
7	Skip to channel 2	Space 1 line
8	Skip to channel 1	Space 1 line
A	No space	Skip to channel 8
В	No space	Skip to channel 7
С	No space	Skip to channel 6
D	No space	Skip to channel 5
E	No space	Skip to channel 4
F	No space	Skip to channel 3
G	No space	Skip to channel 2
Н	No space	Skip to channel 1
blank	No space	Space 1
0	Space 1	Space 1
-	Space 2	Space 1
*	No space	No space
other	No space	Skip to channel 1

Examples:

(a) To advance paper to the top of the new page

CIØ
61
REJX
PAGE
1

PAGE BCD 1,1

(b) To advance one line

DS


RTJ	CIØ
02	61
RTJ	REJX
00	DS
00	1
BCD	1

Note: If unit 61 is assigned to tape by the operator and the tape is listed later or is listed off-line, trouble may develop because of the short print record (4 chars).

Therefore it is recommended that all records be at least 24 characters so that they won't be considered 'noise' records by tape input routines.

SCOPE CONTROL CARDS

- 17.1 INTRODUCTION
- 17.2 SEQUENCE CARD
- 17.3 JOB CARD
- 17.4 ENDSCOPE STATEMENT
- 17.5 ENDREEL STATEMENT
- 17.6 CTO STATEMENT
- 17.7 REWIND STATEMENT
- 17.8 UNLOAD STATEMENT
- 17.9 EQUIP STATEMENT
 - 17.9.1 Hardware Definition
 - 17.9.2 Equating Logical Units
 - 17.9.3 Physical Unit Assignment
- 17.10 TRANSFER STATEMENT
- 17.11 LOAD STATEMENT
- 17.12 COMPASS LIBRARY CALLING STATEMENT
- 17.13 RUN STATEMENT
- 17.14 DIAGRAMMATIC DECK



17.1 INTRODUCTION

SCØPE control cards have a 7,9 punch in column one. There must be no other punchings in column 1.

Columns 2 through 80 contain Hollerith information or blanks. The first information on each card must be the statement name, followed by a comma.

> 7_{RUN},
> 7**Jøв**, e.g.

17.2 SEQUENCE CARD

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
SEQUENC	E, j. , , , , , , , , , , , , , , , , , ,
: (*) * (*) * (*) * (*)	

The sequence statement assigns a number (j) to the job which it precedes. j must lie between 1 and 999. This card is normally supplied by the operating staff.

An EØF $\underline{\text{must}}$ precede each SEQUENCE statement except the first on input.

When a SEQUENCE statement is detected, the statement is typed out on the console typewriter, and listed on the standard output unit. SCOPE writes an EOF on the standard output tape (when tape is being used), and on the punch tape (if assigned), and releases all programmer units held from the last job.

SCOPE also closes off the last job's accounting, and opens a new accounting record for the new job.

If the sequence card is not followed by a JØB card, the job is terminated, and SCØPE searches forward until it finds an EØF. The following statement must be a SEQUENCE, ENDREEL or ENDSCØPE. If it is a SEQUENCE followed by a JØB card, SCØPE proceeds normally.

After SEQUENCE is read, SCOPE pauses for comments from operator to be typed in on the console typewriter. These enable the operator to specify the services for program execution (e.g. special EQUIP statements). This is the only opportunity the operator has to enter such statements.

Note: If the column following "j" contains a comma, comments may follow.

Example:

7sequence,027,

COMMENT

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
3JØB, c, i,	t 45 ND
. [2] 4 . * [5] 4 . * [8]	0 10 10 10 10 10 10 10 10 10 10 10 10 10

The symbols used in the statement are interpreted as follows:

- c charge number, 0-8 characters
- i programmer identification, 0-4 characters
- t time limit in minutes for the entire job, including all operator setting up, idle time, etc.
 - NS indicates a single non stacked job. If NS is specified, NP is implied also.

All system units are rewound and unloaded, making all I/O units available to the programmer.

- NP Suppresses system I/O protection for stacked job.
- ND Suppresses the normal post execution dump in octal of the non system part of memory should abnormal termination of the job occur.

The c, i, and t fields are mandatory. If a field is blank, the comma showing this must appear.

The job card is written on the standard output unit, and also on the CTØ (comments to operator) if the job is part of a stack. It must be immediately preceded by a SEQUENCE card or the run will be terminated.

17.4 ENDSCOPE STATEMENT

			·
LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD	
ZENDSC Ø	PE		
11815 816 817	1 * * * * * * * * * * * * * * * * * * *	10 2: 22 T5 2* 20 2* 27 20 26;	2617:1251231941221861351

This indicates that a SCOPE run is to be terminated. On the standard input unit, it should follow the EOF terminating the last in the stack. This card is normally supplied by the operations staff.

The card is listed on the CTØ unit and on ØUT, and the standard input unit is unloaded, if magnetic tape.

The library tape is rewound, and the accounting file is closed off.

A double EØF and one BCD word, consisting of $ER_{\Lambda\Lambda}$ are written on the standard output tape (when tape is used), which is then unloaded. If the punch tape is assigned, it is treated in the same way.

When all action is completed, the computer stops.

17.5 ENDREEL STATEMENT

LOCATION	OPERATION MODIFIERS ADDRESS FIELD
<i>GENDRE EL</i>	
. (21) 415 617 1	 KII 100 (A) (A) (A) (A) (A) (A) (A) (A) (A) (A)

The statement terminates a reel of magnetic tape containing a job stack. (Normally it will be placed in a card job stack by the operations staff during card to tape operations preparing a tape for use as a standard input tape.)

SCOPE requires an EOF both immediately $\underline{\text{before}}$ and $\underline{\text{after}}$ ENDREEL.

When the statement is detected, SCØPE prints a message on the CTØ unit requesting the operator to mount the next reel of input, and halts the computer until the operator takes the action.

17.6 CTØ STATEMENT

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
ZCTØ, stat	ement
12331414141714	

The programmer may provide instructions of messages to the operator. The message is punched in Hollerith.

Examples: ${}^{7}_{9}$ CTØ,PLEASE UNLØAD TAPE TWØ.

7CTØ, SNAP DUMPS WILL ØCCUR.

The message is printed on the CTØ, and also listed on \emptyset UT. CTØ cards may be placed in the deck where SCØPE control cards may appear, except as follows:

- (i) Before or after SEQUENCE, ENDSCOPE or ENDREEL.
- (ii) After CØMPASS or FØRTRAN.
- (iii) Between RUN and last data card.

17.7 REWIND STATEMENT

LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD	
ZREWIND	$\mathcal{O}_1 \mathcal{U}_1, \mathcal{U}_2, \ldots, \mathcal{U}_n$		
		[[2:37]	

The magnetic tapes specified are rewound to load point. U is the logical unit number, and may be 1 through 57 or 63. The statement is copied onto the standard output unit, and on the CTØ unit.

If U is not 1-57,63 or not a magnetic tape unit, the request is ignored for that unit, but the rest of the units on the card are processed.

Example:

7 9**REWIND**,21,42,01,55

17.8 UNLØAD STATEMENT

LOCATION		OPERATION, MODIFIERS ADDRESS FIELD
ZUNLØAD,	U	<u>, U27 • • • - 5 Un</u>
- 12 2 4 4 6 7 8		{

The Logical units, \overline{U} (1-57), may be unloaded by the programmer. The statement acts similarly to the REWIND, except that the unit is unloaded after rewinding.

Example: 7UNLØAD,21,42,01,55

17.9 EQUIP. STATEMENTS

LOCATION OPERATION MODIFIERS ADDRESS FIELD

GEQUIP, X,=d, x,=de, e + c

Where X = the logical unit number

d = a declaration about the unit.

17.9.1 Hardware definition

 $^{7}_{9}{\tt EQUIP}, {\tt X_1=hh}_1, {\tt X_2=hh}_2, \ldots \ldots {\tt etc}\,.$

hh is a hardware type mnemonic

X is a L.U.N.

Mnemonic	Type
MT	Magnetic Tape
CR	Card Reader
PR	Printer
CP	Card Punch
TY	Console typewriter
PT DP	Paper tape station Disk Pack

 $\texttt{SC} \not \texttt{OPE}$ assigns the LUN to an available equipment of the specified type.

If no equipment is available, a diagnostic is given, and the job is terminated.

Examples:

7EQUIP,51=MT

7 QEQUIP,51=MT,43=PR,26=PT

17.9.2 Equating Logical Units

Logical units are equated by this statement

$$_{9}^{7}$$
EQUIP, $X_{1}=X_{2}$

A system unit (57-63) may not be specified on the left hand side of the statement. If it is, the job is terminated.

Examples:

7EQUIP,43=60 is permissable

hut

7eQUIP,60=43 is illegal

7 9EQUIP,22=MT
Here both LUNS 22 and 23 will
reference the same magnetic tape.

17.9.3 Physical Unit Assignment

c = channel number (0-7), prefixed by C

e = equipment number (controller), prefixed by E

uu = unit number (device), prefixed by U

Example:

It is possible to omit some parameters in the statement. The following table sets out permissable combinations.

hh	C _c	E _e	U uu
x			
x	x		
x	x	x	
x	x	x	x
	х	х	x
	x	x	

Use of non-existant c, e or uu, will cause a diagnostic and termination of the job.

Example:

Assign PUN (LUN 15) and LGO (Load and Go, 56) to the physical unit on channel 0, Equipment 1, and unit 7.

Answer:

7 9EQUIP,15=MTCOE1U07

7 9EQUIP,56=15

or 7EQUIP,15=MTCOE1U07,56=15

LOCATION		OPERATION, MODIFIERS ADDRESS FIELD
ZXFER,U		
-12 > 4 6 6 7 4	,	

U = Magnetic Tape Unit, defined as 1-56, or undefined.

Description:

SCOPE transfers all the information following the XFER statement from the Standard input unit (INP) to the magnetic tape LUN U, until another SCOPE statement is encountered.

The records must be binary records and they are written on LUN U in odd parity. When the next SCOPE statement is found, an EOF is written on the tape, and SCOPE then backspaces over the EOF.

Uses:

- (i) Programmer binary data cards* may be transferred from INP to a magnetic tape unit. A card with a 7 punch in column 1 is sufficient to terminate the XFER operation.
- (ii) Binary object subprograms may similarly be stored on another magnetic tape for future use. The unit must be rewound before the LØAD operation if it is a programmer or scratch unit.

Example:

7 %FER,03

Binary Data*

7 9

The data is written on unit 3; when the $\frac{7}{9}$ card is found, SCØPE writes EØF and backspaces over it.

^{*}Data cards must be binary data cards where column 1 has a $_{9}^{7}$ punch plus at least one punch in the + - 0 1 2 or 3 position. The data used is usually a subprogram binary deck.

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
ζLØAD, υ,,	V _{Zg} V _Z
	# 100 lm ing too lm ing ing lag ing lag ing lag ing lag ing ing ing ing ing ing ing ing ing in

 $(\mathbf{U}_1,\ \mathbf{U}_2 \ \mathrm{and} \ \mathbf{U}_3 \ \mathrm{are} \ \mathrm{Mag.} \ \mathrm{tape} \ \mathrm{units}, \ \mathrm{previously}$ defined by EQUIP statements as LUN 1-56. If omitted, SCOPE will try to load from the INP unit 60)

Description: Not more than 3 units can be specified, and the loading is done in the order indicated. Unit U, will be loaded until an EØF is found. Then U, is loaded until EØF, and finally \mathbf{U}_{3} is loaded. there are 3 parts on one unit, each terminated by an EØF, the unit number can be repeated:

When the units designated have been loaded, the Standard input unit is examined to see if binary object subprograms follow the LØAD card.

If the LGØ unit is being used, the LØAD NOTE: card must be of the form:

The LØAD statement calls the loader to load binary subprograms into memory from programmer units, scratch units, LGØ or INP. Only one LØAD statement may appear in a run.

If 56 (LGØ) is specified, it will first be rewound by SCOPE. Other units must be rewound by rewind statements before loading is attempted.

Example:

LGØ is rewound by SCØPE and loaded until EØF is found. Units 3 and 25 are then loaded to EØF marks.


If only binary object programs are to be NOTE: loaded (on INP), no LØAD card is necessary.

Example:

⁷Jøв,11121156,404,2

Binary object deck

7RUN, 1



Description: The COMPASS library program is called in and loaded into memory, so that source programs in COMPASS may be assembled and executed.

> The parameter letters are free field, and may thus appear in any order. Each parameter must start with the character shown.

I = INPUT (the source subprogram input unit)

Specified as I = u, when u = LUN, when a source subprogram is to be loaded from a unit other than INP.

If the I parameter is absent, input is assumed to be from unit 60 - INP.

Example:

7EQUIP,**MT=2**3 ${}_{9}^{7}$ CØMPASS, I=23, etc.

P = PUNCH-UNIT

Specified as P = u, where the punch unit is to be assigned to an output device.

If P only occurs, punching is on the binary punch unit (PUN) - unit 62.

If the parameter is absent, no binary output is produced.

$$X = EXECUTE (X = u)$$

Assigns the Load-Go unit $(LG\emptyset)$ to logical unit U, which must have been previously defined as a MT unit.

If absent, no LGØ tape will be produced, and the program will be assembled and listed only.

If only X appears, output will be put on the standard LGØ unit (56).

$$L = LIST OPTION (L = u)$$

Output is listed on unit u, which must have been previously defined.

If L only appears, listing will be done on the OUT unit (61).

If the parameter is absent, no listing of the program is given.

R = REFERENCE

When R appears, a symbol reference list is produced on the assembly listing. This is an alphabetic list of all symbols used in the program, with the address, or the value, of the symbol shown. The symbol list appears immediately following the listing of the assembled program.

Example:

A ABNORMAL	77777	EXTERNAL	P00013 P00001	
В	00020		P00013	
JOHN	P00002		P00011	
NAME	P00011		P00013	
X	00057		P00012	P00013

SYMBOLS NOT REFERENCED

ABLE P00013 LOC P00007 START P00000

Note that X is referenced at two different locations in the program (12 and 13).

Character addresses are shown as follows:

CAN P00166 0 BILL P00156 1

17-Bit non-relocatable symbols are shown

тøм 00076 2

LOCATION	OPERATION MODIFIERS ADDRESS FIELD
ZRUN, t,	NM ,
. [1.344] 1.617	* * * * * * * * * * * * * * * * * * *

t = execution time in minutes

May be in the range 0 through 999.

The time is not used by SCOPE, but is entered in the installation accounting file.

If not specified, maximum time is assumed.

NM = NO MEMORY MAP

If NM appears, it suppresses the memory map that would otherwise be written on ØUT, before program is executed. (All absolute memory allocations are given in the map).

Examples:

(i) ${}^{7}_{9}$ RUN,2

(the execution time is assumed to be two minutes. The memory map will appear on ØUT.)

(ii) 7/RUN,727,NM

(the execution time is assumed to be 727 minutes, and no memory map will appear on OUT).

(iii) $^{7}_{9}$ RUN

(maximum execution time is assumed. Map will be printed).

(iv) ${}^{7}_{9}$ RUN,,NM

(maximum execution time assumed, and no map will be listed on $\emptyset UT$).

17.14 DIAGRAMMATIC DECK

```
7
9SEQUENCE,001
_{9}^{7}JØB,3200,STØRMA,10
7<sub>9</sub>EQUIP,56≔MT
7 FØRTRAN, (Parameters)
        PRØGRAM MAIN
                                               FØRTRAN Main Program
        CALL START
         END
            FINIS
  7
9CØMPASS,(Parameters)
                         T₩Ø
             IDENT
                         START
             ENTRY
                          **
                                                 CØMPASS Subprogram
  START
             UJP
              END
             FINIS
   7<sub>9</sub>LØAD,56
   7<sub>9</sub>RUN,5
              data deck
              (End-of-File Card)
    7
9ENDSCØPE
    77
88
```

SCOPE DEBUGGING AIDS

- 18.1 OCTAL CORRECTION CARDS
 - 18.1.1 Location Symbols
 - 18.1.2 Octal Corrections
 - 18.1.3 Relocation Factors
 - 18.1.4 Error Indicators
- 18.2 SNAP DUMPS
 - 18.2.1 Errors
 - 18.2.2 Location
 - 18.2.3 First and Last Word Addresses
 - 18.2.4 Mode
 - 18.2.5 Identification
 - 18.2.6 Note
 - 18.2.7 Example
 - 18.2.8 Rules for Using SNAP
- 18.3 OTHER DEBUGGING AIDS
 - 18.3.1 Memory Map
 - 18.3.2 Abnormal Termination Dump
- 18.4 COMPASS ERROR CODES

18.1 ØCTAL CORRECTION CARDS

7ØCC, location, octal correction, -----, octal correction.

Description: Octal corrections may be made to binary object subprograms after loading, using this instruction.

The parameters are free field.

If a period is used to terminate the card, comments may follow it.

The statement may be used to -

- (i) define corrections
- (ii) enter corrections
- (iii) enter additions to a subprogram by establishing a program extension area after the subprogram area.

18.1.1 Location Symbols

(i) (Program name) k

Corrections on this card are loaded beginning with relative address "k" in the named subprogram. The subprogram name must appear in parentheses.

Examples:

%cc,(BUFFIN)107,20

Example of use:

		IDENT	Twø
		ENTRY	START
0	START	UJP	**
		•	
		•	
10		ENA	20B
		•	
		END	

To change ENA 20B 30B to ENA ⁷øcc,(Twø)10,14600030

(ii) Data Area Corrections

Dk

Corrections are loaded beginning with location "k" in the Data area.

⁷øcc, D70, 14000000 Example:

18.1.1 (cont.)

(iii) Program Extension Area

Xk

(a) First occurrence:

Defines a program extension area of length k words. Corrections on this card are ignored.

(b) Subsequent occurrences:

Corrections are loaded beginning at location k of the program extension area.

Example:

 $\sqrt{9}$ cc, x30

⁷øcc, x3, 14000010, 14000250

(iv) Continuation Cards

+k

Increment k locations from the last location plus 1, corrected by the previous $\emptyset CC$ card. k must be octal.

9¢cc,(TEST)136,00000100

7øcc,+5,14000600

Location 136 in Subprogram TEST, and location 144 in TEST are changed.

18.1.2 Octal Corrections

- (i) Corrections may be of up to 8 digits, and are in the form of machine instructions.
- (ii) Each correction is separated from the preceding correction by a comma.
- (iii) Leading zeros may be omitted. Each value is stored right justified with zero fill, in successive computer words.
 - (iv) Locations may be omitted for correction by using commas to indicate the omissions -

Location 10 is altered to 140

11 is unchanged

12 is altered to 162

13 is unchanged

14 is altered to 10014100

18.1.3 Relocation Factors

- (i) none given the quantity specified is absolute.
- (ii) (Subprogram name) the address field of the correction is

relative to the subprogram's first location.

- (iii) Data area
- Relocate the word address portion of the Octal correction relative to the DATA area.
- (iv) Common Area (

Relocate the word address portion of the Octal correction relative to the COMMON area.

(v) Program Extension Area - X

Relocate relative to Prog. Ext. Area.

(vi) Last subprogram area referred to - *

Relocate relative to the last subprogram named in this or a preceding OCC or SNAP statement.

Example: 7 pCC, (TW p) 30,20000040(TW p)

Correction made to location 30 in subprogram TWØ, with the address part of the correction relocated by the factor by which TWØ itself is relocated.

(i.e., if subprogram TWØ itself is relocated by 1000, the actual correction loaded would be 2001040).

Note: The above example could also have been written:

70cc,(TWØ)30,20000040*

18.1.4 Error Indicators

Errors in ØCC cards prevent execution of the program.

If the extension area is incorrectly defined, the following message is printed on $\phi \text{UT:}$

***Xnnn

where nnn is the 3-digit octal length of the $SC\emptyset PE$ defined extension area.

The format for all other errors is:

*mn COL nn

where mn = error mnemonic

nn = column number on the card.

18.1.4 (cont.)

The following table sets out the error mnemonics used.

Mnemonic	Meaning			
PN	Program name			
BS	Common or data storage is undefined and referenced			
AD	Address or location field begins with an illegal character			
8 F	Octal field contains a non- octal character			
XA	Program extension area error			
WR	Wrap around of location field address - exceeds core size			
AN	Antecedent reference to a program or loading address			
RL	Relocation factor error			

18.2 SNAP DUMPS

 $SCO\!\!\!/\!\!\!/ PE$ provides selective memory dumps during execution, using this statement.

7SNAP, (Parameters)

The statement must appear after the program is loaded and before the \mbox{RIN} card is encountered.

The dump is carried out by the library routine SNAPSHØT, which <u>must</u> be defined in the program as an external. (If it is not declared as external, the routine is not loaded into storage at load time. A diagnostic of this is given on the ØUT listing as fcllows:

*** NØSD

RUN ABØRTED

The job is terminated.)

Snap statement parameters define

- (a) Where the dump is to be taken i.e. when execution reaches a predetermined point, the dump is taken.
- (b) The area to be dumped.
- (c) The format of the dump.

The SNAP statement is of the following form:

7 SNAP, location, beginning address, ending address, mode, identification, comments.

Each parameter is separated by commas.

Program names are always enclosed in parentheses.

18.2.1 Errors

If there is an error in any subfield, the following diagnostic is ren.

*mn, COL nn

mn = error mnemonic

nn = the card column number, in which the
error occurs.

The error mnemonics are set out in the table on the following page.

Mnemonic	Meaning
PN	Program name
BS	Common or data storage is undefined
AD	Address or location field begins with illegal character
8F	Octal field contains a non-octal character
XA	Program extension area is undefined or too small
WR	Location field address wrap around - exceeds core size
OV	Overflow of memory will recur if this SNAP is loaded
IM	Illegal mode
RG	Range to be snapped has FWA greater than LWA

When an error occurs, the SNAP statement is ignored, and execution continues as if no SNAP statement had been given.

18.2.2 Location

- (i) (Subprogram name) k
 - Replace location k in the subprogram with a RTJ to SNAP calling sequence.
- (ii) Program extension area Xk Replace location k in the P.EXT area by a RTJ to SNAP calling sequence.
- (iii) Data area Dk
 Replace statement k in the DATA area by a RTJ to the
 SNAP calling sequence.

18.2.3 First and Last Word Addresses

The ending address must always be greater than the beginning address, or the SNAP statement is ignored.

The address can be

- (i) Dk dump begins or ends with word k in the DATA area.
- (ii) Ck dump begins or ends with word k in the COMMON area.

18.2.3 (cont.)

- (iii) Xk dump begins or ends with word k in the Program Extension Area.
- (iv) (Subprogram name) k dump begins or ends with the location k in the specified subprogram.
- (v) *k dump begins with the location k in the last named subprogram in a preceding ØCC or SNAP statement.

18.2.4 Mode

The dump may be in one of 3 formats, and may include the Register file or not, as specified.

0 = octal

C = 6-Bit Characters

F = Floating point

If the register file is to be included, R is used. Thus $\not R$ will give the dump printed out in $\not R$ plus the register file contents.

18.2.5 Identification

O to 4 BCD characters will be printed out on the SNAP output to identify the dump. (Used if several dumps are to be made).

18.2.6 Note

If the location specified is in a loop, the contents of the area will be dumped out each time the location is encountered in the loop.

18.2.7 Example

Dump after the execution of the 5th instruction of subprogram SUB1 (assuming the first location of the subprogram is the entry point and is entered by a RTJ). Dump from location 441 in SUB1 to location 465 in SUB1 in OCTAL, with the Register File also, and identify the dump as $\emptyset NE$.

Answer:

7SNAP, (SUB1)6, *441, *465, ØR, ØNE

*441 could also be written (SUB1)441

18.2.8 Rules for Using SNAP

(1) DON'T specify SNAP for an instruction using more than one word,

e.g. SRCE

SRCN

MOVE

- (2) $\underline{\frac{DON'T}{}}$ SNAP jumps or tests, e.g., AQJ,EQ. The jumps will not be executed correctly.
- (3) DON'T SNAP indirectly addressed instructions.
- (4) $\underline{\text{DON'T}}$ SNAP instructions which will be modified by program execution.
- (5) AVOID using SNAP instruction in a loop.
- (6) $\underline{\text{DON'T}}$ modify the location at which the SNAP occurs by an $\emptyset CC$ statement.
- (7) DON'T specify SNAP for the following instructions:

MEQ

MTH

SSH

CPR

CON

SEL

EXS INS

INTS

PAUS

- (8) $\underline{\text{DON'T}}$ specify SNAP for any SKIP Instruction e.g. ISI, ASE, QSG, etc.
- (9) DON'T specify SNAP for INPUT/ØUTPUT instructions.

18.3 OTHER DEBUGGING AIDS

18.3.1 Memory Map

The programmer may secure a map of memory allocated to a loaded program at the time the run card is encountered. This map may be suppressed by a parameter of the RUN control statement (NM).

The map contains the following information:

- (1) Absolute address of the first location in each subprogram loaded.
- (2) All entry point symbols and their absolute addresses.
- (3) The absolute addresses of the first and last locations in the common area.
- (4) The absolute address of the first location in the data area.
- (5) The absolute address of the first location in the program extension area.

18.3.2 Abnormal Termination Dump

If a job is terminated abnormally, a post execution dump of all the non system part of memory is written on the standard output unit, unless the programmer has specified in the job card that it be suppressed (ND parameter).

The dump consists of the console conditions, the register file, and all the non-system part of memory.

Should the contents of words making up a line of print be exactly the same as both the last word on the preceding line, and the first word on the following line, the line is not printed, and the word "GAP" appears instead.

e.g. If all the locations between 10010 and 10017 are the same as both 10007 and 10020, the line will not be printed, and GAP will indicate the omission.

18.4 CØMPASS ERROR CODES

- A Format error in address field.
- C Attempt to assemble information into COMMON.

 (Instructions are processed as if a PRG was encountered.)
- D Doubly defined symbol.

(The first time the symbol is used it is legal, and no flag is issued. Subsequent errors are flagged, and the instructions using the symbol are assembled as if no symbol occurred.)

- F Full symbol table.
 - (All F flagged symbols are undefined, and reference to them in address fields of other instructions will produce U errors.)
- L Location field error.
- M Modifier error.
- O Operation code error. (The field is assembled as zeros.)
- U Undefined symbol.
- T Truncation error.

(A symbol defined as a 17-bit character address is used in a subfield of only 15 bits. The 2 least significant bits are lost in truncation, and the flag indicates this loss.)

COMPASS ASSEMBLY OF CONSTANTS

- 19.1 OCTAL CONSTANT PSEUDO INSTRUCTIONS
- 19.2 DECIMAL CONSTANTS, FIXED POINT
- 19.3 DOUBLE PRECISION AND/OR FLOATING POINT CONSTANTS
- 19.4 BCD CONSTANTS
- 19.5 BCD CHARACTER CONSTANTS
- 19.6 VARIABLE FIELD CONSTANTS
 - 19.6.1 Introduction
 - 19.6.2 Octal Mode
 - 19.6.3 Hollerith Mode
 - 19.6.4 Word Address Arithmetic Mode
 - 19.6.5 Character Address Mode
 - 19.6.6 Example of VFD Instruction

19. CØMPASS ASSEMBLY OF CONSTANTS

Constants may be

- (i) stated as octal, decimal or character in the source language.
- (ii) single, double or variable precision.
- (iii) fixed or floating point format.
- (iv) placed into bit positions of variable length fields.

19.1 ØCTAL CONSTANT PSEUDO INSTRUCTIONS

LOCATION	OPERATION, MODIFIERS	ADDRESS FIELD	
	фст	My 12,	
10.2.1215.1.1		programy state of the first sector in the sector in	27.1

Description: The instruction expresses constants as signed or unsigned constants. The octal integer may consist of 8 or octal less digits.

> As many constants as can be contained on a card may be expressed in the address field, separated by commas. No blanks may appear between constants. The field terminates at the first blank or at Column 73.

The octal constants are assembled, right justified, in consecutive locations. The symbol in the location field is the 15 bit word address of the first constant in the field.

Example:

CVTABLE

ØСТ

-17,32,12345670,5742,-361

CVTABLE	7	7	7	7	7	7	6	0
	0	0	0	0	0	0	3	2
	1	2	3	4	5	6	7	0
	0	0	0	0	5	7	4	2
	7	7	7	7	7	4	1	6

Binary Scale factor:

An optional binary scale factor may be stated by suffixing the constants by B, and expressing the scale factor as a signed or unsigned decimal integer of not more than 2 digits. The magnitude of the constant after scaling must be less than

The scaling factor is used to save space in coding

Examples: (i) CVTABLE ØCT 72B2

 $72 = 111 \ 010 \ in \ binary$

= 111 010 00 scaled by 2 (shift binary point 2 places right)

= 11 101 000 regrouped

$$= 3 5 0$$

(CVTABLE) = 0000 0350

19.1 (cont.)

LØC 0000 0360 0000 4000 0000 0056

(iii) NUMBER ØCT 2416,311B16,3417B-8,-372

NUMBER 0000 2416 6220 0000 0000 0007 7777 7405

Note: In negative scaling, digits are discarded from the right. If the number after scaling is greater than 2^{24} -1, the field is set to zero and the A flag is set.

Example: ØCT 6666B20

Assembled as A = 00000000

19.2 DECIMAL CONSTANTS, FIXED POINT

LØC

LOCATION	1	OPERATION MODIFIERS ADDRESS FIELD
1 1 1 1 1 1 1	Ť	DEC d., d. 1 dn

Description: The instruction expresses constants as single precision fixed point binary constants. The constant may consist of a sign, and not more than 7 digits, with a magnitude of less than 2²³. The symbol in the location field is the address of the first constant in the field. The address field may contain as many constants separated by commas as the card may contain. The field terminates at first blank or Column 73.

1,82,-38

Example:

ГфС	0	0	0	0	0	0	0	1
	0							
	7	7	7	7	7	7	3	1

DEC

Scaling Factors:

Both decimal and/or binary scaling factors may be stated by suffixing the constant with D and/or B, and expressing the scale factor as signed or unsigned decimal integers. The magnitude of the constant after scaling must be less than 2^{23} .

Steps in the conversion:

(i) Decimal integer is converted to binary.

The result must be less than 2²³.

Example:
$$36_{10} = 44_8$$
= 100 100

(ii) Binary integer is multiplied or divided by 10^d, where d is the scaling factor.

The result must be less than 2²³.

Example:
$$36_{10}$$
 D2 = 36×100
= $44_8 \times 144_8$
= 100100×001100100
= 111000×010000
= 7020_8

(iii) Shift the result the number of bits specified by the binary scaling factor.

> Negative factor = RIGHT shift Positive factor = LEFT shift

Example:

19.3 DOUBLE PRECISION AND/OR FLOATING POINT CONSTANTS

ICCATION	OPERATION, MODIFIERS	ADDRESS FIELD	
250	DECD	d, , dz,dn	المساورت
1.1919-41619-11	* (+ G 1	00.000.000.000.000.000.000.000.000.000.000	[J4155134182]

Description: Decimal values may be stored as double precision fixed point constants, or as floating point constants. Either format requires 48 bits for storage (2 consecutive words). Up to 14 decimal digits may be specified, and the value of the expression must be less than 247.

> Decimal and binary scaling factors may be used, as in the DEC instruction.

The signed 48-bit result is stored in two consecutive computer words.

Example:

SYM.TAG DECD

32,64D2B4

Floating Point Constants:

1. Floating point constants contain a decimal point.

Examples: 300.246

2.040117321

.111

1765122.1

They are stored in two consecutive 24 bit words as a 12 bit characteristic (exponent) and a 36-bit mantissa (coefficient).

WORD 1	BIASED EXP	COEFF
WORD 2	CO	eff

- 3. A floating point constant may contain not more than 14 decimal digits and a decimal point.
- 4. Binary scaling is not permitted, but decimal scaling is.
- 5. The result after scaling must not exceed the capacity of the hardware $(10^{\pm308})$

19.4 BCD CONSTANTS

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	BCD n, G, G, G, an
	C

Description:

Characters are assembled for store into consecutive computer words as 6-bit BCD character codes, in addressable character positions. The code used is internal BCD.

The decimal integer n = the number of words to be used.

The maximum number of characters to be stored would be $4\ x\ n$.

The instruction reserves "n" words of storage, and any character positions not filled from the instruction are filled with blanks.

Characters specified in excess of $(4 \times n)$ are treated as comments.

The symbol in the location field is the 15-bit address of the first word.

Example:

(i) ERRØRMSG BCD

3,I/Ø ERRØR

ERRØRMSG

I	/	ø	60
E	R	R	ø
R	60	60	60

3 words reserved, therefore the maximum number of characters is 12. Here only 9 appear before the end of message, so all are included.

(ii) ERRØRMSG BCD

2,I/Ø ERRØR

ERRFRMSG

I	/	ø	60
E	R	R	ø

2 words reserved, therefore the maximum number of characters is 8. Here 9 appear, therefore the last one is treated as a comment and discarded.

19.5 BCD CHARACTER CONSTANTS

LGCATION	OPERATION, MODIFIERS	ADDRESS FIELD	bookers (Tanger)
	BCD,C	n, C, C, C,	1 :
-1812:4161818		1:(0:21:172:Y5:24:28:24:25:24:25:34:36:36:36:36:36:36:36:36:36:36:36:36:36:	

Description:


Characters are assembled into consecutive character positions. n signifies the number of character positions to be reserved, and must be an integer less than 2¹⁵. Characters in excess of n are treated as comments; positions reserved but not used are filled with blanks.

The symbol in the location field is the 17-bit address of the first character.

Storage

If the line of coding before BSS,C assigns character storage, the character string begins in the next available character position. If not, it begins with the first character position in the first available word.

If the number of characters specified does not exactly fill the last word, the rest of the word is zero filled. However, if the next instruction in the program which consumes space is a BCD,C instruction, it will fill up the remaining character positions in the last word.



(iv) Example of actual listing of assembled BCD and BCD,C constants:

Assembled Constants	Instr	ruction
31 61 46 60 25 51 51 46	BCD	2,1/ø ERRØR
31 61 46 60 25 51 51 46	BCD	3,1/ø ERRØR
51 60 60 60 63 25 62 63 60 47 51 46	BCD,C	9,TEST PRØG
27 63 25 62 63 60 47	BCD,C	6,TEST PR∲G
63 25 62 63 60 47 51 46 27	BCD,C	10,TEST PRØG
60 25 45 24 60 00 00 00	BCD,C	4,END

19.6 VARIABLE FIELD CONSTANTS

19.6.1 Introduction

The general form of the instruction is:

LECATION	OPERATION, MOBILITIES	ACORESS FIXES	
	VFD	Mn/v,, Mn/v	Į.
-1818141614.1	18 9 2 1 12 12 13 14 15 15 15 16 16 16	# 10, 1112,7518 (PA) 8618 1-2812619015115.72812412514.25	.i

where M = mode indicator

- n = positive decimal integer denoting the number of bit positions in the variable field specified by this subfield. (NOTE: the range of values of n varies with the mode M).
- v = the content of the field. This varies according to the mode and is restricted by the declared length.

As many address subfields as may be contained on a single card are allowed. Each subfield is terminated by a comma, except the last, which is terminated by a blank.

Use:

The instruction is used to enter information in one of the following modes into a field of a designated bit-length.

- (i) octal numbers
- (ii) character codes (BCD)
- (iii) relocatable addresses (either word or character addresses)
- or (iv) constants.

It enables information to be packed into computer words during assembly time.

Packing:

- (i) Values are entered right adjusted in the field, with sign extension.
- (ii) Character strings are entered left adjusted, with blank fill.
 - e.g. A B X is a character string.
 If entered in a 24-bit character
 VFD, it will be entered as:

21 22 69 60

Relocation:

If relocatable addresses are entered into a field, the addresses will be relocated when the assembled subprogram is loaded. (The listing will show only the <u>assembled</u> fields.)

19.6.2 Octal Mode

ROTAGOJ	OFERATION MODIFIERS	ADDRESS FIELD
	VFD	Malu
		Øn/v
	1	
11.000000000000000000000000000000000000	[* 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1	.a

where \emptyset indicates the octal mode.

n indicates the number of $\underline{\text{bit}}$ positions in the field. It may be in the range 1-24 inclusive.

v indicates the octal information to be entered into the field. It may be 1-8 octal digits, and may be signed. (If v is negative, the filled content is stored in one's complement form). The information is entered right justified in the field, zero filled if positive, one-bit filled if negative.

A binary scale factor, similar to that used with the OCT pseudo instruction, may be specified.

Example:

VFD

Ø24/24B6

Assembled as

00002400

Examples: (i)

VFD

Ø24/30502

Assembled as 00030502

(ii) VFD

Ø24/-30502

Assembled as 77747275

(iii) VFD Ø15/30502

Assembled as 30502000

(Unused portions of the word are zero filled)

Errors:

If the value v exceeds the field length n, or is not octal, the error is flagged and the field is set to zero. (The COMPASS address field error flag A appears on the listing.)

Example:

VFD

Ø15/30502,Ø15/2030502

Assembled as: 30502000 in word 1,

word 2 not shown on the listing. "A" error flag set against the line.

(Note: the program will not be executed.)

Note:

If an error occurs in any field on the card, subsequent fields in that card are not listed, although space is reserved for them.

Example:

VFD

Ø10/12345,Ø15/24,Ø15/60,Ø24/1021

Word 1 is set to zero because the field

is too small.

Words 2 and 3 are not listed.

Program listing resumes at word 4 with

next card.

19.6.3 Hollerith Mode

LOCATION	OPERATION. MODIFIERS	ADDRESS	FIELD
	VFD	Hn/y	
1 2 3 2 4 1 5 1 6 1 7 1 6	· [EC] LUZ papa [EC papa]	2012/12/12/12	##12# #7,##12# #6131 #2 \$712# \$5\ #6 \$2

Here n must be a multiple of 6 to enable storage of Hollerith information as 6-bit internal BCD character codes. The address subfield terminates with a blank or a comma. If the field is too small for the number of characters specified, an error results.

Example:

LØC VFD

VFD

H18/ABC =21 22 00

ĽØC

H12/ABC is illegal. (Address field flag "A" is set).

19.6.3 (cont.)

If the field is longer than the number of characters specified, the work is blank filled. Characters are stored <u>LEFT</u> justified in the field.

Example: $L\phi C$ VFD H18/AB = 21 22 60 00

19.6.4 Word Address Arithmetic Mode

10	CATION	OPERATION, MODIFIERS ADDRESS FIELD	
		VFD An/v	
	31*16161718	 	1321

The address field v may be:

- (i) A constant
- (ii) A symbol
- (iii) An expression formed by the rules of address field arithmetic.

If the expression yields a relocatable word address, the programmer must arrange so that it will be right justified on bit 0 in a word, and be contained in 15 bits. If it is not relocatable, the full 24 bits can be used.

Examples: (i) ALØC VFD A24/A+3

If A is a relocatable word address, previously defined, then answer must be 15 bits stored Right justified in word on bit 0.

If A is an absolute value, 24 bits can be stored.

(ii) Using relocatable word address

VFD Ø9/010,A15/BUFR

where BUFR is a symbol, address 00002 in the program.

Assembled as 01000002

(iii) Using non relocatable symbol

A EQU 77777B
B EQU 57B
C EQU 20B
VFD A21/A-B+C

Assembled as 777740 in the designated 21 bits.

19.6.5 Character Address Mode

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	VFD Cn/v
. 12321414141714(*	erin ing hatin ing ing hazing na isotsikaskahtelesi erisa, selitelaokan kasipalpalpalpalpalpa

A minimum of 17 bits is required for character addressing. n must therefore not be less than 17.

19.6.5 (cont.)

If the address is relocatable, the field must be right justified on bit ${\tt 0}$ in the word.

Examples: (i) VFD C24/237B

Assembled as 00000237

VFD C24/237 Assembled as 00000355

(ii) Suppose NAME is assembled at location 00025 in the subprogram, and is a word address.

VFD C24/NAME Assembled as 00000124

(Note: 124 is the character address of word address 25)

CADR: is assembled as a 17-bit character address

= 000237

= Word 47, character position 3

= 000473 on the listing.

 $\underline{\phi}PAD$: is assembled as a 24-bit word

= 02000237

 ${\tt O4}$ is entered right justified in a 7-bit field

= 0000100

= 000 010 0

CADR is the 17-bit character address 000237

= 00 000 000 010 011 111

(iv) Suppose TMPC is assembled as character 0 in word 20 in the subprogram

JAC

VFD

Ø7/4,C17/TMPC

Assembled as 02000100

(100 is character address of TMPC)

19.6.6 Example of VFD instruction

If NAME is located at address 00011 in the assembled program, what will be assembled as a result of:

A EQU 77777B

X EQU 57B

B EQU 20B

VFD Ø12/-737,A21/A-X+B,H24/HA3,A15/NAME+2,H12/BQ

Answer:

70	40	77	77
74	03	02	10
36	00	00	13
22	50	00	00

INPUT/OUTPUT WITHOUT CIO

0 - 7 0 0 - 1			
20.1	INPUT/OU	TPUT CHARACTERISTICS	
	20.1.1	Introduction	
	20.1.2	Interface Signals	
	20.1.3	System Configuration	
	20.1.4	Logical Sequence of Events for Initiating	
		INPUT/OUTPUT Operations	
20.2	CONNECT		
20.3	SELECT		
20.4	WORD ADD	RESSED INPUT TO STORAGE	
20.5	WORD ADD	RESSED OUTPUT FROM STORAGE	
20.6	CHARACTE	R ADDRESSED INPUT TO STORAGE	
20.7	CHARACTE	R ADDRESSED OUTPUT FROM STORAGE	
20.8	INPUT/OU	IPUT TO AND FROM THE A REGISTER	
	20.8.1	Input Character to A	
	20.8.2	Input Word to A	
	20.8.3	Output Character from A	
	20.8.4	Output Word from A	
20.9	SENSING	INSTRUCTIONS	
	20.9.1	Sense External Status	
	20.9.2	Copy External Status and Interrupt Mask Register	
	20.9.3	Sense Interrupt	
	20.9.4	Sense Internal Status	
	20.9.5	Copy Internal Status and Interrupt Mask Register	
	20.9.6	Comments on Internal Status and the Interrupt Mask Register	r
20.10	CONSOLE	TYPEWRITER INPUT/OUTPUT	
	20.10.1	General Description	
	20.10.2	Operation	
		20.10.2.1 Set Tabs, Margins and Spacing 20.10.2.2 Clear 20.10.2.3 Status Checking 20.10.2.4 Type In and Type Load 20.10.2.5 Type Out and Type Dump	
	20.10.3	Typewriter Console Switches and Indicators	
	20.10.4	Character Codes	
	20.10.5	Input/Output Instructions	
		20.10.5.1 Set Console Typewriter Input 20.10.5.2 Set Console Typewriter Output 20.10.5.3 Pause Instruction (as used with console typewriter instructions)	


20.1.1 Introduction

The Input/Output section of the computer is responsible for transferring data to and from the computer and to and from an external device. Data is transferred between a 3200 Computer and its associated external equipment via a 3206 or 3207 Communication Channel. For programming purposes, the eight possible 3206 channels in a system are designated by numbers 0 through 7. A 3207 replaces the 3206 type I/O channels 2 and 3 in expanded systems. It is programmed as channel 2.

20.1.2 Interface signals

Up to eight external equipment controllers may be attached in parallel to each 3206 Communication Channel. The following chart shows the principal signals which flow between a 3206 and its external equipment. The 12 status lines are active only between the channel and the controller to which it has been connected by the CON (77.0) instruction*.

The eight interrupt lines, designated 0-7, connect to all eight controllers attached to a channel. These lines match the Equipment Selector switch setting on each controller. For a complete description of the I/O interface signals as well as an I/O timing chart, refer to the 3000 Series I/O Specification, publication number 60048800.




^{*} The connect instruction selects one of eight controllers which may be attached to the channel.

20.1.3 System configuration

A typical configuration is:

3200 SYSTEM



20.1.4 Logical Sequence of Events for Initiating INPUT/OUTPUT Operations

Execute a connect instruction which will indicate the channel, controller and unit which is to receive or transmit the data.

Sense the status of the controller to determine if the unit is available and capable of performing the function and/or data transmission ("PRE-STATUS").

Send the appropriate select functions. Select functions are used to format the INPUT/OUTPUT device.

Execute the data transmission instructions.

At end of operation, sense the status of the controller to determine if the function and/or data transmission was successful ("POST-STATUS" check).

20.2 CONNECT

LOCATION		OPERATION, MODIFIERS ADDRESS FIELD
		CON X,4
.18.3.4.6.6.7.4	,	[] [0] [12] 4 4 4 4 4 4 4 4 4

23	18	17	15	14	12	11		00
7	7	C)	٥	h		×	

ch = I/O channel designator, 0-7
x = 12 bit connect code. Bits 09-11
 select one of eight controllers which
 may be attached to channel ch. Bits
 00-08 select the peripheral units
 connected to the controller.

Description:

This instruction sends a 12-bit connect code along with a connect enable to an external equipment controller on I/O channel 'ch'. If a Reply is received from the controller within 100 usec, the next instruction is read from address P+2. If a Reject is received or there is no response within 100 usec, a reject instruction is read from address P+1. If the I/O channel is busy, a reject instruction is read immediately from address P+1.

Once the connect is successful (RNI at P+2) it will remain in effect until another connect is attempted on the same channel or a clear function is performed.

Examples:

CØN 1001B,2

This instruction connects controller number 1 and unit 1 on channel 2.

The reject instruction coded at P+1 is usually a jump back to the connect to cause the computer to wait until the connect is successful.

e.g. CØN 1001B,2 UJP *-1

20.2 (cont.)

In the following example, which controllers and units will be connected on channel 1 and 2 when the computer stops. Assume all connects can be made.

CØN	2004B,1	
UJP	*-1	
CØN	3004B,2	
UJP	*-1	
CØN	5B,1	Answers:
UJP	*-1	Channel $1 = Equip 0$, Unit 5
UCS		Channel $2 = Equip 3$, Unit 4

20.3 SELECT

LOCATION		OPERATION, MODIFIERS ADDRESS FIELD
		SEL X,d
18 3 8 6 9 2 3 8	2	ing the tractive tractive tractive tractical terms (\$4150 \$4.550 \$4150 \$4.101 \$4.501 \$8.50 \$8.50

_	23 18	17 15	14 12	11	00
	77	1	ch	×	

ch = I/0 channel designator, 0-7 x = 12-bit function code. Each piece of external equipment has a unique set of function codes to specify operations within that device. Refer to the 3000 Series Computer Systems Peripheral Equipment Codes publication No. 60113400 for a complete list of function codes.

Description: This instruction sends a 12-bit function code along with a function enable to the unit connected to I/O channel 'ch'. If a Reply is received from the unit within 100 usec, the next instruction is read from P+2. If a Reject is received or there is no response within 100 usec, a reject instruction is read from address $P\,+\,1$. If the I/O channel is busy, a reject instruction is read immediately from address P + 1.

> The following conditions or combination of conditions will result in a Reject:

- 1) No Unit or Equipment Connected: The referenced device is not connected to the system and cannot recognize a Function instruction. If no response is received within 100 usec, the Reject signal is generated automatically by the I/O channel.
- 2) Undefined Code: When the Function code x is not defined for the specific device, a Reject may be generated by the device. However, in some cases an undefined code will cause the device to generate a Reply although no operation is performed. (Refer to the reference manual for the specific device.)
- 3) Equipment or Unit Busy or Not Ready: The device cannot perform the operation specified by the function code x without damaging the equipment or losing data. For example, a Write End of File code is rejected by a tape unit if the tape unit is rewinding.
- Channel Busy: The selected data channel is currently performing a Read or Write operation.

20.3 (cont.)

The function codes for magnetic tape and card reader are:

MAGNETIC TAPE CONTROLLERS FUNCTION CODES		324	8 CARD READER CONTROLLER FUNCTION CODES
0000	Release	0001	Negate Hollerith to
0001	Binary		Internal BCD Conversion
0002	Coded	0002	Release Negate Hollerith
0003	556 BPI		to Internal BCD Conversion
0004	200 BPI	0004	Set Gate Card
0005	Clear	0005	Clear
0006	800 BPI	0020	Interrupt on Ready and
0010	Rewind		Busy
0011	Rewind Unload	0021	Release Interrupt on
0012	Backspace		Ready and Busy
0013	Search Forward to	0022	Interrupt on End of
	File Mark		Operation
0014	Search Backward to	0023	Release Interrupt on
	File Mark		End of Operation
0015	Write File Mark	0024	Interrupt on Abnormal
0016			End of Operation
0020	Interrupt on Ready	0025	Release Interrupt on
	and Busy		Abnormal End of Operation
0021	Release Interrupt on		
	Ready and Busy		
0022	Interrupt on End of		
	Operation		
0023	Release Interrupt on		
	End of Operation		
0024	Interrupt on Abnormal		
	End of Operation		
0025	Release Interrupt on		
0015	Abnormal End of Operation		
0040	Clear Reverse Read		
0041	Set Reverse Read		

Example:

CØN	2B,1	Connects Controller 0 Unit 2 on channel 1
UJP	REJX	
SEL	10B,1	Rewinds Tape Unit 2 to Load Point
UJP	REJX	•
SEL	3B,1	Sets the Density to 556 bpi
UJP	REJX	•
SEL	1B,1	Sets the Mode to binary
UJP	REJX	•
•		
•		
UCS		

Exercise:


What does the following group of select function codes for Tape Unit 6 accomplish?

CØN	6B,0	
UJP	REJX	
SEL	6B,0	
UJP	REJX	
SEL	13B,0	
UJP	REJX	

UCS

20.4 WORD ADDRESSED INPUT TO STORAGE

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	INPW, INT, B, N ch, m, n
112131618181718	



B = "1" for backward storage

ch = I/0 channel designator, 0-7

INT = "1" for interrupt upon completion

N = "0" for 12- to 24-bit assembly

= "1" for no assembly

m = first word address of I/O data block; becomes current address as I/O operation progresses

n = last word address of input data block,
 plus one (minus one, for backward
 storage)

Description:

This instruction transfers a word-addressed data block from an external equipment to storage. Transferring 12-bit bytes or 24-bit words depends upon the type of I/O channel used. The 3206 utilizes 12-bit bytes and the 3207 uses 24-bit words.

During forward storage and 12- to 24-bit assembly, the first byte of a block of data is stored in the upper half of the memory location specified by the storage address. Conversely, during backward storage, the first byte is stored in the lower half of the memory location.

This instruction is an initiate type instruction, which means all the foregoing actions will occur only if the instruction executes normally. And RNI will be at P+3. However, if the input/output control for the specified channel in Block Control is busy, the instruction will act as a double NOP and RNI from P+2. The instruction at that location is termed the 'Reject Instruction'.

Examples:

(i)	CØN	1001B,1
	RTJ	REJX
	SEL	2B,1
	RTJ	REJX
	SEL	3B,1
	RTJ	REJX
	INPW	1, INBUFF, INBUFF+50
	RTJ	REJX

This example initiates an Input from tape unit 1, controller 1 on channel 1. The tape is written in BCD mode at 556 bpi.

(ii) A block of memory is as shown:

And the contents of a data card is:

${\tt ABCDEFGHIJKABCDEF$

What will be the contents of memory as a result of the following coding examples?

(1) CØN 3000B,0 UJP REJX INPW 0,INBUFF,INBUFF+20 UJP REJX

(2) CØN 3000B,0 UJP REJX INPW,B 0,INBUFF+19,INBUFF-1 UJP REJX


(3) CØN 3000B,0 UJP REJX INPW,N 0,INBUFF,INBUFF+40 UJP REJX

(4) CØN 3000B,0 UJP REJX INPW,B,N 0,INBUFF+39,INBUFF-1 UJP REJX

20.4 (cont.2)

Answers:	(1)		(2)	
	INBUFF	21222324 25262730 31414121 22232425 26273031 41422122 23242526 27303141 42212223 24252627 30314142 21222324 25262730 31414221 22232425 26273031 41422122 23242526 27303141 42212223	INBUFF	22334221 31412730 25262324 21224142 30312627 24252223 42213141 27302526 23242122 41423031 26272425 22234221 31412730 25262324 21224142 30312627 24252223 42213141 27302526 23242122
	(3)		(4)	
	INBUFF	77772122 77772324 77772526 77772730 77773141 77774221 77772627 77773031 77774142 77772526 77772526 77772627 77773041 77774221 77772223 77772425 77772627 77773031 77774142 77772223 77772425 77772627 77773031 77774142 77772122 77772324 77772526 77772324 77772526 77773031 77774142 77772122 77772324 77772526 77773031 777744221 77772223 77772425 77772526 7777230 77773141 77774221 77772223 77772324 77772526 77773031 77774342 77772526 77773031 77774342 77772526 7777230 77773141 77774221	INBUFF	7777223 7777421 77773741 77772730 77772526 77772324 77772122 77774142 77773031 77772627 77772425 77772421 77773141 77772730 77772425 77772425 77772425 77772426 77773141 77772627 77772425 77772425 77772425 77772425 77772425 77772425 77772426 77772427 77772426 77772421 77773141 77772730 77772627 77772425 77772425 77772425 77772426 77772426 77772421 77773141 77772730 77772526 77772421 77773141 77772730 77772526 77772526 77772526 77772526

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	OUTW, INT, B, N ch, m, n
111371414161714	# [0]



B = "1" for backward storage
ch = I/O channel designator

INT = $^{n}1^{n}$ for interrupt upon completion

N = "0" for 24- to 12 bit disassembly

= "1" for straight 24-bit (no disassembly) data transfer

m = first word address of I/O data block;

ecomes current address as I/O operation progresses

n = last word address of output data block, plus one (minus one, for backward output)

Description:

This instruction transfers a word-addressed block of data consisting of 12-bit bytes or 24-bit words, from storage to an external equipment.

With no disassembly, 12 or 24-bit transfer capability depends upon whether a 3206 or 3207 I/O channel is used. If an attempt is made to send a 24-bit word over a 3206 I/O channel, the upper byte will be lost.

This instruction is an initiate type instruction, which means all the foregoing actions will occur only if the instruction executes normally. And RNI will be at P + 3. However, if the input/output control for the specified channel in Block Control is busy, the instruction will act as a double NOP and RNI from P + 2. The instruction at that location is termed the 'Reject Instruction'.

Examples:

A block of memory is as shown:

Numerical Value

Alphabetical Representation

ØUTBUFF 21222324 25262730

21222324
25262730
31414221
22232425
26273031
41422122
23242526
27303141
42212223
24252627
30314142
21222324
25262730
31414221
22232425
26273031
41422122
242526
27303141
42212223

		В	C	D	
		F	G	H	
	Ι	J C	K	Α	
1	3	С	D	E	_
-			H	I B	
	J		A		
	3]		E	F	
		H	I	J	
		Ā	В	С	
I			F	G	
I		I	J	K	
P		3	С	D	_
E				H	
]		J .		A	
E				E	_
F	' (;]	H	Ι	
Ü		ζ,		В	
()	E	F	_
C	1	1	Ι	J	
K		\	В	С	

What will be printed on the line printer as a result of the following coding examples?

(1) CØN 5000B,1 UJP REJX ØUTW 1,ØUTBUFF,ØUTBUFF+20 UJP REJX

(2) CØN 5000B,1 UJP REJX ØUTW,B 1,ØUTBUFF+19,ØUTBUFF-1 UJP REJX

(3) CØN 5000B,1 UJP REJX ØUTW,N 1,ØUTBUFF,ØUTBUFF+20 UJP REJX

(4) CØN 5000B,1 UJP REJX ØUTW,B,N 1,ØUTBUFF+19,ØUTBUFF-1 UJP REJX

Answers:

(1)

 $\verb|ABCDEFGHIJKABCDEFG$

(2)


 $\verb|BCKAIJGHEFCDABJKHIFGDEBCKAIJGHEFCDABJKHIFGDEBCKAIJGHEFCDABJKHIFGDEBCKAIJGHEFCDAB|\\$

(3)

CDGHKADEHIABEFIJACFGJKCDGHKADEHIABEFIJBC

(4)

BCIJEFABHIDEKAGHCDJKFGBCIJEFABHIDEKAGHCD



Description:

This instruction transfers a character-address block of data, consisting of 6-bit characters or 12-bit bytes, from an external equipment to storage. During 12- to 24-bit assembly, the lowest bit of each character address is forced to remain a "0" in register OX. This ensures that assembled bytes are in either the upper or the lower half of the word being stored.

This instruction is an initiate type instruction, which means all the foregoing actions will occur only if the instruction executes normally. And RNI will be at P + 3. However, if the input/output control for the specified channel in Block Control is busy, the instruction will act as a double NOP and RNI from P + 2. The instruction at that location is termed the 'Reject Instruction'.

dxsmples:

A block of memory is as shown:

INBUFF

///////
7 7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777
7777777

And the contents of a data card is:

What will be the contents of memory as a result of the following coding examples?

		-0 0		
	(1)	CØN UJP INPC UJP	3000B,0 REJX O,INBUFF,INBUFF+0 REJX	30
	(2)	CØN UJP INPC,B UJP	3000B,0 REJX 0,INBUFF+79,INBU REJX	FF-1
	(3)	CØN UJP INPC,H UJP	3000B,0 REJX 0,INBUFF,INBUFF+8 REJX	30
	(4)	CØN UJP INPC,B,H UJP	3000B,0 REJX O,INBUFF+79,INBUI REJX	FF-1
Answers:	(1)		(2)	
		21222324 25262730 31414221 22232425 26273031 41422122 23242526 27303141 42212223 24252627 30314142 21222324 25262730 31414221 22232425 26273031 41422122 23242526 27303141 42212223		23222142 41313027 26252423 22214241 31302726 25242322 21424131 30272625 24232221 42413130 27262524 23222142 41313027 26252423 22214241 31302726 25242322 21424131 30272625 24232221
	(3)		(4)	
		Same as #1		Same as #2

Same as #1

Same as #2

B = "1" for backward storage

ch = I/O channel designator, 0-3

H = "0" for 24- to 6-bit disassembly

= "1" for 24- to 12-bit disassembly INT = "1" for interrupt upon completion

I/O operation progresses

s = last character address of output
 data block, plus one (minus one,
 for backward output)

Description:

100000

This instruction transfers a character-addressed block of data, consisting of 6-bit characters or 12-bit bytes, from storage to an external equipment.

This instruction is an initiate type instruction, which means all the foregoing actions will occur only if the instruction executes normally. And RNI will be at P+3. However, if the input/output control for the specified channel in Block Control is busy, the instruction will act as a double MOP and RNI from P+2. The instruction at that location is termed the 'Reject Instruction'.

Examples:

A block of memory is as shown:

Numerical Value

Alphabetical Representation

ØUTBUFF

21222324
25262730
31414221
22232425
26273031
41422122
23242526
27303141
42212223
24252627
30314142
21222324
25262730
31414221
22232425
26273031
41422122
23242526
27303141
42212223

A	В	С	D	
E	F	G	Н	
I	J	K	Α	
В	С	D	E	
F	G	Н	I	
J		Α	В	
C	D	Е	F	
G	Н	I	J	
K	A	В	С	
D	E	F	G	
Н		J	K	
A		С	D	
E		G	Н	
I	J	K	Α	
В	C	D	E	
F		Н	I	
J		A	В	
0		E	F	
G	H	I	J	
K	. A	В	С	

What will be printed on the line printer as a result of the following coding examples?

(1) CØN 5000B,1 UJP REJX ØUTC 1,ØUTBUFF,ØUTBUFF+80 UJP REJX

(2) CØN 5000B,1 UJP REJX ØUTC,B 1,ØUTBUFF+79,ØUTBUFF-1 UJP REJX

(3) CØN 5000B,1 UJP REJX ØUTC,H 1,ØUTBUFF,ØUTBUFF+80 UJP REJX

(4) CØN 5000B,1 UJP REJX ØUTC,B,H 1,ØUTBUFF+79,ØUTBUFF-1 UJP REJX

Answers:

(1)

ABCDEFGHIJKABCDEFGHI

(2)

 $\verb|CBAKJIHGFEDCBAKJIH$

(3)


Sames as Number 1

(4)

Same as Number 2

20.8 INPUT/OUTPUT TO AND FROM THE A REGISTER

20.8.1 Input Character to A



ch = I/O channel designator, 0-7 INT = "1" for interrupt upon completion "O" for do not interrupt upon completion

Description:

This instruction transfers a 6-bit character from an external equipment into the lower 6-bits of the A register. A is cleared prior to loading and the upper 18-bits remain cleared.


Main control is stalled until the character is received from the external equipment. At that time it resumes reading instructions and RNI's from P + 3. If the input/output control for the specified channel in Block Control is busy, the instruction will act as a double NOP and RNI from P+2. The instruction at that location is termed the 'Reject Instruction'.

Example:

CØN	3000B,1
UJP	*-1
INAC	1
UJP	*- 2

This example inputs 6-bits from controller 3, unit 0 on channel 1 into the lower 6-bits of the A register. A is cleared prior to loading and the upper 18-bits remain cleared.

20.8.2 Input Word to A



ch = I/O channel designator, 0-7 INT = "1" for interrupt upon completion "O" for do not interrupt upon completion

Description: This instruction transfers a 12-bit byte into the lower 12-bits of A or a 24-bit word into all of A from an external equipment. Transferring 12 or 24 bits depends upon whether a 3206 or 3207 I/O channel is used. (A) is cleared prior to loading and, in the case of a 12-bit input, the upper 12 bits remain cleared.

Main control is stalled until the byte (word) is received from the external equipment. At that time it resumes reading instructions and RNI's from P+3. If the input/output control for the specified channel in Block Control is busy, the instruction will act as a double NOP and RNI from P+2. The instruction at that location is termed the 'Reject Instruction'.

Note: Bits 18, 19 and 20 are all zeros when a 3206 data channel is used. If the operation with A involves the use of a 3207, these bits take on the following significance:

Bit 20 = always a "0"

Bit 19 = If bit 18 = "1", the state of bit 19 is of no consequence.

If bit 18 = "0", a "1" in bit 19 signifies backward operation. A "0" in bit 19 signifies a forward operation.

Examples:

If the connect code for the card reader is 3000B and a data card has ABCD in the first four columns, what will be the contents of the A register as a result of the following coding examples? Assume a 3206 data channel.


CØN	3000B,0
UJP	REJX
INAW	0
UJP	REJX

Answer: (A) = 00002122 Also, this is all the information that is available from that card.

Another input to A would cause the next card to be read.

20.8.3 Output Character from A

LOCATION	OPERATION MODIFIERS ADDRESS FIELD
	OTAC, INT Ch
118131816181218	10 11 12 12 14 15 16 17 18 14 TOLS: 122 28 28 28 18 187 28 189 30 31 32 33 184 35 36 27



Bits 00-16 at P and P+1 should be loaded with 0's

ch = I/O channel designator, 0-7
INT = "1" for interrupt upon completion
 "0" for do not interrupt upon completion

Description:

This instruction transfers a character from the lower 6-bits of A to an external equipment. The original contents of A are retained.

After outputting the character, main control proceeds immediately and RNI's at P+3. Should the input/output control for the specified channel in Block Control be busy, the instruction will act as a double NOP and RNI from P+2. The instruction at that location is termed the 'Reject Instruction'.

Example:


If the connect code for the external device is 3002B, it is connected to channel 4, and it requires a data output of 21B to perform a certain task, what coding is necessary to perform the task.

Ans: CØN 3002B,4 UJP *-1 ENA 21B ØTAC 4 UJP *-2

The data sent to the external device is 0021B accompanied by a suppress assembly/disassembly control signal. This latter informs the device to ignore the upper 6 bits and recognize the 21B only.

20.8.4 Output Word from A





Bits 00-16 at P and P+1 should be loaded with 0's

Description:

This instruction transfers a 12-bit byte from the lower 12 bits of A (or all 24-bits of A) to an external equipment depending upon the type of I/O channel (3206 or 3207) that is used. The contents of A is not disturbed and is retained.

After outputting the information, main control proceeds immediately and RNI's at P+3. Should the input/output control for the specified channel in Block Control be busy, the instruction will act as a double NOP and RNI from P+2. The instruction at that location is termed the 'Reject Instruction'.

Note: Bits 18, 19 and 20 are all zeros when a 3206 data channel is used. If the operation with A involves the use of a 3207, these bits take on the following significance:

Bit 20 = always a "0"

Bit 19 = If bit 18 = "1", the state of bit 19 is of no consequence.

If bit 18 = "0", a "1" in bit 19 signifies backward operation. A "0" in bit 19 signifies a forward operation.

Example:

Assuming a remote typewriter connected to a data channel (not to be confused with the console typewriter) has a connect code of 5000B and is connected to channel 2, what code is necessary to cause that typewriter to perform a carriage return tab sequence of operations? The code for a carriage return is 77B and for the tab is 75B.

20.8.4 (cont.)

5000B,2 CØN Answer: UJP *-1 7775B **ENA** 2 **ØTAW** UJP *-2

The data transmitted to the typewriter is 7775B.

20.9 SENSING INSTRUCTIONS

20.9.1 Sense External Status

-	LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	1 1 1 1 1 1 1	EXS ×,·h
	·[#]>;* \$ \$(7:#	

23	18 17	7 15	14	12	11	00
77		2	С	h		x

ch = I/O channel designator, 0-7 x = external status sensing mask code

Description: When a peripheral equipment controller is connected to an I/O channel by the CØN (77.0) instruction, the EXS instruction can sense conditions within that controller. Twelve status lines run between each controller and its I/O channel. Each line may monitor one condition within the controller, and each controller has a unique set of line definitions. To sense a specific condition, a "l" is placed in the bit position of the status sensing mask that corresponds to the line number. When this instruction is recognized in a program, RNI at address P + 1 if an external status line is active when its corresponding mask bits are "l". RNI at address P + 2 if no selected line is active.

Status Codes: Following are the status response codes for magnetic tape and card reader:

	MAGNETIC TAPE STATUS CODES		3248 CARD READER STATUS CODES
XXXI	Ready	XXX1	Ready
XXX2		XXX2	Busy
2121212	Read/Write Control	XXX4	
	and/or Unit Busy		File Card Read
XXX4	,	XX2X	
XXLX		MLZM	Stacker Full or
XX2X			Jam
XX4X	-	XX4X	-
	Density 20 bit**	X1XX	
X2XX	2l bit**	VIVV	End of File Switch On
ΛΖΛΛ		X2XX	
	** 00 = 200 bpi	ΛζΛΛ	
	01 = 556 bpi	W/.WW	Interrupt Present
	10 = 800 bpi	X4XX	- - - - -
/	11 = undefined	1 171717	Interrupt Present
	Lost Data	1XXX	
	End of Operation		Operation Interrupt
2XXX		_	Present
	Longitudinal	2XXX	
	Parity Error		Preread Error or
4XXX	Reserved by another		Illegal Suppress
	control (multiple		Assembly
	channel controllers		
	only)		

20.9.1 (cont.)

Comments:

Refer to the 3000 Series Computer Systems Peripheral Equipment Codes manual, publication no. 60113400 for a complete list of status response codes.

Example:

The example below accomplishes the following:

- a) Connects the card reader on channel 0.
- b) Checks the status of the card reader. If busy it waits until it becomes not busy.
- c) Initiates reading of a card at the card reader and transfer of the data read to memory.
- d) Waits until the INPUT is complete.

CØN	3000B,0	CONNECT CARD READER
UJP	*-1	
EXS	2B,0	SENSE BUSY
UJP	*-1	LOOP IF BUSY'
INPW	O, INBUFF, INBUFF+20	INITIATE INPUT
UJP	*-2	
EXS	2B,O	SENSE BUSY
UJP	*-1	LOOP UNTIL DONE
•		
•		
•		
UCS		

20.9.2 Copy External Status and Interrupt Mask Register

g1174444		A
LOCATION	GPERATION MODIFIERS ADDRESS FIELD	
	COPY	/ .
		and also
111912 4 114 1		14 - 5 "

23	18	17	15	14	12	11		00
77	,	:	 2	٥	:h		0000	

ch = I/0 channel designator, 0-7

Description:

This instruction performs the following functions:

- (1) The external status code from I/O channel ch is loaded into the lower 12 bits of A. See EXS instruction.
- (2) The contents of the Interrupt Mask register are loaded into the upper 12 bits of A.
- (3) RNI from address P + 1.

Examples:

If the INTERRUPT MASK REGISTER is 0032_8 , and the external status on channel $1=1004_8$, what will be in A after execution of the following instruction?

C**Ø**PY

Answer:

- (a) A is cleared.
- (b) Contents of INTERRUPT MASK REGISTER put in upper 12 bits of A.
- (c) External status on channel 1 put in lower 12 bits of A.
 - (A) = 00321004

LOCATION	OPERATION, MODIFIERS ADDRESS FIELD
	INTS x,ch
1 (2 : 3 : 4 : 4 4 : 7 : 8	* ind techte figtige tag tiebta, fing techtorist staltalite tem reites, techtorist tag tag faet zeiteilan.

23	18	17	15	14	12	11_		<u>00</u>
	77		4	ď	:h		x	

ch = I/O channel designator, 0-7 x = Interrupt sensing mask code

Description: Sense for the interrupt conditions listed in the following table. RNI from P+1 if an interrupt line is active corresponding to any "1" bit in the mask. If none of the selected lines are active, RNI from $P\,+\,2$. Internal interrupts are cleared as soon as they are sensed. External interrupts are cleared by connecting the unit and executing one of the SEL functions controlling peripheral interrupts.

INTERRUPT SENSING MASK BIT ASSIGNMENTS

Mask Bit	Mask Code	T
Position	X	Interrupt Condition Represented
00 01	0001 0002	I/O Equip # 0 on designated channel
02	0004	2 I 2 External
03	0010	J
04	0020	4 Interrupts
05	0040	5
06	0100	6
07	0200	7
08	0400	Real-time Clock
09	1000	Exponent Overflow/Underflow (flt pt)
		and BCD Fault Internal
10	2000	Arithmetic Overflow Interrupts and Divide Fault (integer)
11	4000	Search/Move Completion

i) If there is an interrupt line active on channel 2, which Examples: instruction will be executed after executing the INTS instruction in the following section of code?

	INTS UJP UJP	4B,2 INTADD NØINT	
Answer:	UJP	INTADD	if equip. nr. 4 generated the interrupt, else UJP NØINT

ii) The contents of the A register = 37777777 and the instruction executed is:

INA

An arithmetic overflow is generated. What code is necessary to sense this fact?

Answer:	INTS	2000В	
	UJP	overflow-routine non-overflow next instruction	(P+1) (P+2)

Note: The "ch" designator is required only when sensing external interrupts originating on a channel.

	. IF LRATION, MODIFIERS	ACORESS FIELD
	TNC	
		×, ch
è	and be about the fabrication	AP ATTEMPT OF A SEASON PROPERTY OF A STATE OF A SEASON AND A SEASON AN

23	18	17	15	14	12	11	00
7	7	.;	3	С	h		x

ch = I/O channel designator, 0-7

x = Internal Status Sensing Mask Code

Description:

Sense for the internal conditions listed in the following table. RNI from P+1 if an internal condition is present corresponding to any "1" bit in the mask. If none of the selected conditions are present, RNI from P+2. Internal conditions are cleared as soon as they are sensed, except when they are related to channel "ch".

INTERNAL STATUS SENSING MASK BIT ASSIGNMENTS

Mask Bit	Mask Code	
Position	x	Internal Condition Present
00	0001	Parity Error
01	0002	Read Active
02	0004	Write Active Channel
03	0010	External (controller) Reject Control
04	0020	Internal (no response) Reject
05	0040	Illegal Write Main Control
06	0100	CØN or CØN and SEL executed
_		and channel currently not busy
07	0200	Block Control Interrupt waiting Channel
		Write: Buffer complete Control
		Read: Buffer complete or
		End of Record at peripheral
80	0400	Exponent Overflow/Underflow fault
		(flt pt option)
09	1000	Arithmetic Overflow fault
		(main arithmetic section) Main Control
10	2000	Divide fault
		(main arithmetic or flt pt opt)
11	4000	BCD fault (BCD option)

Example:

The following coding example sums a table of 50 numbers. It detects and corrects for arithmetic overflow using the INS instruction.

	ENI	49,1	SET LØØP INDEX TØ MAX NR - 1
	ENA	0	CLEAR THE ACCUMULATOR
LØØP *	ADA	TABLE,1	ADD NEXT ENTRY OF TABLE TO THE ACCUMULATOR
	INS	1000B,0	WAS THERE ARITHMETIC ØVERFLØW
	UJP	ø۷	YES, JUMP TØ CØRRECT AT LØCATIØN
*			ØV
	IJD	LØØP,1	AFTER LAST TIME THRØUGH LØØP -
*		•	NØ DECREASE B1 BY 1 ØR JUMP
*			TØ LØØP
FINIS	SHAQ	- 24	CØNVERT 24 BIT SUM TØ 48 BITS
	ADAQ	SUM48	ADD CONVERTED SUM TO 48 BIT
*	•		ACCUMULATØR
	UJP	EXIT	
øν	SHAQ	-24	CØRRECT FØR ARITHMETIC ØVERFLØW
	XØA,S	- 0	BY COMPLEMENTING THE SIGN
	A DAQ	SUM48	ADD CØNVERTED SUM TØ 48 BIT
*	•		ACCUMULATØR
	STAQ	SUM48	
	ENA	0	CLEAR 24 BIT ACCUMULATØR
	IJD	LØØP,1	DECREASE B1 AND JUMP TØ LØØP
	UJP	FINIS	The state of the s
SUM48	DECD	0	
TABLE	BSS	50	

Exercise:

Assuming that data channel 5 is busy at the moment, determine if the operation in progress is a Read or a Write. Write the coding required to do this check.

20.9.5 Copy Internal Status and Interrupt Mask Register

LOCATION	OPERATION MODIFIERS ADDRESS FIELD	
	CINS &	

23 1	B 17 15		11 00)
77	3	ch	0000	

ch = I/O channel designator, 0-7

Description:

The CINS instruction performs the following functions:

- 1) The internal status information (see table in Section 20.9.4) is loaded into the lower 12 bit positions of the A register.
- 2) The contents of the Interrupt Mask register are loaded into the upper 12 bit positions of the A register.
- 3) RNI from P+1

Example:

If the Interrupt Mask register contains 01218 and the internal status is 01118, what will be in the A register after execution of the following instruction?

CINS

1

Answer:

- a) The A register is cleared
- b) The contents of the Interrupt Mask Register is copied in the upper 12 bits of A.
- The current internal status is copied in the lower 12 bits of A.

 $(A) = 01210111_8$

Exercises: i) If the Interrupt Mask register contains 74008 and a parity error has occurred on the channel for data channel 6 (called a "transmission parity error"), what will be in A after the execution of:

> 6 CINS

ii) If the Interrupt Mask register contains 04038 and the reject instruction following a SEL was executed, what coding would be necessary to determine the cause of the reject. (Remember there are three sources of SEL rejects 1) channel busy, 2) function illegal, and 3) function not recognized)

20.9.6 Comments on Internal Status and the Interrupt Mask Register

At first glance, it appears that the INTS and INS instructions perform essentially the same function with relation to internal conditions. However, there is one important difference and that is the INTS instruction needs both the condition and the interrupt mask bit set to get a match. The INS instruction senses the internal condition without the necessity of having the interrupt mask register bit set.

20.10 CONSOLE TYPEWRITER INPUT/OUTPUT

20.10.1 General Description

The 3192 Console Typewriter is an on-line input-output (I/O) device; i.e., it requires no connection to a communication channel and no function codes are issued. The typewriter receives output data directly from storage via the lower 6 bits of the Data Bus. Inputs to storage are handled in the same manner.

The console typewriter consists of an electric typewriter and a typewriter control panel mounted on a desk console.

Used in conjunction with block control and the Register File, the typewriter may be used to enter a block of internal binary-coded characters into storage and to print out data from storage. The two storage addresses that define the limits of the block must be stored in the register file prior to an input or output operation. Register 23* contains the initial character address of the block, and register 33 contains the last character address, plus one. Because the initial character address is incremented for each storage reference, it always shows the address of the character currently being stored or dumped. Output operations occur at the rate of 15 characters per second. Input operations are limited by the operator's typing speed.

*The upper seven bits of registers 23 and 33 should be "0".

20.10.2 Operation

The general order of events when using the console typewriter for an input or output operation is:

- 1) Set tabs, margins and spacing. Turn on typewriter.
- 2) Clear
- 3) Check status
- 4) Type out or type in

20.10.2.1 Set tabs, margins, and spacing

All tabs, margins, and paper spacing must be set manually prior to the input or output operation. A tab may be set for each space on the typewriter between margins.

20.10.2.2 Clear

There are three types of clears which may be used to clear all conditions (except ENCODE FUNCTION) existing in the typewriter control. These are:

1) Internal Clear or a Master Clear

This signal clears all external equipment, the communications channels, the typewriter control, and sets the typewriter to lower case.

20.10.2.2 (cont.)

2) Clear Channel, Search/Move Control, or Type Control instruction (77.51).

This instruction selectively clears a channel, the S/M control, or, by placing a "l" in bit 08 of the instruction, the typewriter control, and sets the typewriter to lower case.

3) Clear Switch on typewriter.

This switch clears the typewriter control and sets the typewriter to lower case.

20.10.2.3 Status Checking

The programmer may wish to check the status of the type-writer before proceeding. This is done with the Pause instruction. Status response is returned to the computer via two status lines.

The typewriter control transmits two status signals that are checked by the Busy Comparison Mask using the Pause instruction. These status signals are:

Bit 09 Type Not Finish Bit 10 Type Not Repeat

An additional status bit appears on sense line 08. This code is Type Busy, and is transmitted by block control in the computation section when a typewriter operation has been selected. If the programmer is certain of the status of the typewriter, this operation may be omitted.

20.10.2.4 Type In and Type Load

The Set Type In instruction or pressing the TYPE LOAD switch on the console or typewriter permits the operator to enter data directly into storage from the typewriter. When the TYPE LOAD indicator on the console or typewriter glows, the operator may begin typing. The Encode function switch must be depressed to enable backspace, tab, carriage return, and case shifts to be transmitted to the computer during a typewriter input operation.

Input is in character mode only. As each character is typed, the information is transmitted via the Data Bus to the storage address specified by block control. This address is incremented as characters are transmitted. When the current address equals the terminating address, the TYPE LOAD indicator goes off and the operation is terminated. Data is lost if the operator continues typing after the TYPE LOAD indicator goes off.

20.10.2.5 Type Out and Type Dump

The typewriter begins to type out when the computation section senses a Set Type Out instruction or the operator presses the TYPE DUMP switch on the console or typewriter. Single 6-bit characters are sent from storage to the typewriter via the lower 6 bits of the Data Bus. When the current address equals the terminating address, the TYPE DUMP indicator goes off and the operation is terminated.

During a Type Out operation, the keyboard is locked to prevent loss of data in the event a key is accidentally pressed.

20.10.3 Typewriter Console Switches and Indicators

The following table shows the function of each switch and indicator for the console typewriter.

Name	Switch (S) Indicator (I)	Description
HIGH TEMP	I	This indicator glows when the ambient temperature within the typewriter cabinet exceeds 110°F.
BUSY	I	This indicator shows that the TYPE LOAD or TYPE DUMP switch has been pressed and the operation is in progress.
POWER ON	I	This indicator shows that power is applied to the typewriter.
TYPE DUMP	S & I	This switch is in parallel with the TYPE DUMP switch on the main console and causes the computer to send data to the typewriter for print-out. It is a momentary contact switch that is illuminated until the last character in the block has been print printed or the CLEAR button is pressed.
TYPE LOAD	. S&I	This switch is in parallel with the TYPE LOAD switch on the main console and allows the computer to receive a block of input data from the typewriter. The TYPE LOAD indicator remains on until either the FINISH, REPEAT or CLEAR button is pressed, or until the last character of the block has been stored. If the program immediately reactivates the typewriter, it may appear that the light does not go off.
REPEAT	S & I	This switch is pressed during a Type Load operation to indicate that a typing error occurred. This switch deactivates busy sense line 10 (see PAUS instruction). If the computer does not respond, this light remains on.
FINISH	S & I	This switch is pressed during a Type Load operation to indicate that there is no more data in the current block. This action is necessary if the block that the operator has entered is smaller than the block defined by registers 23 and 33. This switch also deactivates busy sense line 09. If the computer does not respond, this light remains on.
NTERRUPT	S & I	This switch is in parallel with the MANUAL INTERRUPT switch on the console and is used to manually interrupt the computer program.
NCODE UNCTION	S & I	This switch enables the typewriter to send to storage the special function codes for backspace, tab, carriage return, upper-case shift, and lower-case shift.
LEAR	S & I	This switch clears the typewriter controls and sets the typewriter to lower case but does not cancel Encode Function.

20.10.4 Character Codes

The following table lists the internal BCD codes, typewriter print-out and upper- or lower-case shift that applies to the console typewriter. All character transmission between the computation section and the typewriter is in the form of internal BCD. The typewriter logic makes the necessary conversion to the machine code.

Note: Shifting to upper case (57) or lower case (32) is not necessary except on keyboard letters where both upper and lower case is available. The standard type set for the 3192 has two sets of upper case letters and no lower case letters. This eliminates the need for specifying a case shift.

Those characters that are strictly an upper or lower case character are not affected by the case currently selected. Case selection only affects those characters that may be printed in either upper or lower case.

CONSOLE TYPEWRITER CODES

Print-out	Case	Internal BCD Code	Print-out	Case	Internal BCD Code
0 1 2 3 4 5 6 7 8 9 + = " ; ; + A B C D E F G H I (Shift to LC)	L L L L L L L L L L L L L L L L L U U U U U O O O C L U U U O O C L U U U O O C L U U O C L U U O C L U U U U U U U U U U U U U U U U U U	00 01 02 03 04 05 06 07 10 11 12 13 14 15 16 17 20 21 22 23 24 25 26 27 30 31 32 33 34 35 36 37	- J K L M N O P Q R ° (degree) * # % (Shift to UC) (Space) / S T U V W X Y Z & , ((Tab) (Backspace) (Carriage Return)	L U or L	40 41 42 43 44 45 46 47 50 51 52 53 54 55 56 67 60 61 62 63 64 65 66 67 70 71 72 73 74 75 76 77

20.10.5 Input/Output Instructions

20.10.5.1 Set Console Typewriter Input

LOCATION	_	OPERATION, MODIFIERS ADDRESS FIELD
		CTI
118181816141718	ļ.	

23	18	17	12	11				C	0	į
77			75							

Bits 00 - 11 should be loaded with zeros

Description:

This instruction, like the TYPE LOAD switch, permits a block of data to be entered into storage as soon as the Type Load indicator lights. If a block of data smaller than the one defined by registers 23 and 33 is to be typed, the FINISH switch should be depressed when the typing is completed. If more data is entered than the defined block can hold, the excess data is lost. If a typing error occurs, the REPEAT button should be depressed, the typewriter input operation is terminated and the appropriate status bits (09 and 10) may be sensed with the PAUS instruction.

Example:

The below example illustrates initiating a typewriter INPUT. The INPUT data is to be stored in address INBUFF through INBUFF \pm 12.

	ECHA	INBUFF	
	TAM	23B	SET R.F. LØCA 23 TØ FCA
	INA	13	
	TAM	33B	SET R.F. LØCA 33 TØ LCA+1
	CTI		INITIATE TYPEWRITER INPUT
	•		
	•		
	•		
	UCS		
INBUFF	BSS,C	13	

20.10.5.2 Set Console Typewriter Output

LUCATION	OPERATION, MODIFIERS AUDRESS FIELD
	CT9
	1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0

23	18 17	12 11	00
77	70	6	

Bits 00 - 11 should be loaded with zeros

Description:

This instruction, like the TYPE DUMP switch, causes the typewriter to print out the block of data defined by the character addresses in registers 23 and 33.

Note: The CTI and CTO instructions are mutually exclusive. Any attempt to execute one while the other is being executed will be ignored by the computer. Typewriter busy should be checked before these instructions are used and before registers 23 and 33 are altered.

Example:

The following example illustrates initiating a typewriter OUTPUT. The OUTPUT will be from address ØUTBUFF through ØUTBUFF+15.

	ECHA	ØUTBUFF			
	TAM	23B	SET R.F.	LØCA 23 TØ	FCA
	INA	16			
	TAM	33B	SET R.F.	LØCA 33 TØ	LCA+1
	стø		INITIATE	TYPEWRITER	ØUT PUT
	•				
	•				
	•				
	UCS				
Ø UTBUFF	BSS,C	16			

20.10.5.3 Pause Instruction (as used with Console Typewriter Instructions)

(OCATION	OPERATION, MODIFIERS	AGORESS FIFLD	
	PAUS	×	
11815:41615:418	nisti utuk endisitise		

23	18	17	15	14	12	11		00
77		6	3				x	

Bits 00 - 11 should be loaded with zeros

Description:

This instruction allows the program to halt for a maximum of 40 ms if a condition (excluding typewriter-see note) defined by the pause sensing mask exists. If a "l" appears on a line that corresponds to a mask bit that is set, the count in P will not advance. If the advancement of P is delayed for more than 40 ms, a reject instruction is read from address P + 1. If none of the lines being sensed is active, or if they become inactive during the pause, the program immediately skips to address P + 2. If an interrupt occurs and is enabled during a PAUS, the pause condition is terminated, the interrupt sequence is initiated and the address of the PAUS instruction is stored as the interrupted address.

Note: If either bit 08, 09 or 10 (or any combination of these bits) is set and the sensed condition exists, a pause will not occur and the instruction at P+1 is read up immediately. If these bits are set but the condition(s) does not exist,

the program immediately skips to P+2. For all other bits, the normal PAUS routine is followed.

PAUSE Sensing Mask Table

Mask Bit	Mask Code	Condition	Notes
00 01 02 03 04 05 06	0001 0002 0004 0010 0020 0040 0100 0200	I/O channel O Busy 1 2 3 4 5 6 7	Channel Read or Write operation in progress, or the external Master Clear logic within the channel is set.
08 09 10 11	0400 1000 2000 4000	Typewriter BUSY Typwrtr NOT FINISH Typwrtr NOT REPEAT Search/Move control BUSY	Typewriter input or output in progress FINISH switch not depressed REPEAT switch not depressed Search or Move operation in progress

Examples: i) This example initiates and waits until a typewriter OUTPUT is complete.

	ECHA	Ø UTBUFF
	TAM	23B SET R.F. LØCA 23 TØ FCA
	INA	16B
	TAM	33B SET R.F. LØCA 33 TØ LCA+1
	CTØ	INITIATE TYPEWRITER ØUTPUT
	PAUS	400B WAIT UNTIL OUTPUT IS COMPLETE
	UJP	*-1
	•	
	•	
	•	
	UCS	
Ø UTBUFF	BCD,C	16, THIS IS THE END

ii) Study the following example and determine what it will do.

```
*
            PAUS
                       400B
            UJP
                       *-1
            ECHA
                       INBUF
            TAM
                       23B
            INA
                       80
            TAM
                       33B
            CTI
            PAUS
                       400B
           UJP
                       *-1
           ECHA
                       CR
           TAM
                      23B
           INA
                      1
           TAM
                      33B
           CTØ
           FAUS
                      400B
           UJP
                      *-1
           ECHA
                      INBUFR
           TAM
                      23B
           INA
                      10
           TAM
                      33B
           CTI
           UJP
                      ELSE
*
          BSS,C
INBUF
                      80
CR
           ØCT
                      -0
INBUFR
           BSS,C
                     10
          etc.
```

It looks like the program will do an input, then a carriage return and then call for more input. If the first input is terminated by a REPEAT or FINISH, and 1) few or no characters were inputted or 2) if the operator is slow in getting his finger off the switch, then the second input will be terminated before he has a chance to type any further characters.

Verify this for yourself by studying the actions listed on the next page. The key is that the CTI can be initiated during the 50msec interval following the end of a type-out as the PAUS 400B senses buffer busy not typewriter busy.

Note: Some programs use the REPEAT and FINISH switches as self clearing sense switches. This use is possible but is not recommended except under controlled conditions. The reason for this will be evident when the actions of the REPEAT and FINISH switches and PAUS instruction are studied below.

REPEAT or FINISH switch depressed

Typewriter NOT busy and not in the 50msec interval following a type-out operation

Action: Set REPEAT or FINISH status bit, turn on light

Typewriter executing a type-out or in the 50msec interval following a type-out operation

Action: None

Typewriter waiting for type-in

Action: Set REPEAT or FINISH status bit, turn on light

and terminate type-in.

End of 50msec interval at end of type-out operation and REPEAT or FINISH switch being held down

Typewriter not busy.

Action: Set REPEAT or FINISH status bit, turn on light

Typewriter busy with new output

Action: None

Typewriter busy with type-in

Action: Set REPEAT or FINISH status bit, turn on light and terminate type-in.

At any time when the REPEAT or FINISH light is on and status bit set and the REPEAT or FINISH switch is being held down.

REPEAT or FINISH being sensed by PAUS instruction

Action: Clear REPEAT or FINISH status bit and turn off light. (Switch must be released and depressed again to reset) RNI at P+2, where otherwise it would be P+1.

Exercise:

Write a subroutine that will output a carriage return and then tab the console typewriter. Then initiate a type-in of 1 character and wait until that character is received or a NOT busy, repeat or finish condition arises. Clear repeat and/or finish if present.

INTERRUPTS

- 21.1 INTERRUPTS USING CIC
- 21.2 INTERRUPTS WITHOUT USING CIC
- 21.3 I/O USING CIC
- 21.4 INTERRUPT MASK REGISTER BIT ASSIGNMENTS
- 21.5 CIT ASSIGNMENTS

Description: There are twelve groups of conditions for which, when one or more of these conditions occur, the programmer may wish to jump to a special sequence of coding, and upon completion of that task, resume processing in his original task. Processing in this manner is called "interrupt processing".

> The twelve groups of conditions mentioned above are listed in the table "Interrupt Mask Register Bit Assignments" in Section 21.4 at the end of this discussion. This register (IMR) is set by the programmer.

In addition to the IMR, there are twelve flip-flops, each representing one of the conditions specified by the IMR. (Schematically, we may consider this as a 12-bit Interrupt Register.) When one of the 12 interruptible conditions occurs, the hardware sets the corresponding flip-flop in this Interrupt Register. If the corresponding bit has been set by the programmer in the IMR (and the interrupt system is enabled), interrupt processing will take place. The programmer must have previously placed the address of his interrupt routine in the CIT table.

Example:

Add the integers in BUF thru BUF+99. If an arithmetic overflow occurs, jump to a routine to process the sum using double-precision (48-bit) integer arithmetic.

SUM START	EXT ØCT UJP ENA ENI SWA SSIM EINT •	CIT 0,0 ** INTADD 7,1 CIT,1 2000B	*STØRE ADDRESS ØF INTERRUPT RØUTINE AT CIT+7 (SEE TABLE 21.5) *SET IMR FØR ØVERFLØW CØNDITIØN *ENABLE INTERRUPT SYSTEM
	•		
	ENA ENI	0 99 , 1	
Løø₽	ADA	BUF,1	*ADDITIØN LØØP
	IJD	LØØP,1	
*			*100 WØRD SUM IS COMPLETE, EXCEPT
	SHAQ	-24	*ADD 24-BIT SUM IN *A*
	ADAQ	SUM	TØ 48-BIT SUM IN *SUM*
	STAQ	SUM	*ALL DØNE
	•		
	•		
	•		
	UJP,I	START	
*	001,1	orium.	
INTADD	UJP	**	
	ENA	INTADD	1
	SWA	CIT,1	2
	ENI	1,1	3
	LDA	CIT,1	4
	SHAQ	-24	5
	XØA,S	- 0	6
	ADAQ	SUM	7
	STAQ	SUM	8
	ENA	0	9
	STA	CIT,1	10
	UJP,I	INTADD	11

21.1 (cont.1)

Discussion of START+1 thru START+5 in the Example

Initialization to recognize an interrupt

- (1) the programmer must store the address of his interrupt routine in the lower 15 bits of the proper CIT table entry (See Section 21.5) and
- (2) the programmer must set the proper bit or bits in the IMR (See Section 21.4) and
- (3) the programmer must enable the interrupt system.

Discussion of INTADD in the Example

Processing the interrupt

- (1)* and (2)* CIC replaced the lower 15 bits of CIT+7 with the address of ABNORMAL. If we expect to get another overflow interrupt, we must again place the address of our routine in CIT+7. (Location CIT+7 applies only to overflow interrupts, see Section 21.5)

 Upon entry to an interrupt routine, CIT+(B¹) equals the CIT table location where the FWA of an Interrupt Routine must be placed to process the next interrupt of the type currently being processed.
- (3)*and (4)* CIC stored the original contents (the "overflowed" sum) of the A register at CIT+1 and used the A register for its own purposes. We are merely reloading the original A register contents at the time of overflow so that we may process the overflow.
- (4)*, (5)*, (6)*, (7)* & (8)* are processing the overflow condition into a 48-bit true sum.
- (9)* and (10)* Since CIC will load the A register from CIT+l before returning to our original sequence, we must place into CIT+l whatever quantity we desire to be in the A register upon re-entry into our original sequence.
- (11)* Returns us to CIC for housekeeping (explained later) before giving control to our original sequence.

Discussion of the Function of CIC

When an interruptible condition occurs, the Interrupt Register is compared to the IMR. If (a) any corresponding bits are set, and (b) the interrupt system has been enabled, then

- (1) the interrupt system is disabled,
- (2) the address of the instruction which would normally be executed next is stored in the lower 15 bits of absolute location 4.
- (3) an identifying code is stored in the lower 12 bits of location 5 and,
- (4) control is given to location 5.

Here are the contents of locations 4, 5 and 6 under SCOPE.

00004	UJP	**
00005	NØP	0
00006	II.IP	CTC

^{*}refers to card number in INTADD example

Since the hardware gives control to location 5 (which is a no operation instruction), we see that a jump is made to CIC (Central Interrupt Control). CIC saves the contents of A, Q, B^1 , B^2 and B^3 at CIT+1 thru CIT+5. Since an identifying code (showing what condition caused the interrupt) is set in the lower 12 bits of location 00005, CIC knows which entry in CIT contains the address of the programmers interrupt routine.

CIC does a return jump to this location, and the programmer's interrupt routine (INTADD in this example) is executed. The interrupt routine does a UJP or UJP,I thru it's entry point to return to CIC when finished.

CIC restores the five registers, clears the flip-flop which was set by the interruptible condition (arithmetic overflow in the example), enables the interrupt system, and does an indirect jump through location 00004. The indirect jump gives control back to the instruction which was originally interrupted.

21.2 INTERRUPTS WITHOUT USING CIC*

If the programmer does not wish to use CIC to help in the processing of his interrupt, then at location 00006 he must store a jump to the address to which he wishes control to be given. In his interrupt routine, he must save and restore his registers (if his routine uses them) if he wishes them to have their original contents upon return to the main coding. He must also clear the flip-flop in the Interrupt Register (with an INCL instruction) which signalled the interruptible condition. His last two instructions should be:

EINT UJP,I 4

If the last instruction in the interrupt routine does not use an indirect reference to location 00004, the control may never return to the main program. This is because after an EINT he is assured of being able to execute only one more instruction before the interrupt system can recognize another interrupt. Hence, if he has programmed for interrupt on more than one condition and another is present, the computer will interrupt again and the address portion of the jump instruction at location 00004 will be changed before it can be executed. Since it will be changed to 00004, the computer will stall on a jump to location 00004 after completing the processing of the current interrupt.

*Since CIC is essential for SCOPE I/O, it is assumed that no I/O will be done or that SCOPE isn't being used.

21.3 I/O USING CIC (See also Section 16.2.3)

In programming for I/O interrupts using CIO, all the housekeeping is done by CIO. (The programmer does not EINT, SWA CIT+k, or set the IMR with an SSIM). CIO actually uses CIC in the same manner that we indicated, but the programmer does not have to attend to the details.

Example: Suppose that we wish to output 30 words from locations BUFF thru BUFF+29 onto logical unit 15. We wish to continue executing instructions while the output is going on. However, as soon as the output is finished, we wish to be "interrupted" and process a special sequence of code, then return to our original sequence.

21.3 (cont.)

Following is the code that will accomplish the task:

	EXT	CIØ	
START	UJP	**	ENTRY
D 2111	•		
	•		
	•		<u>.</u>
	ENA	0	SET BUFFER FLAG TØ BUSY
	STA	BFRBUSY	
	RTJ	CIØ	GØ TØ CIØ TØ -
	02	15,2	WRITE WITH INTERRUPTS ØN LU 15
	UJP	REJECT	WRITE REJECTED IF WE GET HERE
	40	BUFF	START ØUTPUTTING FRØM LØCA *BUFF* ØUTPUT 30 WØRDS
) O	30 INTADD	WHEN INTRPT ØCCURS, GØ TØ INTADD
	0	INTADD	WHEN INITED POCORD, GP 19 INITED
	•		
	•		
	•		
	SSH	BFRBUSY	NEED *BUFF* NØW, IS WRITE DØNE
	UJP	*-1	IF NØ, LØØP UNTIL FINISHED
			IF YES, CONTINUE
	•		
	•		
	UJP,I	START	PRØGRAM ALL DØNE, EXIT TØ SCØPE
*			42 SUMPROVING DAMETHE
INTADD	UJP	**	ENTRY PØINT ØF INTERRUPT RØUTINE
	•		
	•		Interrupt Routine
	•		Special Sequence of Code
	•		Special Sequence of Goto
	•		1
	ena,s	-0	SET BUFFER FLAG TØ NØT BUSY
	STA	BFRBUSY	Dar Borran Lanc of the state
	UJP,I	INTADD	EXIT TØ MAIN CØDE VIA CIC
*	,	-	·
BFRBUSY	ØCT	-0	+0 = BUSY, -0 = NØT BUSY

21.4 INTERRUPT MASK REGISTER BIT ASSIGNMENTS

Mask Bit Positions	Mask Codes (x)	Interrupt Conditions Represented
00	0001	I/O Channel O (includes interrupts generated within the channel and external equipment interrupts)
01	. 0002	1
02	0004	2
03	0010	3
04	0020	4
05	0040	5
06	0100	6
07	0200	7
08	0400	Real-time clock
09	1000	Exponent overflow/underflow & BCD faults
10	2000	Arithmetic overflow & divide faults
11	4000	Search/Move completion
		<u>-</u>

21.5 CIT ASSIGNMENTS


Symbolic Location	Content	Explanation
CIT+0	Interrupt flag	If +0, no interrupt occurred.
		If -0, interrupt occurred.
+1 +2 +3 +4 +5	(A) (Q) (B ¹) (B ²) (B ³)	Contents of these registers when last interrupt occurred. Registers are restored from here on exit from CIC.
+6 +7 +8 +9 +10 +11 +12 +13	Real Time Clock Arithmetic Overflow Divide Fault Exponent Overflow BCD Fault Search/Move Manual Interrupt Associated Processor Interrupt	Initially contains UJP ABNØRMAL. Address of user interrupt routine stored in CIT by user main program when the corresponding interrupt is selected.
+14 +15 +16 +17 +18 +19 +20 +21	Channel 0 Channel 1 Channel 2 Channel 3 Channel 4 Channel 5 Channel 6 Channel 7	Initially contains UJP ABNØRMAL. Address is set by CIO when interrupt is selected. Table is extended for each pair of channels added to the hardware configuration*.

^{*} The Central Interrupt Table (CIT) length varies from 15 to 21 entries and is dependent on the number of channels present in the system. The length of the table is specified at the time CIC is assembled under COMPASS prior to doing a PRELIB (Prepare library tape) of SCOPE.

SAMPLE COMPASS PROGRAMS

SEQUENCE,001	AlT
EXAMPLES	A1B - A9T
EXAMPLE 20 (AVERAGE)	A9B - A10B
EXAMPLE 19A(GR2PR)	A11T - A12T
EXAMPLE 21 (CODE)	A12B - A13B
EXAMPLE 22 (MEQ.TEST)	A14T - A15T
EXAMPLE 23 (TY.OUT)	A15B - A16B
EXAMPLE 24 (DEMO)	A17T - A21B
EXAMPLE 25 (MTDRIVER)	A22T - A24B
MAC	A25T - A26B
EXAMPLE 26 (COPY)	A27T - A29T
CIC VERSION SI 0.0	A29B - A31B
MTMTCIO	A32T - A33B
TYPEIN	A34T - A35T
SORT	A35B - A36B
TYPEOUT	A37T - A38T
FLOATF	A38B - A39B
CRDTP	A40T - A41B
MTMT	A42T - A43B
CVTBCDB	A44T - A45T
CVTBBCD	A45B - A46B
SEQUENCE,002	A47T
IDC	A47B - A48T
- Load/Snap/Run -	A48B
- Memory Map -	A49T
- Snap Number 1 & 2 -	A50T - A50B
SEQUENCE,003 and OCC's	A51T
- Memory Map -	A51B

- Memory Dump -



A52B

```
SEQUENCE + 001
JOB, .,,
COMPASS, L,R
                                                                                                                   11/21/66 PAGE 1
  COMPASS-32 (2.1) EXAMPLES
    UNDEFINED SYMBOLS
SAM
SYM
SYMBOL
    MULTIPLY-DEFINED SYMBOLS GEORGE
    EXTERNAL SYMBOLS
BCOBOXS
FOPBOXS
    LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
```

```
THIS IS A LISTING OF THE CDC 3200 INSTRUCTION SET
CUMPASS-32
                                                         (2.1)
                                                                                                                                        EXAMPLES
                                                                                                                                                              DEFINITION OF OPERATION OPERATION OF OPERATION OPERATION OF OPERATION OF OPERATION OF OPERATION OPERATION OPERATION OPERATION OPPORT OF OPERATION OPERATION OPPORT OF OPERATIO
                                                                                                                                                                                              £Φ
                                                                                                                                                                                                                                       EQUAL
                                                                                                                                                                                                                                     EGUAL
NOT EGUAL
GHEATER THAN OR EGUAL TO
LESS THAN
INDIRECT ADDRESSING
SIGN EXTENSION
INTERRUPT
HACKWARD
HALF ASSEMBLY OR DISASSEMBLY
                                                                                                                                                                                               NE
                                                                                                                                                                                               GE
                                                                                                                                                                                                INT
                                                                                                                                                                                                                                        NO ASSEMBLY OR DISASSEMBLY
                                                                                                                                                              ----- DEFINITION OF TERMS, AND SYMBOLS -----
                                                                                                                                                                                                                                        THE #A# REGISTER
                                                                                                                                                                                                                                     THE #A# REGISTER

THE #Q# REGISTER

48 BIT REG , (A AND Q COMBINED RESPECTIVELY)

48 RIT REG , (Q AND A COMBINED RESPECTIVELY)

THE 48 BIT #E# REGISTER

LOWER 24 BITS OF #E#

UPPER 24 BITS OF #E#

OF #E#

UPPER 24 BITS OF #E#

UPPER 25 BIT (13 CMAR) #E OECIMAL# REGISTER. SAME AS

#E# BUT EXTENDED FROM 48 TO 32 BITS.

96 BIT REG , (A*, OAN) E COMBINED RESPECTIVELY)

ANY ONE OF THE THREE INDEX REGISTERS

INDEX REGISTER THO OALY

INDEX REGISTER THO OALY

ABIT #D# REGISTER

INTERRUPT MASK REGISTER
                                                                                                                                                                                               QΑ
                                                                                                                                                                                              EL
EU
EO
                                                                                                                                                                                               AGE
                                                                                                                                                                                                B
B1
                                                                                                                                                                                               H2
                                                                                                                                                                                               D
IMR
                                                                                                                                                                                               м
                                                                                                                                                                                                                                        15 BIT WORD ADDRESS
                                                                                                                                                                                                                                      17 BIT CHARACTER ADDRESS
FIRST SOURCE CHARACTER ADDRESS
FIRST DESTINATION CHARACTER ADDRESS
6 BIT REGISTER FILE ADDRESS
                                                                                                                                                                                              FSCA
FOCA
                                                                                                                                                                                                                                       S BIT OPERAND
6 BIT SEARCH CHARACTER
4 BIT OPERAND (BCD FIELD LENGTH)
CURRENT INSTRUCTION ADDRESS AS INDICATED BY THE P REG
                                                                                                                                                                                                                                        CONTENTS OF
                                                                                                                                                                                                                                      CONTENTS OF MEMORY LOCATION M
48 BIT CONTENTS OF MEMORY LOCATION M
68 BIT CONTENT OF MEMORY CHARACTER LOCATION R
24 BIT CONTENTS OF REG FILE LOCATION V
                                                                                                                                                                                                (M)
(M+M+1)
                                                                                                                                                                                                 (H)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         •
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         •
CUMPASS-32 (2.1)
                                                                                                                                      EXAMPLES
                                                                                                                                                                                                                                                                                                                                                                         11/21/66 PAGE
                                                                                                                                                                                              RNI
                                                                                                                                                                                                                                       READ NEXT INSTRUCTION
                                                                                                                                                                                                                                       MHERE DATA IS BEING STORED INTO PART OF A MEMORY LOCATION, THE REMAINDER OF THAT LOCATION REMAINS UNCHANGED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         ALL POSSIBLE OPERATION MODIFIERS ARE SHOWN WITH EACH
                                                                                                                                                                                                                                        MNEMONIC CODE . SEPARATED BY (.).
THERE IS NO ONDER . WHERE MULTIPLE MODFIERS ARE
                                                                                                                                                                                                                                       POSSIBLE. WING MODIFIERS ARE OPTIONAL AND CAN HE DROPPED BY ELEMINATING BOTH THE MODIFIER AND THE PRECEDING COMMA.
                                                                                                                                                                                                                                       I . S . INT . B . H . N .
                                                                                                                                                                                                                                      ON ALL CONDITIONAL JUMP AND SKIP INSTRUCTIONS . IF THE CONDITION IS NOT MET THEN RNI P+1
```

```
11/21/66 PAGE
                                                                                            EXAMPLES
             COMPASS-32
                                           (2.1)
                                                                                                        *****************
                                                                                                        ----- 3200 INSTRUCTION SET ------
                                                                                                                                                     LOAD CLASS
                                          20725252 20 1 25252 3
21725252 21 1 25252 3
22425253 22 1 05252 3
23425253 23 1 05252 3
24725252 24 1 25252 3
25725252 25 1 25252 3
26725252 26 1 25252 3
27725252 27 1 25252 3
54725252 27 1 25252 3
                                                                                                                                                                                                    (M) TO A
                              00000
                                                                                                                          LDA . I
                                                                                                                                                  M.B
                                                                                                                                                                                                   (M) TO Q
(M) TO Q
(M) TO Q
(M) TO A 05-00 . A 23-06 CLEARED
(M) TO Q 05-00 . Q 23-06 CLEARED
(M) COMPLEMENT TO A
(M**++1) TO AQ
(M**++1) TO AQ
(M) M(Q) TO A . M AND Q UNCHANGE
(M) [M(Q) TO B
                                                                                                                          LDA+I
LDQ+I
LQCH
LCA+I
LDAQ+I
LCAQ+I
                                                                                                                                                  м,В
                              00001
                                                                                                                                                  H.82
H.8
H.8
                              20000
                              00003
                              00005
                              00006
00007
                                                                                                                                                  M.R
                                                                                                                           LOL.I
                                                                                                                                                  M.B
M.B
                              00010
                                                                                                                                                     STORE CLASS
                              00011 40725252 40 1 25252 3
                                                                                                                           STAFI
                                                                                                                                                                                                    (A) TO M
                             00012 41725252 40 1
00012 41725252 41 1
00013 42425253 42 1
00014 43425253 43 1
00015 44725252 44 1
00016 45725252 45 1
                                                                                                                                                                                                                                                                                                                    .
                                                                                                                           STQ+I
SACH
SUCH
                                                                                                                                                                                                    (Q) TO M
                                                                                25252 3
05252 3
                                                                                                                                                  M.B
R.B2
                                                                                                                                                                                                   (W) TO M

(A 05-00) TO R

(W 05-00) TO R

(A 14-00) TO M 14-00

(AQ) TO M-M+1

(A 16-00) TO M 16-00

(B) TO M 14-00
                                                                              05252 3
05252 3
25252 3
25252 3
25252 3
                                                                                                                                                  R.BI
                                                                                                                                                                                                                                                                                                                    SWA,I
STAU,I
SCHA,I
                                                                                                                                                  M.B
                                           46725252 46 1
47725252 47 1
                                                                                                                                                                                                                                                                                                                   •
                                                                                                                           STIOI
                                                                                                                                                   M.B
                              00020
                                                                                                                                                    24 BIT ARITH CLASS
                                                                                                                                                  M.B
                                                                                                                                                                                                   (A) + (M) TO A
                              00021 30725252 30 1 25252 3
                                                                                                                           ADA . I
                                                                                                                                                                                                   (A)=(M) TO A
(A)=(M) TO QA
(AQ)/(M) TO A . REMAINDER TO Q
                                           31725252 31 1 25252 3
50725252 50 1 25252 3
51725252 51 1 25252 3
                                                                                                                           SBA+I
MUA+I
DVA+I
                              00022
                                                                                                                                                  M.B
                                                                                                                                                                                                                                                                                                                    •
                                                                                                                                                   4.B
                              00024
                                                                                                                                                                                                    (A)+(M) TO M . A IS UNCHANGED
                              00025 34725252 34 1 25252 3
                                                                                                                           RAD . I
                                                                                                                                                  4.B
                                                                                                                                                     48 BIT ARITH CLASS

        00026
        32725252
        32 1
        25252
        3

        00027
        33725252
        33 1
        25252
        3

        00030
        56725252
        56 1
        25252
        3

        00031
        57725252
        57 1
        25252
        3

                                                                                                                                                  4.B
                                                                                                                                                                                                   (AQ) + (M.M+1) TO AQ
                                                                                                                           AUAQ. I
                                                                                                                                                                                                    (AQ) = (M,M+1) TO AQ
(AQ) * (M,M+1) TO AQE
                                                                                                                           SBAW, I
                                                                                                                                                                                                                                                                                                                   MUAW, I
                                                                                                                                                  4,B
                                                                                                                                                                                                    (AQE)/(M,M+1) To AQ. REMOR TO E
                                                                                                                           DVAW. I
                                                                                                                                                   ч,в
                                                                                                                                                     FLOATING POINT ARITH CLASS
                              00032 60725252 60 1 25252 3
00033 61725252 61 1 25252 3
00034 62725252 62 1 25252 3
00035 63725252 63 1 25252 3
                                                                                                                                                  м,в
                                                                                                                                                                           FP(AQ) + FP(M,M+1) TO AQ
                                                                                                                           FAD.I
                                                                                                                                                                            FP(AQ) - FP(M,M+1) TO AQ
FP(AQ) * FP(M,M+1) TO AQ
FP(AQ) / FP(M,M+1) TO AQ
                                                                                                                                                                                                                                                                                                                   .
 FSR . I
                                                                                                                                                  4.8
M.B
                                                                                                                                                                                                                                                                                                                   0
 -
                                                                                                                                                                                                                                                                                                                    •
•
                                                                                                                                                                                                                                                                                                                   •
                                                                                                                                                                                                                                                                                                                   •
                                                              EXAMPLES
             COMPASS-32 (2.1)
                                                                                                                                                                                                                               11/21/66 PAGE
                                                                                                                                                     BCD CLASS
 .
                                                                                                                                                                                                                                                                                                                   •
                                                                                                                                                 FCA,81 (FCA THRU FCA+(D)-1) TO ED RIGHT JUSTIFIED FCA,82 (ED) TO FCA THRU FCA+(D)-1 + RIGHT JUSTIFIED FCA,83 (ED)+(FCA THRU FCA+(D)-1) TO FD FCA,83 (ED)+(FCA THRU FCA+(D)-1) TO FD K+B SHIFT ED + K DIGITS LEFT OR RIGHT (END OFF)
                              00036 64425253 64 1 05252 3
                                                                                                                           100
                              00037 65425253 65 1 05252 3

00040 66425253 66 1 05252 3

00041 67425253 67 1 05252 3

00042 70300014 70 0 00014 3
                                                                                                                          STF
ADE
SBE
SFE
 •
 •
                                                                                                                                                                                                                                                                                                                   •
                              00043 70700012 70 1 00012 3
                                                                                                                           SET
                                                                                                                                                  FL
                                                                                                                                                                  FL TO D
                                                                                                                                                                  RNI M IF ED OVERFLOW CHARACTER IS NONZERO RNI M IF ED CONTAINS ZERO RNI M IF ED IS NEGATIVE
                                                                                                                                                                                                                                                                                                                   00044 70625252 70 1 25252 2
                                                                                                                           ΕOJ
                               00045 70425252 70 1 25252 0
00046 70525252 70 1 25252 1
                                                                                                                           EZ.I.EQ
                                                                                                                           EZJ+LT
 .
                                                                                                                                                                                                                                                                                                                   24 BIT INTER-REGISTER TRANSFER CLASS

        00047
        53300000
        53 0
        00000
        3

        00050
        53700000
        53 1
        00000
        3

        00051
        53010077
        53 0
        10077
        0

        00052
        53410077
        53 1
        10077
        0

                                                                                                                                                                                                                                                                                                                   •
                                                                                                                           TIA
                                                                                                                                                                                                    (8) TO A 14-00 . A 23-15 CLEARED
                                                                                                                                                                                                   (A) 14-00 . A 23-15 CLEARED
(A) 170 B
(V) 170 Q
(Q) 170 V
(V) 170 A
(A) 170 V
(V) 14-00) 170 B
(B) 170 V 14-00 , V 23-15 CLEARED
                                                                                                                           TAI
TMQ
TQM
TMA
                                              53020077 53 0 20077 0
53420077 53 1 20077 0
53330077 53 0 30077 3
53730077 53 1 30077 3
                               00053
                               00054
 •
                               00055
                                                                                                                            TMT
                                                                                                                                                  V.B
                              00056
                                                                                                                           TIÑ
                                              53040000 53 0 40000 0
53340000 53 0 40000 3
53740000 53 1 40000 3
 00057
                               00060
                                                                                                                            AIA
                                                                                                                                                                                                    (A) + (B) TO A
                              00061
                                                                                                                                                                                                                                                                                                                    48 BIT INTER-REGISTER TRANSFER

        00062
        55100000
        55
        0
        00000
        1

        00063
        55500000
        55
        1
        00000
        1

        00064
        55200000
        55
        1
        00000
        2

        00065
        55600000
        55
        1
        00000
        2

        00066
        55300000
        55
        0
        00000
        3

        00067
        55700000
        55
        1
        00000
        3

                                                                                                                                                                                                                                                                                                                   ELO
                                                                                                                                                                                                    (EL) TO Q
                                                                                                                                                                                                    (Q) TO EL
(EU) TO A
(A) TO EU
(E) TO AQ
                                                                                                                           QEL
                                                                                                                           EUA
 •
                                                                                                                                                                                                                                                                                                                   AQF
                                                                                                                                                                                                    (AQ) TO E
 •
```

```
COMPASS-32
                                   (2.1)
                                                                      EXAMPLES
                                                                                                                                                                        11/21/66 PAGE
                                                                                                                 STOP AND JUMP CLASS
                      00070 14000000 14 0 00000 0
                                                                                             NOP
                                                                                                                                                   DO NOTHING
                      00071 00025252 00 0 25252 0
                                                                                                                                                   STOP. RNI M
                       00072 77770000 77 1 70000 3
                                                                                             UCS
                                                                                                                                                    STOP, RNI P+1
                       00073 01725252 01 1 25252 3
                                                                                             UJP.I
                                                                                                               м, В
                                                                                                                                                   RNI M
                       00074 00725252 00 1 25252 3
                                                                                             RTJ
                                                                                                                                                    (P) TO M 14-00 , RNI M+1
                      00075 00125252 00 0 25252 1
                                                                                                                                                   RNI M IF KEY 1 IS SET
                                  00225252 00 0 25252 2
00325252 00 0 25252 3
00425252 00 1 25252 0
00525252 00 1 25252 1
00625252 00 1 25252 2
                      00076
00077
                                                                                                                                                  RNI M IF KEY 1 IS SET
RNI M IF KEY 2 IS SET
RNI M IF KEY 3 IS SET
RNI M IF KEY 4 IS SET
RNI M IF KEY 5 IS SET
RNI M IF KEY 6 IS SET
                                                                                             SJo
                                                                                             SJ3
SJ4
                       00100
                      00101
                                                                                             SJS
                                                                                             SJ6
                      00103 03025252 03 0 25252 0
                                                                                             AZJ,EQ
                                                                                                                                                  RNI M IF (A) EQ + OR - ZERO
RNI M IF (A) NE + OR - ZERO
RNI M IF (A) POSITIVE
RNI M IF (A) NEGATIVE
                                 03125252 03 0 25252 1
03225252 03 0 25252 2
                       00104
                                                                                             AZJ+NE
                                                                                             AZJ+GE
AZJ+LT
                      00106 03325252 03 0 25252 3
                                                                                                                                                  RNI M IF (A) EQ (Q)
RNI M IF (A) NE (Q)
RNI M IF (A) GE (Q)
RNI M IF (A) LT (Q)
                      00107 03425252 03 1 25252 0
                                                                                             AGJ.EQ
                      00110 03525252 03 1 25252 1
00111 03625252 03 1 25252 2
00112 03725252 03 1 25252 3
                                                                                             AUJ+NE
AUJ+GE
                                                                                             AQJeLT
                      00113 02325252 02 0 25252 3
00114 02725252 02 1 25252 3
                                                                                            IJI
                                                                                                                          IF (B) NE 0 (g)+1 TO B AND RNI M. OW RNI P+1
                                                                                             IJŋ
                                                                                                              M.B
                                                                                                                         IF (8) NE 0 (8)=1 TO 8 AND RNT M. ON RNI P+1
                                                                                                                 SKIP CLASS
                                                                                             WITHOUT SIGN EXTENSION . ONLY THE LOWER 15 BITS OF A OR Q
                                                                                             ARE COMPARED WITH Y. ARE COMPARED WITH Y. WITH SIGN EXTENSION , BIT 14 OF Y IS EXTENDED THRU BIT 23 MAKING Y 24 BITS FOR COMPARISON WITH ALL OF A OR Q.
                      00115 04412345 04 1
00116 04512345 04 1
00117 04312345 04 0
                                                           12345 0
                                                                                                                                                  RNI P+2 IF (A) EQ Y , OW RNI P+1 RNI P+2 IF (Q) EQ Y , OW RNI P+1 RNI P+2 IF (B) EQ Y , OW RNI P+1 RNI P+2 IF Y EQ 0 , OW RNI P+1
                                                                                                                                                                                                                                     12345 1
12345 3
                                                                                            QSE+S
                                                                                            ISE
ISE
                                                                                                              Ý.B
                      00120 04012345 04 0
                                                           12345 0
                                                                                                                                                                                                                                     00121 05412345 05 1 12345 0
                                                                                            ASG+S
                                                                                                                                                  RNI P+2 IF (A) GE Y • OW RNI P+1
RNI P+2 IF (Q) GE Y • OW RNI P+1
RNI P+2 IF (R) GE Y • OW RNI P+1
                      00122 05512345 05 1 12345 1
00123 05312345 05 0 12345 3
                                                                                            QSG+S
ISG
                                                                                                              ݕ8
                      00124 10712345 10 1 12345 3
00125 10312345 10 0 12345 3
                                                                                                                         IF (8) EQ Y CLEAR B AND RNI P+2. OTHERWISE IF (B) EQ Y CLEAR B AND RNI P+2. OTHERWISE (8)+1 TO B AND RNI P+1 (8)-1 TO B AND RNI P+1
                                                                                                             Y.B
                                                                                                                                                                                                                                     •
                                                                                            ISI
                                                                                                              Y.8
                                                                                                                                                                                                                                     •
                                                                                                                                                                                                                                    •
                                                                                                                                                                                                                                    COMPASS-32
                                                                     EXAMPLES
                                                                                                                                                                      11/21/66 PAGE
                                                                                                                SHIFT CLASS
                                                                                            POSITIVE SHIFT COUNT (K) INDICATES LEFT SHIFT. ALL LEFT
                                                                                            SHIFTS ARE END AROUND.
NEGATIVE SHIFT COUNT (K) INDICATES RIGHT SHIFT. ALL RIGHT SHIFTS ARE END OFF WITH SIGN EXTENDED.
                                                                                                                                                                                                                                    •
                                                                                                                                                                                                                                    4
                      00126 12300014 12 0 00014 3
                                                                                                                                                 SHIFT (A) LEFT OR RIGHT K BITS
SHIFT (Q) LEFT OR RIGHT K BITS
SHIFT (AQ) LEFT OR RIGHT K BITS
                               12700014 12 1 00014 3
13300014 13 0 00014 3
                                                                                                             K.8
K.B
                     00130
                                                                                                                                                                                                                                    00131 13700014 13 1 00014 3
                                                                                           SCAG
                                                                                                            K.A
                                                                                                                                                 SCALE (AQ)
                                                                                                                ENTER CLASS
                                                                                           WITHOUT SIGN EXTENSION . THE UPPER BITS OF A OR Q ARE CLEARED. WITH SIGN EXTENSION . BIT 14 OF Y (BIT 16 OF R) IS EXTENDED MAKING Y OR R 24 BITS FOR ENTRY INTO ALL OF A OR Q.
                                                                                                                                                                                                                                    •
                     00132 14412345 14 1 12345 0
00133 14512345 14 1 12345 1
00134 14312345 14 0 12345 3
                                                                                           ENA . S
                                                                                                            Y
Y
Y•B
                                                                                                                                                 Y To A 14-00
Y To G 14-00
Y To B
                                                                                           ENG+S
ENI
                                                                                                                INCREASE CLASS
                                                                                           WITH OR WITHOUT SIGN EXTENSION . Y WILL BE TREATED AS A 24 BIT
                                                                                                                                                                                                                                    •
                                                                                          WITH UR WITHOUT SIGN ENCLOSED. THE UP OF Y VALUE WHEN ADDED TO A OR Q. WITHOUT SIGN EXTENSION, BITS 23-15 OF Y WILL BE ZERO. WITH SIGN EXTENSION, BIT 14 OF Y IS EXTENDED THRU BIT 23 MAKING Y A 24 BIT VALUE.
                                                                                           IF Y IS A NEGATIVE VALUE , THE REGISTER WILL BE DECREASED BY THAT AMOUNT. ( MUST USE SIGN EXT IN THIS CASE FOR A AND Q)
                                                                                                                                                                                                                                    .
                                                                                                                                                                                                                                   00135 15412345 15 1 12345 0
00136 15512345 15 1 12345 1
                                                                                           INA . S
                                                                                                                                                INCREASE (A) BY Y
INCREASE (Q) BY Y
                                                                                           INQ.S
                                                                                                                                                                                                                                    •
                                                                                          INT
                                                                                                            Y . 8
                                                                                                                                                INCREASE (B) BY Y
```

COMPASS-32	(2.1)	EXAMPLES			11/21/66 PAGE
				LOGICAL INSTRU	CTIONS WITHOUT STORAGE REFERENCE
			WITH OR W	ITHOUT SIGN EXTEN	ISION . Y IS TREATED AS A 24 BIT
			VALUE.		
					ITS 23-15 OF Y ARE ZEROS.
				A 24 BIT VALUE FO	14 OF Y IS EXTENDED THRU BIT 23 HR THE OPERATION.
00140	16412345 16	1 12345 0	XUA+S	Y	SC (A) BY Y
	16512345 16		XOQ+S	Ý	SC (Q) BY Y
	16312345 16		XOT	Y•B	SC (B) BY Y
	-		•		
	17412345 17		ANA . S	Y	LM (A) BY Y
	17512345 17		ANQ . S	Υ _	LM (Q) BY Y
00145	17312345 17	0 12345 3	ANŢ	Y•B	LM (B) BY Y
				LOGICAL INSTRU	CTIONS WITH STORAGE REFERENCE
00146	35725252 35	1 25252 3	SSA·I	4.B	SS (A) BY (M)
	36725252 36		SCA . I	M•B	SC (A) BY (M)
00150	37725252 37	1 25252 3	LPA+I	4,8	LM (A) BY (M)
				BUFFERED SEARC	H AND MOVE CLASS
00151	71425261 71	1 05254 1	SHCE. INT	C.FCA,LCA+1	SEARCH (FCA THRU LCA) FOR EQ
00152	23025253 23	0 05252 3			
	01000151 01		UJP	*- 2	REJECT INSTRUCTION
	71425261 71		SRCN, INT	C.FCA.LCA+1	SEARCH (FCA THRU LCA) FOR NE
	23425253 23 01000154 01		UJP	*• 2	REJECT INSTRUCTION
	72425653 72			FL,FSCA,FDCA	MOVE (FSCA THRU FSCA+FL=1) T
	05025253 05				
00161	01000157 01	0 800157 0	ijJρ	*-2	FUCA THRU FDCA+FL=1 REJECT INSTRUCTION
00101	01000157 01	0 1 00231 0	307	_	
				STORAGE TEST C	LASS
	06225252 06		MEQ	4, INTERVAL	MASKED EQUALITY SEARCH
	07225252 07		MTH	4. INTERVAL	MASKED THRESHOLD SEARCH
	10025252 10		SSH	M M	STORAGE TEST AND SHIFT
00165	52725252 52	1 59696 3	CPR • I	4,B	COMPARE (M) WITH (A) AND (Q)

•	COMPASS-32	(2.1)	EXAMPLES			11/21/66 PAGE 9	•
					INPUT / OUTPUT		_
•	00166	77067007 77 0 670	07 0	CON	CC+CH	CONNECT TO 1/0 EQUIPMENT	•
1		01000166 01 0 P001			#=1	REJECT INSTRUCTION	
		77160022 77 0 600			FC CH	SELECT FUNCTION ON I/O EQUIPMENT	. •
	00171				*-1	REJECT INSTRUCTION	_
•		73025261 73 0 0529		INPC.INT.B	H CH+FCA+LCA+1	CHAR ADRS INPUT TO STORAGE	•
l		63425253 63 1 0529					
•	00174	01000172 01 0 P001	72 0	UJP	*-2	REJECT INSTRUCTION	•
١_	00175	73400000 73 1 000	00 0	INAC. INT	СН	CHAR ADRS INPUT TO A	
●		60400000 60 1 000					•
_	00177	01000175 01 0 P001	75 0	UJP	*- 2	REJECT INSTRUCTION	
							•
		74025322 74 0 253		INPW, INT, B	N CHOFWAOLWA+1	WORD ADRS INPUT TO STORAGE	-
		63425252 63 1 252					_
•	00202	01000200 01 0 P002	00 0	UJP	*-2	REJECT INSTRUCTION	•
•	00203	74400000 74 1 000	00 0	INAW.INT	СН	WORD ADRS INPUT TO A	•
1		60400000 60 1 000			•	and the same same same same same same same sam	•
•	00205	01000203 01 0 P002	03 0	UJP	*- 2	REJECT INSTRUCTION	
_							•
		75025261 75 0 052		OUTC, INT, B	+H CH+FCA+LCA+1	CHAR ADRS OUTPUT FROM STORAGE	_
•	00207	63425253 63 1 052	52 3				•
	00210	01000206 01 0 P002	06,0	UJP	*-2	REJECT INSTRUCTION	
•	00311	75400000 75 1 000		07.0		0.110 .000 0.1-0.1-0.1-0.1-0.1-0.1-0.1-0.1-0.1-0.1-	•
l		60400000 60 1 000		OTAC, INT	CH	CHAR ADRS OUTPUT FROM A	
		01000211 01 0 P002		UJP	*-2	REJECT INSTRUCTION	•
	******		•• •	50 F		MEACL THRUMALINA	
•	00214	76025322 76 0 253	22 0	OUT#, INT, B	N CHOFWAOLWA+1	WORD ADRS OUTPUT FROM STORAGE	•
l		63425252 63 1 252		0-1,70,1170	0.171 4474411	HOND HOND GOLFOT FROM STORAGE	•
•	00516	01000214 01 0 P002	14 0	UJP	**2	REJECT INSTRUCTION	
1							•
۱ ـ	00217	76400000 76 1 000	00 0	TAI.WATO	СН	WORD ADRS OUTPUT FROM A	
•	00220	60400000 60 1 000	00 0		• •	,	•
	00221	01000217 01 0 P002	17 0	UJP	*-2	REJECT INSTRUCTION	
							•
i		77750000 77 1 500		CTI		CONSOLE TYPEWRITER INPUT	
	00223	77760000 77 1 600	00 3	сто		CONSOLE TYPEWRITER OUTPUT	_
							•
1							

SENSING AND COPY CLASS 00224 77260000 77 0 60000 2 COPY 00225 77360000 77 0 60000 3 CINS CH COPY EXTERNAL STATUS AND INR TO A 00226 77267777 77 0 67777 2 EAS ALCH SENSE EXTERNAL STATUS AND INR TO A 0226 77267777 77 1 67777 3 INN A ACH SENSE EXTERNAL STATUS AND INR TO A 0227 77467777 77 1 67777 2 INN A ACH SENSE EXTERNAL STATUS AND INR TO A 0223 7750777 77 1 67777 2 PAUS X CONTROL CLASS 00232 7750777 77 1 07777 1 INC X INTERRUPT CLEAR INPUT/OUTPUT CLEAR INPUT/OUT	00225 00226 00227 00230 00231 00232 00233 00234 00235	77360000 77 0 77267777 77 1 77467777 77 1 77507777 77 1 77517777 77 1 77517777 77 1 77710000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77730000 77 1 77740000 77 1	0 60000 3 67777 2 67777 3 67777 0 07777 1 1 17777 1 1 10000 3 20000 3		CINS EXS EXS EXS EXS EXS EXS EXS EXS EXS EX	CH CH X+CH X+CH X+CH X CONTRC X X INTERF	DL CLASS	COPY EXTERNAL SENSE EXTER SENSE INTER SENSE INTER SENSE INTER PAUSE INTERRUPT (INPUT/OUTPL SET FLOATIL SET BCD FAL SELECTIVELY DISABLE INT	_ STATUS AND IMR TO A RNAL STATUS RRUPT CLEAR UT CLFAR NG POINT FAULT JLT SET IMR (CLEAR IMR IERRUPT SYSTEM
00224 7750000 77 0 00000 2 COPY CH COPY EXTERNAL STATUS AND IMR TO 00225 77360007 77 0 00000 3 CIUS CH COPY EXTERNAL STATUS AND IMR TO 00226 7726777 77 0 07777 3 INS X.CH SENSE EXTERNAL STATUS OCCION TO 00230 77467777 77 1 07777 2 PAUS X COMPROL CLASS CONTROL CLASS 00230 77467777 77 1 07777 1 INCT X INTERNUT CLEAR INTERNUT CLEAR INTERNUT CLEAR INTERNUT CLEAR INTERNUT CLEAR SENSE INTERNUT CLEAR SENSE INTERNUT CLEAR INTERNUT CLEAR INTERNUT CLEAR SENSE SEN	00225 00226 00227 00230 00231 00232 00233 00234 00235	77360000 77 0 77267777 77 1 77467777 77 1 77507777 77 1 77517777 77 1 77517777 77 1 77710000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77730000 77 1 77740000 77 1	0 60000 3 67777 2 67777 3 67777 0 07777 1 1 17777 1 1 10000 3 20000 3		CINS EXS EXS EXS EXS EXS EXS EXS EXS EXS EX	CH CH X+CH X+CH X+CH X CONTRC X X INTERF	DL CLASS	COPY EXTERNAL SENSE EXTER SENSE INTER SENSE INTER SENSE INTER PAUSE INTERRUPT (INPUT/OUTPL SET FLOATIL SET BCD FAL SELECTIVELY DISABLE INT	_ STATUS AND IMR TO A RNAL STATUS RRUPT CLEAR UT CLFAR NG POINT FAULT JLT SET IMR (CLEAR IMR IERRUPT SYSTEM
00225 77780000 77 0 67777 2 EAS XACH SENGE INTERNAL STATUS AND INR TO A 0220 77867777 77 1 67777 2 EAS XACH SENGE INTERNAL STATUS AND INR TO A 0230 77867777 77 1 67777 2 EAS XACH SENGE INTERNAL STATUS AND INR TO A 0230 77867777 77 1 67777 2 PAUS X COMTROL CLASS 00230 77867777 77 1 67777 2 PAUS X COMTROL CLASS 00231 77567777 71 1 7777 1 1 1 INCL X INTERNAT CLEAR INTERNAT CLEAR 100233 7751777 71 1 10000 3 SEPF SET FLOATING POINT FAULT SET BIOL FAULT SE	00226 00231 00231 00231 00232 00233 00234 00235 00236 00237 00240 00241	77267777 77 0 77367777 77 0 77467777 77 1 77607777 77 1 77507777 77 1 7751777 77 1 77710000 77 1 77527777 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77740000 77 1	0 67777 2 0 67777 3 0 67777 0 0 77777 2 0 07777 1 1 17777 1 1 10000 3 2 20000 3 2 27777 1 3 37777 1 3 30000 3 4 40000 3		EXS INS INTS PAUS INCL IOCL SEPF SBCD SSIM SCIM DINT EINT ECHA+S	X.CH X.CH X.CH X CONTRO X X X INTERF		COPY INTERNAL SENSE EXTER SENSE INTER SENSE INTER PAUSE INTERRUPT (INPUT/OUTP) SET FLOATIN SET BCD FAR SELECTIVELY DISABLE INT	_ STATUS AND IMR TO A RNAL STATUS RRUPT CLEAR UT CLFAR NG POINT FAULT JLT SET IMR (CLEAR IMR IERRUPT SYSTEM
00227 7737777 70 67777 31 NS X1CH SERVE EXTERNAL STATUS 00231 77607777 77 1 07777 3 INS X1CH SERVE INTERRAL STATUS 00232 77507777 77 1 07777 2 PAUS X CONTROL CLASS 00232 7750777 77 1 07777 1 INCL X INTERRUPT CLEAR 00233 7751777 77 1 17777 1 INCL X INTERRUPT CLEAR 00234 77710000 77 1 10000 3 SPFF SET FLOATING POINT FAULT 00236 77527777 77 1 27777 1 SSIM X SELECTIVELY SET IMR 00237 77537777 77 1 37777 1 SCIM X SELECTIVELY CLEAR INR 00240 77730000 77 1 30000 3 SIMT SET SELECTIVELY CLEAR INR 00240 77730000 77 1 30000 3 SIMT SELECTIVELY CLEAR INR 00241 77740000 77 1 40000 3 SIMT SELECTIVELY CLEAR INR 00242 11425253 11 05252 3 ECHA,S R R TO A LABOL INTERRUPT SYSTEM 00243 77570000 77 1 70000 1 IAPR INS INS 00243 77570000 77 1 70000 1 IAPR INS INS SIMPLY SET IMR SCIM INCL INTS INCL PAUS INS 00400 CM 1 CM C CM C LINE 0 CM 0 CM 0 BUSY PARTY SER ON CM X SELECTIVELY CLEAR INR 00400 CM 1 CM 1 CM 1 LINE 1 CM 1 CM 1 BUSY CM X BUSY READING 01 0000 CM 1 CM 1 CM 1 LINE 1 CM 1 CM 1 BUSY CM X BUSY READING 02 00040 CM 2 CM 2 LINE 2 CM 2 CM 2 BUSY PARTY SER ON CM X BUSY READING 03 0010 CM 3 CM 3 LINE 3 CM 3 LINE 3 CM 3 BUSY SEX REJECT ON CM X BUSY READING 04 0020 CM 1 CM 1 LINE 1 CM 1 CM 1 BUSY CM X BUSY READING 05 0000 CM 1 CM 1 LINE 1 CM 1 CM 1 BUSY CM X BUSY READING 06 0000 CM 1 CM 1 LINE 1 CM 1 CM 1 BUSY CM X BUSY READING 07 0200 CM 7 CM 1 LINE 7 CM 2 CM 5 CM 5 BUSY SEX REJECT ON CM X BUSY READING 08 0400 CM 2 CM 2 LINE 2 CM 2 CM 2 CM 3 BUSY SEX REJECT ON CM X BUSY READING 08 0400 CM 2 CM 1 LINE 3 CM 3 LINE 3 CM 3 BUSY SEX REJECT ON CM X BUSY READING 09 1000 SERPLOYMENT OF ALLTH CHOCK INT TY TY BUSY SEX REJECT ON CM X BUSY READING 09 1000 SERPLOYMENT OF ALLTH CHOCK INT TY TY BUSY SEX REJECT ON CM X BUSY READING 00 0001 TO CM 1 LINE 1 CM 1 LINE 1 CM 1 CM 1 BUSY SEX REJECT ON CM X BUSY READING 00 0001 SERPLOYMENT OF ALLTH CHOCK INT TY TY BUSY SEX REJECT ON CM X BUSY READING 00 0001 SERPLOYMENT OF ALLTH CHOCK INT TY TY BUSY SEX REJECT ON CM X BUSY READING 00 0001 SERPLOYMENT OF ALLTH CHOCK INT TY BUSY SEX REJECT ON CM X BUSY READ	00237 00231 00231 00232 00233 00234 00235 00236 00237 00240 00241	77367777 77 1 77667777 77 1 77607777 77 1 77507777 77 1 77517777 77 1 77710000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77740000 77 1	0 67777 3 67777 0 07777 2 0 07777 1 1 17777 1 1 10000 3 20000 3 20000 3 40000 3		INS INTS PAUS INCL IOCL SEPF SBCD SSIM SCIM DINT EINT ECHA+S	X.CH X.CH X CONTRO X X INTERF X		SENSE EXTER SENSE INTER SENSE INTER PAUSE INTERRUPT (INPUT/OUTP) SET FLOATIF SET BCD FAL SELECTIVELY DISABLE INTER SENSE INTER SENSE INTER SELECTIVELY DISABLE INTER SENSE	NAL STATUS RRUPT CLEAR JI CLEAR NG POINT FAULT JLT SET IMR C CLEAR IMR IERRUPT SYSTEM
00230 77467777 77 1 67777 2 PAUS X CONTROL CLASS 00232 7750777 77 1 07777 1 1000 77 1 1000 X 00233 77517777 77 1 17777 1 1000 X 00234 77710000 77 1 10000 3 SFPF 00235 77728080 77 1 20000 3 SFPF SET FLOATING POINT FAULT SET BCD FAULT 1NTERRUPT CLASS 00236 7752777 77 1 27777 1 SSIM X SELECTIVELY SET IMR 00237 773777 77 1 37777 1 SSIM X 00237 773777 77 1 37777 1 SSIM X 00240 77730000 77 1 30000 3 DINT 00241 7774000 77 1 40000 3 EINT 00242 1145253 11 1 05252 3 ECHA,S R 00243 77570000 77 1 70000 1 IAPR 00243 77570000 77 1 70000 1 IAPR 881 CODE SSIM SCIM INCL INTS 10CL PAUS INS 00 0001 CH 0 CH 0 LINE 1 CH 1 CH 1 EUSY CH X BUSY READING SCIM INCL INTS 10CL PAUS INS 00 0001 CH 3 CH 3 LINE 3 CH 3 CH 4 SUSY READING 00 0001 CH 3 CH 3 LINE 1 CH 1 CH 1 CH 1 SUSY CH X BUSY READING 00 0000 CH 4 CH 4 LINE 4 CH 4 CH 4 BUSY OF ART READER OF ART READER ON CH X 01 0002 CH 4 CH 4 LINE 4 CH 4 CH 4 BUSY OF ART READER ON CH X 04 0020 CH 4 CH 4 LINE 4 CH 4 CH 4 BUSY OF ART READER ON CH X 05 0040 CH 5 CH 5 LINE 5 CH 5 CH 5 BUSY STREED ON CH X 06 0100 CH 5 CH 5 LINE 6 CH 6 CH 6 BUSY OF ART READER ON CH X 07 0200 CH 4 CH 4 LINE 6 CH 6 CH 6 BUSY OF ART READER ON CH X 09 1000 SERVE OF ART READER ON CH X 09 1000 SERVE OF OFFINISH SARRY OF ART INTERNAL INTO CH I 09 1000 SEARCH/MOVE COMPLETE S/N S/N BUSY SRC INTERNAL INTO CH I 10 2000 SEARCH/MOVE COMPLETE S/N S/N BUSY SRC INTERNAL INTO CH I 10 2000 SEARCH/MOVE COMPLETE S/N S/N BUSY SRC INTERNAL INTO CH I 10 2000 SEARCH/MOVE COMPLETE S/N S/N BUSY SRC INTERNAL INTO CH I 10 2000 SEARCH/MOVE COMPLETE S/N S/N BUSY SRC INTERNAL INTO CH I 11 4000 SEARCH/MOVE COMPLETE S/N S/N BUSY SRC INTERNAL INTO CH I 11/21/66 PAGE 11	00230 00231 00232 00233 00234 00235 00236 00237 00240 00241	77467777 77 1 77607777 77 1 77507777 77 1 77517777 77 1 77710000 77 1 77720000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77740000 77 1	. 67777 0 07777 2 . 07777 1 . 17777 1 . 10000 3 . 20000 3		INTS PAUS INCL IOCL SEPE SBCD SSIM SCIM DINT EINT ECHA+S	CONTRC X X INTERF X		SENSE INTERPAUSE INTERRUPT (INPUT/OUTPL SET FLOATI SET BCD FAL SELECTIVELY SELECTIVELY DISABLE INTERPAUSE	CLEAR JI CLFAR NG POINT FAULT JLT SET IMR 1 CLEAR IMR
00231 77607777 77 1 07777 2 PAUS	00232 00233 00234 00235 00236 00237 00240 00241	77507777 77 1 77507777 77 1 7751777 77 1 77710000 77 1 77720000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77740000 77 1	. 07777 2 . 07777 1 . 17777 1 . 10000 3 . 20000 3 . 27777 1 . 37777 1 . 30000 3		PAUS INCL IOCL SEPE SBCD SSIM SCIM DINT EINT ECHA-S	X CONTRO		INTERRUPT (INPUT/OUTPU SET FLOATI! SET BCD FAU SELECTIVELY SELECTIVELY DISABLE INT	CLEAR UT CLFAR NG POINT FAULT ULT SET IMR (CLEAR IMR
00232 77507777 77 1 07777 1 10CL X INTERRUPT CLEAR 00233 77517777 77 1 17777 1 1000 3 SP6F SET INTERRUPT CLASS 00234 77710000 77 1 20000 3 SP6F SET BCD FAULT INTERRUPT CLASS 00236 77527777 77 1 27777 1 SSIM X SELECTIVELY SET IMR 00237 77537777 77 1 37777 1 SCIM X SELECTIVELY CLEAR IMR 00240 77730000 77 1 30000 3 EINT DISABLE INTERRUPT SYSTEM 00240 77730000 77 1 30000 3 EINT ENABLE INTERRUPT SYSTEM 00241 77740000 77 1 40000 3 EINT ENABLE INTERRUPT SYSTEM 00242 11425253 11 1 05252 3 ECHA-S R R IN A 16-00 00243 77570000 77 1 70000 1 IAPR INTERRUPT ASSOCIATED PROCESSOR 81T CODE SSIM SCIM INCL INTS 10CL PAUS INS 00 0001 CM 0 CM 0 LINE 0 CM 0 CM 0 BUSY PARTY ERR ON CM X 01 0002 CM 1 CM 1 LINE 1 CM 1 H SUSY CM X BUSY MEADING 02 0004 CM 2 CM 2 LINE 2 CM 2 CM 2 BUSY CM X BUSY MEADING 03 0004 CM 2 CM 2 LINE 2 CM 2 CM 2 BUSY CM X BUSY MEADING 04 0002 CM 1 CM 3 LINE 3 CM 3 CM 3 BUSY PARTY ERR ON CM X 04 0002 CM 1 CM 3 LINE 3 CM 3 CM 3 BUSY PARTY ERR ON CM X 05 0040 CM 5 CM 5 LINE 5 CM 5 CM 5 BUSY CM X BUSY MEADING 06 0100 CM 6 CM 6 LINE 6 CM 6 CM 6 BUSY PARTY ERR ON CM X 06 0100 CM 6 CM 6 LINE 6 CM 6 CM 6 BUSY CM X BUSY MEADING 07 0200 CM 7 CM 7 LINE 7 CM 7 CM 7 BUSY INTERNAL INTO N CM X 08 0400 REAL TIME CLOCK INT TY TY BUSY 08 0400 REAL TIME CLOCK INT	00233 00234 00235 00236 00237 00240 00241	77517777 77 1 77710000 77 1 77720000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77740000 77 1	. 17777 1 . 10000 3 . 20000 3 . 27777 1 . 37777 1 . 30000 3 . 40000 3		SEPF SBCD SSIM SCIM DINT EINT ECHA.S	X X INTERF X X		INPUT/OUTPU SET FLOATIN SET BCD FAU SELECTIVELY SELECTIVELY DISABLE INT	UT CLFAR NG POINT FAULT JLT SET IMR (CLEAR IMR IERRUPT SYSTEM
00233 77517777 77 1 17777 1 10000 3 SPF SET FLOATING POINT FAULT SET BCD FAULT 00234 77710000 77 1 20000 3 SPF SET FLOATING POINT FAULT SET BCD FAULT 00236 77527777 77 1 27777 1 SSIM X SELECTIVELY SET IMR SELECTIVELY CLEAR IHR 00240 77730000 77 1 30000 3 DINT DISABLE INTERBUDT SYSTEM EMABLE INTERBUDT SYSTEM IN TO A 16-00 SIM SCIM INCL INTS 10CL PAUS INS 00240 7773000 77 1 70000 1 IAPR INCL INTS 10CL PAUS INS 8IT CODE SSIM SCIM INCL INTS 10CL PAUS INS 00 0001 CH 0 CH 0 CH 0 LINE 0 CH 0 CH 0 BUSY PARTIY ERR ON CH X OF A 10 ST WILL WILL WILL WILL WILL WILL WILL WIL	00233 00234 00235 00236 00237 00240 00241	77517777 77 1 77710000 77 1 77720000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77740000 77 1	. 17777 1 . 10000 3 . 20000 3 . 27777 1 . 37777 1 . 30000 3 . 40000 3		SEPF SBCD SSIM SCIM DINT EINT ECHA.S	X INTERR X X	RUPT CLASS	INPUT/OUTPU SET FLOATIN SET BCD FAU SELECTIVELY SELECTIVELY DISABLE INT	UT CLFAR NG POINT FAULT JLT SET IMR (CLEAR IMR IERRUPT SYSTEM
00234 77710000 77 1 10000 3 SPPF SET FLOATING POINT FAULT SET BCD FAULT INTERRUPT CLASS 00236 77527777 77 1 27777 1 SSIM X SELECTIVELY SET IMR 00237 77537777 77 1 37777 1 SCIM X SELECTIVELY CLEAR IMR 00240 77730000 77 1 30000 3 DINT DISABLE INTERRUPT SYSTEM 00241 77730000 77 1 40000 3 EINT ENARLE INTERRUPT SYSTEM 00242 11425253 11 1 05252 3 ECMANS R R TO A 16-00 00243 77570000 77 1 70000 1 IAAPR INTERRUPT ASSIGNMENTS	00234 00235 00236 00237 00240 00241	77710000 77 1 77720000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77740000 77 1	27777 1 37777 1 30000 3		SEPF SBCD SSIM SCIM DINT EINT ECHA,S	INTERR X X	RUPT CLASS	SET FLOATING SELECTIVELY SELECTIVELY DISABLE INT	NG POINT FAULT JLT SET IMR (CLEAR IMR (ERRUPT SYSTEM
00235 77720000 77 1 20000 3 S8CD SET BCD FAULT 00236 77527777 77 1 27777 1 SSIM X SELECTIVELY SET IMR 00237 77537777 77 1 37777 1 SSIM X SELECTIVELY CLEAR IMR 00240 77730000 77 1 30000 3 DINT 00241 77740000 77 1 40000 3 EINT 00242 1142553 11 1 05252 3 ECHA,S R R TA 16-00 00243 77570000 77 1 70000 1 IAPR BIT CODE SSIM SCIM INCL INTS IOCL PAUS INS 00 0001 CH 0 CH 0 LINE 0 CH 0 CH 0 BUSY PARTY ERR ON CH X SCIM INCL INTS IOCL PAUS TOS 00 0001 CH 0 CH 0 LINE 1 CH 1 BUSY CH X BUSY MEADING 02 0004 CH 2 CH 2 LINE 2 CH 2 BUSY CH X BUSY MEADING 03 0010 CH 3 CH 3 CH 3 CH 3 CH 4 BUSY CH X BUSY MEITING 04 0020 CH 4 CH 4 LINE 5 CH 5 CH 5 BUSY CH X BUSY MEITING 05 0040 CH 5 CH 5 LINE 5 CH 5 CH 5 BUSY CH X BUSY MEITING 06 0100 CH 6 CH 6 LINE 5 CH 5 CH 5 BUSY CH X BUSY MEITING 07 0200 CH 7 CH 7 LINE 7 CH 7 BUSY METRAL INTO NCH X 08 0400 CH 5 CH 5 LINE 5 CH 5 CH 5 BUSY CH X BUSY MEITING 08 0400 REAL TIME CLOCK INT TY THRUSY CH X PRESET CONJECT 09 0400 SEARCHAVOYE COMPLETE S/M SYM SEA OVELL FAULT 10 2000 SARTHM OVELW/DID FAULT NOT FEINSH SEATH OVER FAULT 10 2000 SARTHM OVELW/DID FAULT NOT FINISH SEATH OVER FAULT • INTERNAL FAULTS CLEARED BY SENSING	00235 00236 00237 00240 00241	77720000 77 1 77527777 77 1 77537777 77 1 77730000 77 1 77740000 77 1	27777 1 37777 1 30000 3 40000 3		SBCD SSIM SCIM DINT EINT ECHA.S	X X	RUPT CLASS	SET BCD FAU SELECTIVELY SELECTIVELY DISABLE IN	JLT SET IMR CCLEAR IMR FERRUPT SYSTEM
INTERRUPT CLASS 00236 77527777 77 1 27777 1 SSIM X SELECTIVELY SET IMR 00237 77537777 77 1 37777 1 SCIM X SELECTIVELY CLEAR IMR 00240 77730000 77 1 30000 3 DINT DISABLE INTERRUPT SYSTEM 00241 77740000 77 1 40000 3 EINT EMARLE INTERRUPT SYSTEM 00242 11425253 11 1 05252 3 ECHALS R R TO A 16-00 00243 77570000 77 1 70000 1 IAPR INTERRUPT ASSOCIATED PROCESSOR	00237 00240 00241 00242	77537777 77 1 77730000 77 1 77740000 77 1 11425253 11 1	37777 1 30000 3 40000 3		SÇIM DINT EINT ECHA,S	X X	RUPT CLASS	SELECTIVELY SELECTIVELY DISABLE INT	SET IMR CCLEAR IMR FERRUPT SYSTEM
00240 77537777 77 1 37777 1 SCIM X 00240 77730000 77 1 30000 3 DINT DISABLE INTERRUPT SYSTEM END FOR THE PROPERTY OF THE PROP	00237 00240 00241 00242	77537777 77 1 77730000 77 1 77740000 77 1 11425253 11 1	37777 1 30000 3 40000 3		SÇIM DINT EINT ECHA,S	х		SELECTIVELY DISABLE IN	CLEAR IMR
00237 77537777 77 1 37777 1 SCIM X 00240 77730000 77 1 30000 3 DINT 00241 77740000 77 1 40000 3 EINT 00242 11425253 11 1 05252 3 ECHA,S R R TO A 16-00 00243 77570000 77 1 70000 1 IAPR	00240 00241 00242	77730000 77 1 77740000 77 1 11425253 11 1	30000 3 40000 3 05252 3		SÇIM DINT EINT ECHA,S			SELECTIVELY DISABLE IN	CLEAR IMR
00241 77740000 77 1 40000 3 EINT ENABLE INTERRUPT SYSTEM 00242 11425253 11 1 05252 3 ECHA,S R R TO A 16-00 00243 77570000 77 1 70000 1 IAPR RTO A 16-00 11APR SIT ASSIGNMENTS TABLE OF MASK BIT ASSIGNMENTS BIT CODE SSIM SCIM INCL INTS IOCL PAUS INS 00 0001 CH 0 CH 0 LINE 0 CH 0 CH 0 BUSY PARITY ERR ON CH X 01 0002 CH 1 CH 1 LINE 1 CH 1 CH 1 BUSY CH X BUSY READING 02 0004 CH 2 CH 2 LINE 2 CH 2 CH 2 BUSY CH X BUSY READING 03 0010 CH 3 CH 3 LINE 3 CH 3 CH 3 BUSY EXTRESCT ON CH X 04 0020 CH 4 CH 4 LINE 4 CH 4 CH 4 BUSY NO RESP REJ ON CH X 05 0040 CH 5 CH 5 LINE 5 CH 5 CH 5 BUSY SY 1 LICEGLA WRITE 06 0100 CH 6 CH 6 LINE 6 CH 6 CH 6 BUSY CH X PRESET CON/SEL 07 0200 CH 7 CH 7 LINE 7 CH 7 CH 7 BUSY INTERNAL INTO N CH 2 08 0400 REAL TIME CLOCK INT TY TY BUSY SEXP OVELUS FAULT 09 1000 **ARITH OVELW FAULT NOT FINISH **ARITH OVELW FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ***OFT FAULT 11 4000 SEARCH/MOVE S/M	00241 00242	77740000 77 1 11425253 11 1	40000 3 05252 3		EINT ECHA,S	a			
00243 77570000 77 1 70000 1						R		EMARTE IN	TERRUPT SYSTEM
BIT CODE SSIM SCIM INCL INTS 10CL PAUS 1NS 00 0001 CM 0 CM 0 LHE 0 CM 0 CM 0 BUSY 01 NO CM X 0002 CM 1 CM 1 LINE 1 CM 1 CM 1 BUSY CM X 0002 CM 1 CM 1 LINE 2 CM 2 CM 2 BUSY CM X 0004 RD 1 LINE 3 CM 2 CM 2 BUSY CM X 0004 RD 1 LINE 3 CM 2 CM 3 BUSY CM X 0004 RD 1 CM 3 LINE 3 CM 4 CM 4 BUSY CM X 0002 CM 4 CM 4 CM 4 LINE 4 CM 4 CM 5 BUSY CM X 000 RESP REJ ON CM X 05 0040 CM 5 CM 5 LINE 5 CM 5 CM 5 RUSY MO RESP REJ ON CM X 05 0040 CM 7 CM 7 LINE 7 CM 7 CM 7 BUSY MO RESP REJ ON CM X 06 000 CM 7 CM 7 LINE 7 CM 7 CM 7 BUSY MO RESP REJ ON CM X 07 0200 CM 7 CM 7 LINE 7 CM 7 CM 7 CM 7 BUSY MO RESP REJ ON CM X 08 0400 REAL TIME CLOCK INT TY TY TYBSY MOTERAL INT ON CM 1 10 2000 ARRITH ONFLW/BUSY FULL TIME 7 CM 7 CM 7 BUSY MOTERAL INT ON CM 1 10 2000 ARRITH ONFLW/BUSY FULL TIME 7 CM 7 CM 7 BUSY MOTERAL THE CLOCK INT TY TYBSY MOTERAL INT ON CM 1 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY HOLD FAULT SARTTH OVELW FAULT SHOULD SEARCH/MOVE COMPLETE S/M S/M BUSY SARTH OVELW FAULT SHOULD SEARCH/MOVE COMPLETE S/M S/M BUSY SHOULD SARTH OVELW FAULT SHOULD SEARCH/MOVE COMPLETE S/M S/M BUSY SHOULD SHOULD SEARCH/MOVE COMPLETE S/M S/M BUSY SHOULD SHOULD SHOULD SEARCH/MOVE COMPLETE S/M S/M BUSY SHOULD S					IAPR				
SCIM INCL INTS IOCL PAUS TNS 00 0001 CM 0 CM 0 CH 0 CH 0 CM 0 BUSY PARTITY ERR ON CH X 01 0002 CM 1 CH 1 LINE 1 CM 1 CM 1 BUSY CH X BUSY READING 02 0004 CH 2 CH 2 LINE 2 CH 2 CH 2 BUSY CH X BUSY WRITING 03 0010 CH 3 CH 3 LINE 3 CH 3 CH 3 BUSY CH X BUSY WRITING 03 0010 CH 4 CH 4 LINE 4 CH 4 CH 4 BUSY WRITING 05 0040 CH 5 CH 5 LINE 5 CH 5 CH 5 BUSY CH X BUSY WRITING 07 0200 CH 7 CH 7 LINE 7 CH 7 CH 7 BUSY ILLEGAL WRITE 09 1000 *EXP OVFLW/BOC FAULT NOT FINISH ** ARTHH OVFLW TO VFLW/BOC FAULT NOT FINISH ** ARTHH OVFLW TO VFLW/BOC FAULT NOT REPEAT ** OPFLW FAULT ** 10 2000 *ARTHH OVFLW/DIY FAULT NOT REPEAT ** OPFLW FAULT ** 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY ** ** ARCO FAULT ** ** INTERNAL FAULTS CLEARED BY SENSING* COMPASS-32 (2-1) EXAMPLES 11/21/66 PAGE 1						TABL	E OF MASK	BIT ASSIGNMENT	rs
00 0001 CM 0 CH 0 LINE 0 CH 0 BUSY PARTITY ERR ON CH X 01 0002 CM 1 CH 1 LINE 1 CM 1 CH 1 BUSY CH X BUSY READING 02 0004 CH 2 CH 2 LINE 2 CH 2 CH 2 BUSY CH X BUSY READING 03 0010 CH 3 CH 3 LINE 3 CH 3 BUSY CH X BUSY READING 04 0020 CH 4 CH 4 LINE 4 CH 6 CH 8 BUSY PARTITY ERR ON CH X 05 0040 CH 5 CH 5 LINE 7 CH 7 CH 7 BUSY CH X BUSY READING 06 0100 CH 6 CH 6 LINE 6 CH 6 CH 8 BUSY FAULT 07 0200 CH 7 CH 7 LINE 7 CH 7 CH 7 BUSY INTERNAL INTO N CH 08 0400 REAL TIME CLOCK INT TY TY BUSY CH X PRESET CON/SEL 01 02000 *ARITH OVFLW/BOS FAULT NOT FINISH SARTH OVFLW FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY * INTERNAL FAULTS CLEARED BY SENSING COMPASS=32 (2-1) EXAMPLES 11/21/66 PAGE 1				BIT C	ODE SSIM				
O1 0002 CM 1 CM 1 LINE 1 CH 1 CM 1 BUSY CM X BUSY READING 02 0004 CM 2 CM 2 LINE 2 CM 2 CM 2 BUSY CM X BUSY WRITING 03 0010 CM 3 CM 3 LINE 3 CM 3 CM 3 BUSY WRITING 04 0020 CM 4 CM 4 LINE 4 CM 4 CM 4 BUSY CM X BUSY WRITING 05 0040 CM 5 CM 5 LINE 5 CM 5 CM 5 RUSY WRITING 06 0100 CM 6 CM 6 LINE 6 CM 6 CM 6 BUSY CM X PRESET COM/SEL 07 0200 CM 7 CM 7 CM 7 LINE 7 CM 7 CM 7 BUSY WRITING N CM 2 CM X PRESET COM/SEL 09 1000 EXAMPLES SARCH/MOVE COMPLETE S/M S/M BUSY SARCH FAULT • INTERNAL FAULTS CLEARED BY SENSING COMPASS-32 (2-1) EXAMPLES 11/71/66 PAGE 1:					SCIM	INCL IN	ITS 100	L PAUS	TNS
02 0004 CH 2 CH 2 LINE 2 CH 2 CH 2 BUSY CM X BUSY WRITING 03 0010 CH 3 CH 3 LINE 3 CH 3 CH 3 BUSY EXT REJECT ON CH X 04 0020 CH 4 CH 4 LINE 4 CH 4 CH 4 BUSY NO RESP REJ ON CH X 05 0040 CH 5 CH 5 LINE 5 CH 5 BUSY ILLEGAL WRITE 06 0100 CH 6 CH 6 LINE 6 CH 6 CH 6 BUSY CM X PRESET CON/SEL 07 0200 CH 7 CH 7 LINE 7 CH 7 CH 7 BUSY INTERNAL INT ON CH 2 08 0400 REAL TIME CLOKK INT TY TY BUSY EXPOVEMENT FAULT 09 1000 *EXP OVFLW/BCD FAULT NOT FINISH NOT REPEAT 11 4000 SERCH/MOVE COMPLETE 5/M S/M BUSY * INTERNAL FAULTS CLEARED BY SENSING COMPASS-32 (2-1) EXAMPLES 11/21/66 PAGE 1: COMPASS CODING TECHNIQUES									
03 0010 CH 3 CH 3 LINE 3 CH 3 BUSY EXT REJECT ON CH X 04 0020 CH 4 CH 4 LINE 4 CH 4 BUSY NO RESP REJ ON CH X 05 0040 CH 5 CH 5 LINE 5 CH 5 CH 5 RUSY + ILLEGAL WRITE 06 0100 CH 6 CH 6 LINE 7 CH 7 CH 7 BUSY CH X PRESET CON/SEL 07 0200 CH 7 CH 7 LINE 7 CH 7 CH 7 BUSY CH X PRESET CON/SEL 08 0400 REAL TIME CLOCK INT TY TY BUSY *EXP OVFLW FAULT 09 1000 *EXP OVFLW/BCD FAULT NOT FINISH 10 2000 *ARITH OVFLW/DIV FAULT NOT FINISH 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY **ARCO FAULT * INTERNAL FAULTS CLEARED BY SENSING COMPASS-32 (2-1) EXAMPLES 11/21/66 PAGE 1: COMPASS CODING TECHNIQUES									
04 0020 CH 4 CH 4 LIME 4 CH 4 CH 4 BUSY NO RESP REJ ON CH X 05 0040 CH 5 CH 5 CH 5 CH 5 CH 5 BUSY ILLEGAL WRITE 06 0100 CH 6 CH 6 LIME 6 CH 6 CH 6 BUSY CH X PRESET CON/SEL 07 0200 CH 7 CH 7 LINE 7 CH 7 CH 7 BUSY INTERNAL INTO N CH 08 0400 REAL TIME CLOCK INT TY TY BUSY EXP OVFLW FAULT 09 1000 **EXP OVFLW/BCD FAULT NOT FINISH **ARITH OVFLW FAULT 10 2000 **ARITH OVFLW/BOD FAULT NOT REPEAT **DIVIDE FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY **AROT FAULT * INTERNAL FAULTS CLEARED BY SENSING COMPASS-32 (2*1) EXAMPLES 11/21/66 PAGE 1				03 0	010 CH 3				EXT REJECT ON CH X
06 0100 CH 6 CH 6 LIME 6 CH 6 CH 8 BUSY OF 200 CH 7 CH 7 CH 7 BUSY INTERNAL INTO N CH 2 CH					020 CH 4		NE 4 CH		
COMPASS-32 (2-1) EXAMPLES OB 0400 REAL TIME CLOCK INT TY TY BUSY SEXE OVER FAULT 10 91000 SEARCH/MOVE COMPLETE S/M S/M BUSY SHOOT FAULT S/M BUSY S/M BUSY SHOOT FAULT S/M BUSY SHOOT FAULT S/M BUSY S/M				06 0	100 CH 6				
O9 1000 *EXP OFFL/BCD FAULT NOT FINISH *ARTTH OVFLW FAULT 10 2000 *ARTTH OVFLW/OIV FAULT NOT REPEAT *DIVIDE FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY *BCD FAULT * INTERNAL FAULTS CLEARED BY SENSING COMPASS-32 (2-1) EXAMPLES 11/21/66 PAGE 1					200 CH 7	CH 7 LI	NE 7 CH		INTERNAL INT ON CH
10 2000 *ARITH OVELWYOUV FAULT NOT REPEAT *DIVIDE FAULT 11 4000 SEARCH/MOVE COMPLETE S/M S/M BUSY *RCD FAULT * INTERNAL FAULTS CLEARED BY SENSING COMPASS-32 (2-1) EXAMPLES 11/21/66 PAGE 1					000 MEAL	. TIME CLOCK	CINT TY		
COMPASS-32 (2-1) EXAMPLES 11/21/66 PAGE 1				10 2	000 #ARI1	H OVFLW/DIV	/ FAULT	- NOT REPEAT	*DIVIDE FAULT
COMPASS=32 (2+1) EXAMPLES 11/21/66 PAGE 1				11 4	000 SEAR	CH/MOVE COM	PLETE S/M	S/M BUSY	#ACO FAULT
COMPASS COOING TECHNIQUES				• I	NTERNAL FA	ULTS CLEARE	D BY SENSI	NG	
COMPASS COOING TECHNIQUES									
COMPASS COOING TECHNIQUES									
COMPASS COOING TECHNIQUES									
COMPASS COOING TECHNIQUES									
COMPASS COOING TECHNIQUES									
COMPASS COOING TECHNIQUES									
COMPASS COOING TECHNIQUES									
COMPASS COOING TECHNIQUES	COMPASS-32	(2.1)	EX	AMPLES					11/21/66 PAGE 1
			_						****************

}	COMPASS-32	(2.1)		EXAMPLES				11/21/66	PAGE	11
				*****	******		*********	**********	******	****
,				*****		- COMPASS CODING	TECHNIQUES -			
				*****		********	*****	**********	******	****
						ASSEMBLY OF CO	NSTANTS			
	00244		00000001		OCT	1,2,-2,50,=77				
	00245 00246		00000002 77777775							
	00247		00000050							
	00250		77777700							
	00251		00000001		DEC	1.2.5050.99.98	7454			
	00252		00000005			1124304-30177476	1054			
	00253		00000065							
	00254		77777715							
	00255		00000143							
	00256		03611006							
	00257		00000000		DECD	1,-1,98,-1.,98.,	9.8			
	00260		00000001							
	00261		7777777							
	00262		7777776							
	00263		00000000							
	00264		00000142							
	00265		57763777							
	00266 00267		7777777							
	00270		20076100							
			00000000							
	00271 00272		20044714 63146315							
	00272		44256262		BCD	2.MESSAGE				
	00274		21272560		BCU	2 MESSAUE				
	00275		442562		BCD+C	3.MES				
	002753		62		BCD+C	5.SAGE				
	00276		21272560			3,5402				
	00277		77304643	HOLMSG	VFD	06/77,H18/HOL,09	/n.Aī5/HOLMSG	CZ4 /HOLMSG		
	00300		00000277				, o sur jos ma g med	,,		
	00301		00001374							
•						STORAGE RESERVA	TION			
,	00302			TOM	8Ss	3				
	00305			TOMC	BSS+C	3				
	003053			TOMCI	BSS+C	1				
,	00306	20000302	20 0 P00302	0	LDA	TOM				
	00307	22001424	22 0 P00305	0	LACH	TOMC				

```
11/21/66 PAGE
                                                                                                                                                                                                                             12
                                                                        EXAMPLES
         COMPASS-32
                                    (2.1)
                                                                                                                            ADDRESSING MODES
                                                                                                                                                                                                                                                                •
                                                                                                                                            ABSOLUTE
                       00311 20000012 20 0 00012 0
                                                                                                     LDA
                                                                                                                         10
                      UU311 20000012 20 0 00012 0
00312 20000010 20 0 00010 0 SYMR1
00313 20077740 20 0 77744 0 SYMR2
00314 2000001 20 0 00001 0
00315 20000025 20 0 00025 0
                                                                                                     LDA
LDA
LDA
LDA
                                                                                                                         108
                                                                                                                         -378
SYMB2-SYMB1
ADRS
258
                                                                                                                                                                                                                                                                •
                                                                                    ADRS
                                                                                                                                                                                                                                                                •
                                                                                                                                            RELOCATABLE
                                                                                                                                                                                                                                                                •
                       00316 20000317 20 0 P00317 0 00317 20000321 20 0 P00321 0 TEMP 00320 20000317 20 0 P00317 0 00317 0 TEMP
                                                                                                                         TEMP
                                                                                                     LDA
                                                                                                     LDA
LDA
EQU
                                                                                                                         TEMP+2
TEMP1
TEMP
                                                                                                                                                                                                                                                                •
                                                                                   TEMP1
                                                                                                                                            LITERALS
                                                                                                                                                                                                                                                                •
                       00321 20000361 20 0 P00361 0
00322 25000362 25 0 P00362 0
00323 25000364 25 0 P00364 0
00324 20000360 20 0 P00360 0
00325 25000366 25 0 P00366 0
00326 20000357 20 0 P00357 0
00327 25000370 25 0 P00370 0
                                                                                                                          =09
                                                                                                     LOA
                                                                                                                         =209
=209.
=077777777
=20737373737373737373
=2HARCDEFGH
                                                                                                     LDAQ
LDAQ
LDA
                                                                                                                                                                                                                                                                •
                                                                                                     LDAG
LDA
LDAG
                                                                                                                                                                                                                                                                 •
                                                                                                                                             SPECIAL CHARACTERS
00330 20000330 20 0 P00330 0
00331 20000332 20 0 P00332 0
00332 20000330 20 0 P00330 0
00333 20077777 20 0 777777 0
                                                                                                      LDA
                                                                                                                                                                                                                                                                 •
                                                                                                      LDA
LDA
                                                                                                                         *+2
**
                                                                                                                                                                                                                                                                 •
                                                                                                                                             INTERCHANGE OF WORD AND CHARACTER ADDRESSES
                                                                                    WORDADRS EQU
CHARADR1 EQU+C
CHARADR2 EQU+C
                                                               00334
                                                               00334
003343
                                                                                                                          *+3
                                                                                                                          CHARADR1
CHARADR2
                         00334 20000334 20 0 P00334 0
                    T 00335 20000334 20 0 P00334 0 00336 22001560 22 0 P00334 0
                                                                                                                                                                  TRUNCATION ERROR
                                                                                                       LÜA
                                                                                                                                                                                                                                                                 •
                                                                                                      LACH
                                                                                                                           #ORDADRS
                                                                                                                                                                                                                                                                  .
                                                                                                                                                                                                                                                                  •
                                                                                                                                                                                                                                                                  •
                                                                                                                                                                                                                                                                  •
 •
                                                                                                                                                                                            11/21/66 PAGE
                                                                                                                                                                                                                            13
                                                                              EXAMPLES
            CUMPASS+32
                                       (2.1)
                                                                                                                                              SYMBOL EQUATIONS
                                                                                                                           252528
                                                                 25252
                                                                                      ADDRESS EQU
                                                                                                                            ADDRESS
                                                                 25252
052523
00003
                                                                                                        EWIJ
EWU+C
                                                                                                                                                                                                                                                                  lacktrian
                                                                                                                            M+1
                                                                                                        EQU
EQU
                                                                                                                                                                                                                                                                   •
                                                                                      81
                                                                 00001
                                                                 00001
00002
00003
052523
05254
00014
00077
12345
053523
052523
00012
00006
25252
25321
                                                                                      B2
B3
FCA
LCA
                                                                                                        EQIJ
                                                                                                        EGII+C
EGII+C
                                                                                                                            ₹+5
  12
778
123453
FCA+256
FCA
                                                                                                        EQU
                                                                                                        FUCA
FSCA
FL
CH
FWA
LWA
CC
FC
                                                                                                                           4+39
77778
70078
228
                                                                                                                                                                                                                                                                   •
                                                                  25321
07777
07007
                                                                  00022
                                                                  00002
                                                                                       INTERVAL ENU
                                                                                                                            238
```

CUMPASS-32	(2•1)	EXAM	PLES				/21/66 PAGE 14
A 00337	50000000 50 0	00000 *			COMPASS ASSEMBLY		
- 44331		11 10 10 to to		LUA	288	ADDRESS FORMAT	ERROR
C 00340 00341	20000005 20 0			COMMON LOA OCT PRG	5	ATTEMPT TO ASS	
DA 00342 00343 D 00344	20000343 20 0 00000 00000	001	GEORGE GEORGE	LUA OCT DEC	GEORGE 1	MULTIPLY DEFIN	En SYMBOL
L 00345	20000005 20 0	0 0005 U	123	LUA	5	LOCATION FIELD	E8808
M 00346	00000005 00 0	00005 0		LDA+1	5	OPERATION MODI	
0 00347	00000000 00 0	00000 0		LIn	5	OPERATION CODE	
U 00350	20000000 20 0	00000 0		LUA	SAM	UNDEFINED SYMB	
T 00351	20000352 20 0	P00352 0		LUA	CHAR	THUNCATION ERR	
		003523	CHAR	EWIJOC	*+3		
L 00353 U 00354	22001670 22 0 20000353 20 0 01000000 01 0 01000000 01 0	P00353 0 9	****** ******	LITERAL IN LACH SEARRASSESSESSESSESSESSESSESSESSESSESSESSESSE	N A CHARACTER ADDHE =012 ==012	ESS INSTRUCTION ***********************************	********************
				E NO.			
				END			
LITERALS 00356	00000012		00357		21222324	00360	7777777
00361 00362	00000011	0 00000 00011	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		00364		7777777
00366	73737	37373737373			00370	2004440000 2122232425	2K2730
				NUMBER OF L	INES WITH DIAGNOST	105 13	
							
	(2.1)	EXAMP	 PLES	 -		11/	/21/06 PAGE 1
ADDRESS ADRS	25252 00025	EXAMP	 PLES	P25252 P00315			
ADDRESS	25252	Ехамр	 PLES	P00315 P00000 P00006	P00001 P00007	P00nn4 P00n10	P00005 P00011
ADDRESS ADRS	25252 00025	Examp	 LES	P00315 P00000 P00006 P00012 P00020	P00007 P00015 P00021	P00004 P00010 P00016 P00022	P00005
ADDRESS ADRS	25252 00025	EXAMP	 PLES	P00315 P00000 P00006 P00012 P00020 P00024 P00030	P00007 P00015 P00021 P00025 P00031	P00nn4 P00n10 P00n16 P00n22 P00n26 P00n32	P00005 P00011 P00017 P00023 P00027
ADDRESS ADRS	25252 00025	EXAMP		P00315 P00000 P00006 P00012 P00020 P00030 P00030 P00030	P00007 P00015 P00021 P00025 P00031 P00035	P00014 P00011 P00016 P00022 P00026 P00032 P00042 P00056	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060
ADDRESS ADRS	25252 00025	EXAMP		P00315 P00000 P00012 P00020 P00020 P00024 P00030 P00034 P00050 P00061 P000117	P00007 P00015 P00021 P00025 P00031 P00035 P00055 P00073 P00123	P00004 P00010 P00016 P00022 P00032 P00042 P00056 P00113 P00113	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125
ADDRESS ADRS	25252 00025	EXAME		P00315 P00000 P00012 P00024 P00024 P00030 P00034 P00050 P00051 P00117 P00126 P000134	P00007 P00015 P00021 P00025 P00031 P00035 P00055 P000123 P00123 P00127 P00137	P00004 P00010 P00016 P00026 P00032 P00042 P00056 P00113 P00124 P00130 P00142	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145
ADDRESS ADRS B	25252 00025 00003	E X A MF	PLES	P00315 P00000 P00006 P00012 P00024 P00030 P00034 P00050 P000127 P00126 P00134 P00144 P0010002	P00007 P00015 P00025 P00025 P00031 P00035 P00055 P00123 P00127 P00137 P00147 P000147	P00004 P00010 P00016 P00022 P00026 P00036 P00056 P00113 P00124 P00130 P00142 P00150 P00160	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131
ADDHESS ADMS B B1 B2 B3	25252 00025 00003	Ехамр	PLES	P00315 P00006 P00016 P00012 P00020 P00030 P00034 P00051 P00117 P00126 P00134 P00144 P00002 P00003	P00017 P00015 P00025 P00025 P00031 P00035 P00073 P00123 P00127 P00137 P00147 P00014 P00014	P00004 P00010 P00012 P00022 P00032 P00042 P00056 P00113 P00124 P00130 P00142 P00150	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145
ADDRESS ADRS B	25252 00025 00003 00001 00002 00003 00023 07007	EXAMP	PLES	P00315 P00000 P000012 P00020 P00020 P00030 P00030 P00031 P00117 P00117 P00126 P00134 P00002 P00002 P00004 P000151 P00166	P00017 P00015 P00021 P00025 P00031 P00035 P00073 P00123 P00127 P00137 P00147 P00014 P00013 P00013	P00004 P00010 P00016 P00022 P00026 P00032 P00042 P00056 P00113 P00124 P00130 P00142 P00150 P00130 P00130	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C	25252 00025 00003 00001 00002 00003 00023	EXAMP	°LES	P00315 P00007 P00012 P00020 P00030 P00030 P00030 P000140 P000150 P00003 P00040 P00150 P00166 P00166 P00166	P00017 P00015 P00025 P00025 P00031 P00035 P000173 P00127 P00127 P00147 P00014 P000154	P00014 P00015 P00015 P00025 P00032 P00032 P00056 P00113 P00124 P00130 P00142 P00150 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C	25252 00025 00003 00001 00002 00003 00023 07007 00006	Ехамр		P00315 P00000 P000006 P00012 P00020 P00034 P00050 P000117 P00117 P00126 P00002 P00000 P00151 P00166 P00166 P00200 P00214 P00226	P00017 P00015 P00021 P00025 P00031 P00035 P00055 P000123 P00127 P00137 P00147 P00014 P00013 P000154	P00004 P00010 P00016 P00022 P00026 P00032 P00042 P00056 P00113 P00124 P00130 P00142 P00150 P00036 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145 P00145
B1 B2 B3 C CC CH	25252 00025 00003 00001 00002 00003 00023 07007 00006	EXAMP	?LES	P00315 P00006 P00012 P00020 P00030 P00030 P00031 P00017 P00126 P00134 P00050 P00002 P00006 P00151 P00166 P00166 P00200 P00200	P00007 P00015 P00025 P00025 P00031 P00035 P00073 P00123 P00127 P00137 P00147 P00014 P00014 P000154 P000154	P00014 P00010 P00016 P00022 P00026 P00036 P00036 P00113 P00124 P00130 P00142 P00150 P00036 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C CC CH CHARADH1	25252 00025 00003 00001 00002 00003 00023 07007 00006 P00334 0 P00334 0 P00334 0	Ехамр	PLES	P00315 P00000 P00012 P00020 P00020 P00030 P00031 P000131 P00117 P00134 P00134 P00166 P00166 P00166 P00166 P00200 P00214 P00224 P002351 P00334 P00335	P00017 P00025 P00025 P00025 P00031 P00035 P000173 P00127 P00127 P00137 P00147 P00014 P00013 P00014 P00015	P00014 P00010 P00016 P00022 P00022 P00032 P00042 P00056 P00113 P00124 P00130 P00142 P00150 P00036 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C CC CH CHARADH1 CHARADH2 FC	25252 00025 00003 00002 00002 00003 07007 00006	EXAMP	PLES	P00315 P00006 P00012 P00020 P00020 P00030 P00031 P000136 P00117 P00134 P00136 P00136 P00166 P00166 P00200 P00200 P00214 P00235 P00334 P00335 P00170 P00335 P00170 P00335	P00017 P00025 P00025 P00025 P00031 P00035 P00027 P000123 P00127 P00137 P00147 P00014 P00013 P00014 P00015 P000227	P00014 P00010 P00016 P00022 P00026 P00032 P00042 P00056 P00113 P00124 P00130 P00142 P00150 P00036 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C CC CH CHARADH1 CHARADH2 FCA	25252 00025 00003 00001 00002 00003 00023 07007 00006 P00334 0 P00334 0 P00334 0	EXAMP	°LES	P00315 P000126 P000127 P000126 P000126 P000130 P000130 P000136 P000136 P000136 P00151 P00114 P00151 P00151 P00151 P00151 P00151 P00151 P00151 P00151 P00151	P00017 P00025 P00025 P00025 P00031 P00035 P000173 P00123 P00127 P00137 P00147 P00014 P00013 P00014 P000154 P00227	P00004 P00010 P00016 P00026 P00032 P00042 P00056 P0013 P00124 P00130 P00142 P00150 P00036 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00105 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C CC CH CHARADH1 CHARADH2 FC FCA	25252 00025 00003 00003 00003 00023 07007 00006 P00334 P00334 P00334 P0032 05252 3	ЕХАМБ		P00316 P00016 P00017 P00072 P00072 P00073 P00030 P00017 P00117 P00117 P00117 P00166 P00003 P00061 P00166 P00214 P00166 P00214 P00166 P00351 P00166 P00351 P00166 P00351 P00351 P00351 P00351 P00351 P00351 P00351 P00177 P00157 P00157 P00157 P00157 P00157 P00043	P00017 P00025 P00025 P00025 P00031 P00035 P000173 P00127 P00127 P00147 P00014 P00013 P00014 P000154 P000170 P00203 P00227	P00004 P00010 P00016 P00026 P00032 P00042 P00056 P0013 P00124 P00130 P00142 P00150 P00036 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00105 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C CC CHAR CHARADH2 FC FCA FL FSCA FWA GEUNGE HOLMSG	25252 00025 00003 00003 00003 00003 00003 00006 P00334 0 P00334 3 00022 05252 3 05352 3 00012 05252 3	EXAMP		P00315 P00000 P000016 P00012 P00020 P00030 P00031 P000134 P00017 P00134 P001151 P00166 P00166 P00166 P00200 P00200 P00200 P00200 P00351 P003552 P00177 P00356 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357 P00157 P00357	P00017 P00025 P00025 P00025 P00031 P00035 P000173 P00127 P00127 P00137 P00147 P00014 P00013 P000154 P000154 P000157 P00156 P00227	P00004 P00010 P00016 P00026 P00032 P00042 P00056 P0013 P00124 P00130 P00142 P00150 P00036 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00105 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C CC CH CHAR CMARADH1 CHARADH2 FC FCA FUCA FLCA FSCA FWA	25252 00025 00003 00003 00002 00003 00023 07007 00006 P00334 0 P00334 0 P00334 0 P00334 3 00022 05252 3 25252 25252 3 25252 3			P00315 P000020 P000120 P000120 P00030 P00031 P000130 P000130 P000130 P001170 P00151 P00166 P00166 P00200 P00200 P00200 P00200 P00334 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00355 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P00355 P00157 P0	P00017 P00015 P00021 P00025 P00031 P00035 P000173 P000173 P000177 P000147 P000147 P00014 P00013 P000170 P000277 P00154 P000170 P00277 P00157 P00157 P00214 P00277 P00217	P00004 P00010 P00016 P00022 P00036 P00036 P00113 P00124 P00130 P00142 P00150 P00036 P00037 P00037 P00037	P00005 P00011 P00017 P00027 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145 P00165
B1 B2 B3 C CC CH CHARADH1 CHARADH2 FC FCA FUCA FLCA FUCA FLCA FUCA FUCA FUCA FUCA FUCA FUCA FUCA FU	25252 00025 00003 00003 00003 00023 07007 00006 P00334 0 P00334 0 P00334 3 00022 05252 3 00012 05252 3 25252 P00343 P00343 P00343 P00340 P0034			P00315 P00157 P00157 P00166 P00170 P0	P00017 P00017 P00025 P00025 P00031 P00035 P000173 P000173 P000177 P000147 P00014 P00013 P000170 P000170 P000277 P00154 P00170 P00227 P00157 P00154 P00227 P00157 P00227	P00004 P00010 P00016 P00022 P00032 P00032 P00042 P00056 P00113 P00124 P00130 P00142 P00150 P00036 P00037	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145 P00165 P00175 P00211 P00225 P00041 P00206
B1 B2 B3 C CC CH CHARADH1 CHARADH2 FCA FLA FSCA FWA GEUNGE HULMSG INTERVAL	25252 00025 00003 00003 00003 00003 00003 00006 P00334 0 P00334 0 P00334 3 00022 05252 3 25252 P00343 P00323 05252 3 25252 P00343 P00327 00002 00014			P00315 P00042 P00157 P00166 P00166 P00170 P00777 P00177 P0	P00017 P00025 P00025 P00025 P00031 P00035 P00027 P000123 P00127 P00137 P00147 P00014 P00013 P00027 P00154 P00227 P00157 P00227 P00157 P00227 P00157 P00227 P00157 P00216 P00277 P00163 P00277 P00163 P00277 P00164 P00277 P001654 P00277 P001654 P00277 P00163 P00176	P00014 P00010 P00016 P000122 P00022 P00036 P00013 P00124 P00130 P00142 P00150 P00036 P00037 P00172 P00206 P00224 P00230 P00172 P00276 P00276 P00276 P00276 P00276 P00276 P00276 P002772	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145 P00165 P00175 P00211 P00225 P00206
B1 B2 B3 C CC CH CHARADH1 CHARADH2 FC FCA FUCA FL FSCA FWA GEUNGG INTERVAL K LCA LWA	25252 00025 00003 00003 00003 00003 07007 00006 P00334 3 00022 05252 3 00012 05252 3 25252 25252 3 25252 3 25252 3 25252 00014			P00315 P00016 P00017 P00017 P00017 P00018 P00000 P00000	P00017 P00015 P00025 P00025 P00031 P00035 P00037 P000173 P00127 P00137 P00147 P00014 P00013 P00014 P00015 P00027 P00154 P00227 P00157 P00227 P00157 P00214 P00217 P00227 P00154 P00277	P00004 P00010 P00016 P00012 P00022 P00026 P00036 P00013 P00124 P00130 P00142 P00136 P00037 P00172 P00224 P00230 P00172 P00172 P00172 P00172 P00172 P00172 P00172	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145 P00165 P00175 P00211 P00225 P00206 P00206 P00001
B1 B2 B3 C CC CH CHARADH1 CHARADH2 FC FCA FUCA FL FSCA FWA GEUNGE HOLMSG INTERVAL K LCA LWA	25252 00025 00003 00003 00003 00003 00003 00006 P00334 0 P00334 0 P00334 3 00022 05252 3 25252 P00343 P00323 05252 3 25252 P00343 P00277 00002 00014			P00316 P00016 P00017 P00017 P00017 P00017 P00017 P00017 P0017 P0007 P000	P00017 P00025 P00025 P00025 P00031 P00035 P000173 P00127 P00127 P00127 P00147 P00014 P00013 P00027 P00154 P00027 P00277 P00157	P00014 P00010 P00016 P00012 P00022 P00026 P00032 P00042 P00056 P00113 P00124 P00130 P00142 P00150 P00130 P00172 P00224 P00230 P00172 P00277 P00172 P00172 P00172 P00172 P00172 P00172 P00172 P00172	P00005 P00011 P00017 P00023 P00027 P00023 P00047 P00060 P00114 P00125 P00131 P00145 P00165 P00175 P00211 P00225 P00206 P000130 P00206 P000130 P000211 P000206
B1 B2 B3 C CC CH CHARADH1 CHARADH2 FC FCA FUCA FL FSCA FWA GEUNGE HOLMSG INTERVAL K LCA LWA	25252 00025 00003 00003 00003 00003 00003 00006 P00334 0 P00334 0 P00334 3 00022 05252 3 25252 P00343 P00323 05252 3 25252 P00343 P00277 00002 00014			P00316 P00016 P00017 P00007 P00007 P000000 P00000 P00000 P00000 P00000 P00000 P00000 P00000 P00000 P00000 P000000	P00017 P00025 P00025 P00025 P00031 P00035 P000173 P00127 P00127 P00147 P00014 P00015 P000170 P00203 P00227 P00157 P00227 P00157 P00214 P00277 P00154 P00277 P00154 P00277 P00157 P00214 P00277 P00157 P00214 P00277 P00157 P00214 P00277 P00157 P00214 P00277 P00157 P002157 P002157 P00214 P00275 P00015	P00004 P00012 P00012 P00022 P00032 P00032 P00013 P00124 P00130 P00142 P00130 P00142 P00130 P00172 P00206 P00224 P00230 P00172 P00276 P00277 P00172 P00172 P00172 P00172 P00172 P00172 P00172 P00172	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P000131 P00145 P00155 P00131 P00145 P00165 P00175 P00211 P00225 P00031 P00007 P00005 P00017 P00005 P00017 P00005 P00017 P00003 P00007 P00003
BI B2 B3 C CC CH CHAHADH2 FCA FL FSCA FWA GEUNGE HOLMSG INTERVAL K	25252 00025 00003 00003 00003 00003 00003 00006 P00334 0 P00334 0 P00334 3 00022 05252 3 25252 P00343 P00323 05252 3 25252 P00343 P00277 00002 00014			P00315 P00042 P00126 P00126 P00127 P00131 P00136 P00137 P00157	P00017 P00017 P00017 P00025 P00031 P00035 P000173 P00173 P00177 P00175 P00077	P00004 P00010 P00016 P00022 P00036 P00036 P00013 P00124 P00130 P00142 P00150 P00036 P00037 P00172 P00206 P00224 P00230 P00172 P00706 P00225 P00706	P00005 P00011 P00017 P00023 P00027 P00033 P00047 P00060 P00114 P00125 P00131 P00145 P00165 P00175 P00211 P00225 P00206 P00015 P00001 P00001 P00001 P00001 P00001 P00007 P000027

•

•	COMPASS-32 (2.1)	EXAMPLES	P00111 P00146 P00163	P00112 P00147 P00164	P00113 P00150 P00165	11/71/66 PAGE P00114 P00162 P05252	s	
•	R 05252 3		P25252 P00002	P25321 P00003	P00013	P00014		
•	SAM 00000	UNDEFINED	P00242 P00350	P05252	P05254			
	SYM 00000	UNDEFINED	P00354 P00314					
•	SYMB1 P00312 SYMB2 P00313	OFF THED	P00314					
•	SYMBOL 00000 TEMP P00317	UNDEF INED	P00355 P00316	P00317	P00317			
_	TEMP1 P00317 TOM P00302		P00320 P00306					
•	TOMC P00305		P00307 P00310					
	TOMC1 P00305 3		P00051 P00055	P00052 P00056	P00053	P00054		
•	WORDADRS P00334		P00336		200220	P00231		
•	X 07777		P00236 P00232	P00227 P00233	P00230 P00236	P00237		
	Y 12345		P00115 P00121	P00116 P00122	P00117 P00123	P00120 P00124		
•			P00125	P00132 P00136	P00133 P00137	P00134 P00140		
			P00135 P00141	P00142	P00143	P00144		
•	LITERAL P00366	737373737373737373	P00145 P00325					
	LITERAL P00360 LITERAL P00362	7777777 0000000000000011	P00324 P00322					
	LITERAL P00361	00000011	P00321 P00352					
•	LITERAL P00356 LITERAL P00364	00000012 20044400000000000	P00323					
	LITERAL P00370 LITERAL P00357	2122232425262730 21222324	P00327 P00326					
•								
	SYMBOLS NOT REFERENCED							
	BCDBOXS EXT	FDPBOXS EXT				•		
•								
-								
•								
_								
•								
•								
•								
•								
1		6				11/21/66 PAGE	1	
•	COMPASS-32 (2.1)	EXAMPLE 20 (A	AVERAGE)			11/21/00 PAGE	1	
•	ENTRY-POINT SYMBOLS							
	START 0000	0						
•				•				
	LENGTH OF SUBPROGRAM	00016 00000						
•	LENGTH OF COMMON LENGTH OF DATA	00000						
_								
•								
•								

```
COMPASS-32
                                            (2.1)
                                                                                     EXAMPLE 20 (AVERAGE)
                                                                                                 THIS PROGRAM WILL COMPUTE THE AVERAGE OF THREE POSITIVE NUMBERS
                            ENTRY
                                                                                                                                      START
                                                                                                                                                                                  EXIT TO MONITOR PROGRAM
LOAD FIRST NUMBER INTO A
AUD SECOND NUMBER
ADD THIRD NUMBER
CUNVERT TO A 4R BIT VALUE
DIVIDE BY THREE
STORE RESULT
STOP
GO TO EXIT ON RESTART
CONSTANT (100 OCTAL)
CONSTANT (20 OCTAL)
CONSTANT (20 OCTAL)
CUNSTANT (3)
RESERVED LOCATION FOR RESULT
                                                                                                                                       I BMUN
SBMUN
FBMUN
                                                                                                                  LD4
                                                                                                                  ADA
SHAW
OVA
STA
UCS
OCT
OEC
OCT
OEC
BSS
END
                                                                                                                                       -24
THREE
AVG
                                                                                                                                      START
100
9
20
3
                                                                                             NUMB1
NUMB2
NUMB3
THREE
                            00013
00014
00015
                                                                                              AVG
                                                                                                                                       START
                                                                                                               NUMBER OF LINES WITH DIAGNOSTICS
                                                                                                                                                                                                                                                                                     •
            CUMPASS-32
                                          (2.1)
                                                                                    EXAMPLE 20 (AVERAGE)
                                                                                                                                                                                                          11/21/66 PAGE
                                                                                                                                                                                                                                                                                     •
                                                 P00015
P00011
P00012
P00013
P00000
P00014
                                                                                                                     P00006
P00001
P00002
P00003
P00010
P00005
                        NUMBI
NUMBI
NUMBI
NUMBI
START
THREE
•
```

```
A-11
```

11/21/66 PAGE

```
ENTRY-POINT SYMBOLS
START 00000
                     LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
                                                                                                 00045
00000
                                                                                                                                                                                                                                                                                                                                                                                   •
 •
                 CUMPASS-32
                                                        (2.1)
                                                                                                               EXAMPLE 19A (CR2PR)
                                                                                                                                                                                                                                                                              11/21/66 PAGE
                                                                                                                              ENTRY START
THIS PROGRAM WILL READ ONE HOLLERITH CARD AND COPY IT ON THE LINE PRINTER
                                   THIS :

00000 01077777 01 0 77777 0 START
00001 77012000 77 0 12000 REPFAT
00002 01000001 01 0 P000001 0
00003 74000045 74 0 P00045 0
00004 10000021 10 0 P000021 0
00005 01000003 01 0 P00003 0
00006 77310002 77 0 10002 3
00007 01000006 01 0 P00006 0
00010 77013000 77 0 13000 0
00011 01000010 10 P00001 0
00012 76000045 76 0 P00045 0
00013 10000021 10 0 P00021 0
00014 01000012 01 0 P00021 0
00015 77310004 77 0 10004 3
00016 01000015 01 0 P00015 0
00017 77770000 77 1 70000 3
00020 01000001 01 0 P00001 0
                                                                                                                                                                                                                                                                                                                                                                                   •
                                                                                                                                                     UJP
                                                                                                                                                                                                                                            ESTABLISH CONNECTION TO CR
REJECT INSTRUCTION
INITIATE INPUT OF ONE CARO
                                                                                                                                                    CON
                                                                                                                                                                                 20008.1
*-1
                                                                                                                                                                                                                                                                                                                                                                                   •
 1.BUF.BUF+20
                                                                                                                                                     INPW
                                                                                                                                                                                                                                            REJECT INSTRUCTION
SENSE TO SEE IF CHANNEL 1 IS BUSY
BUSY - THEN KEEP CHECKING
NOT BUSY - THEN CONNECT TO PR
REJECT INSTRUCTION
INITIATE OUTPUT OPERATION
                                                                                                                                                     QUP
SNI
QUD
                                                                                                                                                                                 *-2
2,1
*-1
                                                                                                                                                                                                                                                                                                                                                                                   •
                                                                                                                                                     CON
UJP
OUT#
                                                                                                                                                                                 30008.1
*-1
1,8UF,8UF+20
                                                                                                                                                                                                                                            REJECT INSTRUCTION
SENSE TO SEE IF CHANNEL 1 IS BUSY
BUSY - THEN KEEP CHECKING
NOT BUSY - THEN STOP
REPEAT ON RESTART
                                                                                                                                                                                 *•2
4•1
*•1
                                                                                                                                                     UJP
UJP
UCS
UJP
BSS
END
                                                                                                                                                                                                                                                                                                                                                                                    •
                                                                                                                                                                                 REPEAT
                                                                                                                                                                                  20
Start
                                                                                                                                                  NUMBER OF LINES WITH DIAGNOSTICS
 •
 •
```

EXAMPLE 19A (CRZPR)

CUMPASS-32

BUF REPEAT	P00021	EXAMPLE 19		P00003		11/21/66 PAGE P00012	1
SYMBOLS NOT							
*ST/	ART P00000						
						•	
COMPASS=32	(2.1)	EXAMPLE 21	(CODE)			11/21/66 PAGE	1
COMPASS=32	(2.1)	EXAMPLE 21	(CODE)			11/21/66 PAGE	1
ENTRY-POINT	SYMBOLS	EXAMPLE 21	(CODE)			 11/21/66 PAGE	1
	SYMBOLS	EXAMPLE 21	(CODE)]1/2]/66 PAGE	1
ENTRY-POINT IN•OUT	SYMBOLS 00000		(CODE)			11/2]/66 PAGE	1
ENTRY-POINT	SYMBOLS 00000	EXAMPLE 21 00014 00000	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)]1/2]/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)		·	11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1
ENTRY-POINT IN.OUT	SYMBOLS 00000	00014	(CODE)			11/21/66 PAGE	1

```
EXAMPLE 21 (CODE)

ENTRY
IN.OUT

THIS PROGRAM WILL HANG IN A LOOP UNTIL THE SELECTIVE JUMP KEYS ARE
SET TO A CODE OF 35 OCTAL. PROGRAM REPEATS ON RESTART.
                                                                                                                                                                                                                                                                                                                             lacktriangle
COMPASS-32
                                   (2.1)
                                                                                                                                                                                                                                                                                                                             •
               00000 01077777 01 0 777777 0 IN-OUT
00001 00100003 00 0 P00003 1 LOOP
00002 01000001 01 0 P00001 0
00003 00200001 00 0 P00001 2
00004 00300006 00 0 P00006 3
00005 01000001 01 0 P00001 0
00006 0040010 00 1 P00001 0
00007 01000001 01 0 P00001 0
00010 00500012 00 1 P00001 1
00011 01000001 01 0 P00001 0
00012 00600001 00 1 P00001 0
00012 00600001 00 1 P00001 0
                                                                                                                                              **

*+2

LOOP

*+2

LOOP

*+2

LOOP

*+2

LOOP

LOOP

LOOP

IN.OUT+1

IN.OUT
                                                                                                                                                                                                                                                                                                                             •
                                                                                                                     SJ1
SJ2
SJ3
UJP
SJ4
UJP
SJ5
UJP
SJ6
HLT
END
                                                                                                                                                                                                   TEST BIT 0
                                                                                                                                                                                                   TEST BIT 1
TEST BIT 2
                                                                                                                                                                                                                                                                                                                            •
                                                                                                                                                                                                    TEST BIT 3
                                                                                                                                                                                                                                                                                                                            •
                                                                                                                                                                                                    TEST BIT 4
                                                                                                                                                                                                   TEST BIT 5
                                                                                                                   NUMBER OF LINES WITH DIAGNOSTICS
                                                                                                                                                                                                                                                                                                                            •
                                                                                                                                                                                                                                                                                                                            •
                                                                                                                                                                                                                                                                                                                            •
                                                                                                                                                                                                                                                                                                                           •
                                                                                                                                                                                                                                                                                                                           •
COMPASS-32
                                   (2.1)
                                                                                     EXAMPLE 21 (CODE)
                                                                                                                                                                                                                                11/21/66 PAGE
                                                                                                                                                                                                                                                                                                                            •
              IN.OUT
                                            P00000
P00001
                                                                                                                             P00013
P00002
P00011
                                                                                                                                                                    P00003
P00012
                                                                                                                                                                                                            P00005
                                                                                                                                                                                                                                                     P00007
                                                                                                                                                                                                                                                                                                                            •
                                                                                                                                                                                                                                                                                                                            •
```

A-14

```
COMPASS-32
                              (2.1)
                                                                              EXAMPLE 22 (MEG.TEST)
                                                                                                                                                                                                                      11/21/66 PAGE
     ENTRY-POINT SYMBOLS
START 00000
     LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
                                                                      00014
                                                                      00000
                                                                                                                                                                                                                                                                                                             •
  COMPASS-32 (2.1)
                                                                                 EXAMPLE 22 (MEG.TEST)
                                                                                                                                                                                                                       11/21/66 PAGE
                                                                                              ENTRY START
THIS PROGRAM WILL COUNT THE NUMBER OF EVEN LOCATIONS IN MEMORY (BK)
WITH 35 IN CHARACTER POSITION 2.
                   00000 01077777 01 0 77777 0 START
                                                                                                                  UJP
                  00000 01077777 01 0 77777 0 START UJP
00001 14300000 14 0 00000 3 ENT
00002 14117776 14 0 17776 1 ENT
00003 14603500 14 1 03500 2 ENA
00004 14707700 14 1 07700 3 REENTER MED
00006 06200000 06 0 00000 2 REENTER MED
00007 15300001 15 0 00001 3 UJP
00010 01000005 01 0 P00005 0 UJP
00011 77770000 77 1 70000 3 STOP UCS
00012 01000000 00 0 P00001 1
00013 01000001 01 0 P00001 1 UJP
                                                                                                                                                                                        CLEAR COUNTER (A3)
SET A1 TO 177768
SET SEARCH PATTERN IN A
SET SEARCH ***
** NOT FOUND ** THEN STOP
** FOUND ** THEN INCREASE COUNT
AND CONTINUE SEARCH
DISPLAY RESULTS IN B3
EAIT IF JUMP KEY 1 IS SET
OTHERWISE REPEAT
                                                                                                                                         0+3
177768+1
                                                                                                                                         35008
77008
0.2
STOP
1.3
REENTER
                                                                                                                                         START
START+1
START
                                                                                                                  SJ1
UJP
END
                                                                                                                NUMBER OF LINES WITH DIAGNOSTICS
```

COMPASS-32 (2-1) REENTER P00005 START P00001 STOP P0001)	(MEW.FEST) P00010 P00012 P00006	P00013	11/21/66	PAGE 1	
\$10P P00011	ı	LAAAAA				
COMPASS=32 (2.1)	EXAMPLE 23	(TY•0UT)		11/21/66	PAGE 1	
COMPASS-32 (2.1) ENTRY-POINT SYMBOLS TY-OUT 00		(TY•nUT)		11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY+OUT 00	000	(TY•0UT)		11/21/66	PAGE 1	
	000	(TY•0UT)	<u>.</u>	11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY+OUT 00	000	(TY•0UT)		11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY+OUT 00	000	(TY•nUT)		11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY+OUT 00	000	(TY•0UT)		11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY+OUT 00	000	(TY•0UT)		11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY+OUT 00	000	(TY•0UT)		11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY+OUT 00	000	(TY.OUT)		11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY-OUT 00	000	(TY•nUT)		11/21/66	PAGE 1	
ENTRY-POINT SYMBOLS TY-OUT 00	000	(TY•oUT)		11/21/66	PAGE 1	

```
CUMPASS-32 (2.1)
                                                         EXAMPLE 23 (TY.OUT)
                                                                                                                                                  11/21/66 PAGE
                                                                   ENTRY TY.OUT
THIS IS A CLOSED SUBROUTINE FOR TYPING MESSAGE ON THE CONSOLE TY.
                                                                                CALLING SEQUENCE ECHA FCA (FIRST CHAR ADRS OF MSGE)
                                                                                                               ENU NUM CHARS (LENGTH OF MESSAGE)
RTJ TY-OUT
NEXT INSTRUCTION
                                                                                 NOTE TY.OUT MUST BE DECLARED FXTERNAL (EXT TY.OUT)
                  00000 01077777 01 0 77777 0 TY.OUT
00001 77600400 77 1 00400 2
00002 01000001 01 0 P00001 0
00003 53420023 53 1 20023 0
00004 53040000 53 0 40000 0
00005 53420033 53 1 20033 0
00006 77766000 77 1 60000 3
00007 01000000 01 0 P00000 0
                                                                               UJP
                                                                                                                               IS TY CURRENTLY BUSY
YES - THEN KEEP CHECKING
NO - THEN PLACE FCA IN REG 238
FURM LCA+1
PLACE LCA+1 IN BEG 33B
INITIATE OUTPUT
RETURN TO USFR
                                                                                 PAUS
UJP
TAM
                                                                                                4008
*-1
238
                                                                                TAM
TAM
CTO
UJP
END
                                                                                               338
                                                                                            TY.OUT
                                                                               NUMBER OF LINES WITH DIAGNOSTICS
•
        CUMPASS-32 (2.1)
                                                        EXAMPLE 23 (TY.OUT)
                                                                                                                                               11/21/66 PAGE 1
                                                                                                                                                                                                          •
                 TY-00T P00000
                                                                                 P00007
```

```
11/21/66 PAGE
         COMPASS-32
                                (2.1)
                                                                EXAMPLE 24 (DEMO)
                                                                                                                                                                                             1
            ENTRY-POINT SYMBOLS
LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
                                                         00614
                                                         00000
•
lacktriangle
                                                                                                                                                                                                                         •
          COMPASS-32
                                 (2.1)
                                                               EXAMPLE 24 (DEMO)
                                                                                                                                                              11/21/66 PAGE
                                                                                                       START
                                                                                      ENTRY
                     00000 01077777 01 0 77777 0 START
                                                                                                                                                                                                                         •
                                                                          THE FOLLOWING INSTRUCTIONS WILL INITIATE AN OUTPUT TO THE CONSOLE TY
                                                                                                                                          FIRST CHAR ADRS TO A
                                                                                       ECHA
                                                                                                       4SG
                      00001 11000034 11 0 P00007 0
                     00001 11000034 11 0 P00007 0
00002 53420023 53 1 20023 0
00003 11003060 11 0 P00614 0
00004 53420033 53 1 20033 0
00005 77760000 77 1 60000 3
                                                                                                                                          THEN TO REG FILE LOC 23B
LAST CHAR ADRS TO A
THEN TO REG FILE LOC 33B
INITIATE TYPE OUT
                                                                                       TAM
ECHA
TAM
CTO
                                                                                                       23B
MSGEND
                                                                                                       33B
                                                                                                                                                                                                                         •
                      00006 00000000 00 0 P00000 0
                                                                                       HLT
                                                                                                       START
                                                                                                                                          EXIT BACK TO SCOPE ON RESTART
                                                                          FOLLOWING IS THE MESSAGE
                                                                                                                                                                                                                          •
                      00007
                                              31602144
                                                                         MSG
                                                                                                       40.1 AM A CONTROL DATA 3200 COMPUTER. I AM
                                              31602144
60216023
46456351
46436024
21632160
03020000
60234644
47646325
51336031
                      00010
00011
00012
                      00013
                      00014
                      00015
00016
00017
                      00022
00022
                                              60214460
77575757
21602231
                                                                                       OCT
BCD+C
                                                                                                        77575757
                                                                                                        44.4 BINARY. FIXED WORD LENGTH. STORED PROGRAM.
                                              45215170
73602631
                      00023
                                              73602631
67252460
66465124
60432545
27633073
60626346
51252460
47514627
51214473
77575757
24312731
63214360
2346447
64632551
777775757
                                                                                                                                                                                                                          00025
                      00026
00027
00030
                      00031
                      00032
00034
00035
00036
00037
                                                                                       OCT
BCD+C
                                                                                                        77575757
16.DIGITAL COMPUTER
                       00040
                       00041
00042
                                                                                       OCT
                                                                                                        77775757
                       00043
                                               63302562
                                                                                        BCD+C
                                                                                                        28. THESE ARE MY SPECIFICATIONS
                                                                                                                                                                                                                           •
                       00044
                                               25602151
25604470
                      00046
00047
00050
                                               60624725
23312631
23216331
```

77775757
36,1.25 MICRO SECOND MEMORY CYCLE TIME

00055

46456260 77775757 01330205

60443123

BCD.C

CUMPASS-32	(2.1)	EXAMPLE 24 (DEMO)	11/21/66 PAGE 3
00056 00057	25234645 24604425	CARREGE ET (UEMU)	1122120 1805 3
00060 00061	44465170 60237023		
00062 00063 00064	43256063 31442560 77575757	ост	77575757
00065 00066	10427360 01064273	BCn•C	40.8K. 16K. OR 32K WOHDS OF CORE STORAGE
00067 00070	60465160 03024260		
00071 00072	60664651 24626046		
00073 00074	26602346 51256062		
00075 00076 00077	63465121 27256060 77575757	OCT	77575757
00100 00101	02046022 31636066	BCn+C	20+24 BIT WOND LENGTH
00102 00103	46512460 43254527		
00104 00105	63306060 77575757	OCT C	7757577
00106 00107 00110	03603145 24256760 51252731	9CD•C	20+3 INDEX REGISTERS
00111	62632551 62606060		
00113 00114	77575757 44644363	OCT	77575757 32.multi-level indirect addressing
00115 00116	31404325 65254360		
00117 00120	31452431 51252363		
00121 00122 00123	60212424 51256262 31452760		
00124 00125	77575757 23302151	OÇT	7757577 32:CHARACTER HANDLING INSTRUCTIONS
00126 00127	21236325 51603021		
00130 00131	45244331 45276031		
00132 00133 00134	45626351 64236331 46456260	ı	
00135 00136	77575757 22642626	OCT .	77575757 48, BUFFERED CHARACTER SEARCH AND MOVE OPERATIONS
00137 00140	25512524 60233021		
00141	51212363		
00142 00143	25215123 25215123		
	25516067		
	25516067		
00143	2521512:		
00143	2521512: 2521512:	EXAMPLE 24 (DEMO)	11/21/66 PAGE 4
00143 COMPASS-32 00144 00145	2551606; 2521512; (2•1) 3060214; 246044; 552504;	EXAMPLE 24 (DEMO)	11/21/66 PAGE 4
00143 COMPASS-32 00144 00145 00146 00147	2551606; 2521512; 2521512; (2-1) 3060214; 2460444	EXAMPLE 24 (DEMO)	11/21/66 PAGE 4
00143 COMPASS=32 00144 00145 00146	2551606; 2521512; (2*1) 3060214; 2460444; 6525604; 472512; 6331464; 6260806; 7757575; 2346456;	EXAMPLE 24 (DEMO)	11/21/66 PAGE 4 71575757 201CONSOLE TYPE WHITER
COMPASS-32 00144 00145 00146 00151 00152 00153 00154	2551606; 2521512; (2.1) 3060214; 2460444; 4725512; 6331464; 6260606; 7757575; 2346456; 4643256; 6370472;	EXAMPLE 24 (DEMO)	71575757
COMPASS-32 00144 00145 00146 00150 00151 00152 00155 00156 00157	251606; 2521512; (2-1) 3060214; 246044; 5525604; 4725512; 6331464; 6260606; 7757575; 2346456; 4643256; 6651316; 2551606;	EXAMPLE 24 (DEMO)	71575757 20°COVSOLE TYPE#HITEQ
COMPASS-32 00144 00145 00146 00150 00151 00152 00153 00154 00155 00156 00157	(2.1) 3060214: 2460444: 6525604: 4725512 6331464: 6260066 775757 7346456: 4632266 6370472: 6651316 2551606 7757575 5155214	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C	71575757
COMPASS-32 30144 00145 00146 00150 00151 00152 00153 00154 00155 00156	(2.1) 3060214: 2460444: 6525064: 4725512 6331464: 626060: 7757575 2346456: 4643256 6571316 2551006 7757575 5125214: 6063314 2560234	EXAMPLE 24 (DEMO) OCT BCD+C BCD+C	71575757 20.COYSOLE TYPE#HITER 71575757 16.REAL TIME CLOCK
COMPASS-32 00144 00145 00146 00150 00151 00152 00153 00154 00155 00166 00161 00162 00163 00164 00165	251606; 2521512; 3060214; 246044; 6525604; 4725512; 6331464; 6260606; 7757575; 236456; 4643256; 6651316; 2551606; 7757575; 51525214; 6063314; 2560234; 4623426; 7777575; 626234;	EXAMPLE 24 (DEMO) OCT HCD+C BCD+C	71575757 20.COVSQLE TYPE#HITER 71575757
COMPASS-32 00144 00145 00146 00147 00150 00151 00152 00153 00154 00155 00166 00161 00162 00163 00164 00165	(2.1) 3060214: 240044: 6525004: 4725512: 6331464: 6553166 7757575 2346456: 4643256 6370472: 6651316 2551606 7757575 5125214 6063314: 2560234 4623426 7777575 6263214 2421512 6063114 2421512	EXAMPLE 24 (DEMO) OCT BCD+C BCD+C CT BCD+C	7757577 20,00450LE TYPE#HITER 7757577 16,REAL TIME CLOCK
COMPASS=32 00144 00145 00146 00147 00150 00151 00152 00153 00154 00157 00160 00161 00162 00163 00164 00165 00167	(2.1) 30/0214; 2460444 652504 4725512 6331464; 652506 7757575 2346456; 6370472; 6651316, 2551606 7757575 5125214 6063314; 2560234; 4623426 77777575 6263214; 2421512 6021513 6330442; 6331246	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C	7757577 20,00450LE TYPE#HITER 7757577 16,REAL TIME CLOCK
COMPASS-32	(2.1) 3060214: 2460444: 6525044 4725512 6331464: 6260606 7757575 2346456 6370472: 6651316 2551006 7757575 5125214 6063314 2560234 4623426 7777575 6263214 2421512 6021513 6330442:	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C	7157577 20.00450LE TYPE#HITER 71575757 16.REAL TIME CLOCK 71775757 32.STANDARD ARITHMETIC CAPABILITIES
COMPASS=32 00144 00145 00146 00147 00150 00151 00152 00153 00154 00155 00157 00160 00161 00162 00163 00164 00165 00167 00170 00171	(2+1) 3060214; 2460444; 652504; 4725512; 6331464; 652506; 7757575; 2346456; 6370472; 6651316; 2551606; 7757575; 5125214; 6063314; 2560234; 4623426; 777756; 6263214; 2421512; 6021513; 6330442; 631236; 2321472; 2231433; 6331256; 7777606; 0264002;	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C	7757577 20,00450LE TYPE#HITER 7757577 16,REAL TIME CLOCK
COMPASS=32 00144 00145 00146 00147 00150 00151 00152 00153 00154 00157 00160 00161 00162 00163 00164 00167 00170 00171 00172 00173 00174 00175 00176 00177	(2*1) 3000214; 2460444; 65250444; 652504; 4725512; 6331464; 6260806; 7757575; 2346456; 6316; 2551806; 7757575; 5125214; 6063314; 2560234; 4623426; 7777575; 6263214; 2421512; 6021513; 6331246;	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C OCT BCD+C	71575757 20.CONSOLE TYPEWHITER 71575757 16.REAL TIME CLOCK 71775757 32.STANDARD ARITHMETIC CAPABILITIES
COMPASS=32	(2*1) 3060214: 2521512: 3060214: 2460444 6525646 4725512 6331464: 6260606 7757575 5125214 6651316 2551606 7757575 5125214 6651314 2560234 4623426 67777575 6263214 2421512 6021513 6331236 2321472 2421512 6021513 6331236 2321472 2421512 602160 77777606 7777606 7204602 3163606 6124247 6062642 7360460	EXAMPLE 24 (DEMO) OCT BCD.C COT BCD.C COT BCD.C	71575757 20.CONSOLE TYPEWHITER 71575757 16.REAL TIME CLOCK 71775757 32.STANDARD ARITHMETIC CAPABILITIES
COMPASS=32	251606; 2521512; 3060214; 2460444; 6525604; 4725512; 6331464; 6260606; 7757575; 2346456; 4643256; 6651316; 2551606; 7757875; 5125214; 6063314; 2560234; 4623426; 7777575; 623214; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 2421512; 603124; 6	EXAMPLE 24 (DEMO) OCT	71575757 20.CONSOLE TYPEWHITER 71575757 16.REAL TIME CLOCK 71775757 32.STANDARD ARITHMETIC CAPABILITIES
COMPASS=32 00144 00145 00146 00147 00150 00151 00152 00153 00154 00155 00166 00161 00162 00163 00164 00167 00171 00172 00173 00174 00175 00176 00177 00170 00171 00175 00176 00177	(2*1) 3060214; 2521512; 2460444; 652504; 4725512; 6331464; 6260606; 7757575; 246426; 6651316; 2551606; 7757575; 5125214; 6063314; 2560234; 4623426; 7777575; 6263214; 2421512; 6021513; 6331236; 2321472; 231433; 6331256; 7777606; 6726462; 7360466; 7360466; 7360466; 7360466; 7360466; 73760466; 736066; 736066; 736066; 736066; 736066; 736066; 73606; 736066; 73606; 7	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C OCT BCD+C	71575757 20.COVSOLE TYPE#HITER 71575757 16.REAL TIME CLOCK 71775757 32.STANDARD AHITHMETIC CAPABILITIES 77776060 28.24 BIT AUD. SUB. MULT + DIV
COMPASS=32	(2*1) 3060214: 2501512: 3060214: 2460444: 6552504: 4725512 6331464: 6260606 7757575 5125214 6063314: 2560234 4623426 7777575 6263214 2421512 6021513 6331236 231242 2231433 6331256 77777606 626022 3163606 626242 73604602 3163606 624316 7757606 624316 62642 73604602 3163606 624316 7757606 624316 624316 7757606	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C	77576760
COMPASS=32	(2.1) 30.00214: 2521512: 2460444: 6525064: 4725512 6260606: 7757575: 2346456: 6370472: 6651316 27516066 2757575: 5125214 60633144: 2560234 4623426 7777575 622412512 6021313 6331236 231472 2231433 6331236 231472 2231433 6331246 7777606 620424 63163606 2124247 6062642 7360446 4363602 6024316 7757606 6024316 7757606 602402 3163606 2124226 2260606 77777506	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C OCT BCD+C OCT OCT BCD+C	71575757 20.COVSOLE TYPE#HITER 71575757 16.REAL TIME CLOCK 71775757 32.STANDARD ARITHMETIC CAPABILITIES 71776060 28.24 BIT AUD. SUB, MULT + DIV 77576060 20.48 BIT AUD + SUB
COMPASS-32 00144 00145 00146 00147 00150 00151 00152 00153 00154 00157 00160 00161 00162 00163 00164 00167 00173 00174 00175 00176 00177 00170 00171 00172 00173 00174 00175 00176 00171 00172 00173 00174 00175 00176 00171 00172 00173 00174 00175 00176 00171 00172 00173 00174 00175 00176 00171 00172 00173 00174 00175 00176 00171 00172 00173 00174 00175 00176 00177 00170 00200 00201 00202 00203 00204 00205	(2.1) 3060214: 2521512: 3060214: 2460444: 6525646: 4725512 6331444: 6260606: 7757575: 5346456: 4643256: 6651316: 2551006: 7757575: 5125214: 606314: 2560234: 4623426 7777575 6331236 231433 6331236 231472 2231433 6331236 231472 2231433 6331246 23163066 2124247 6062642 7360446 4363602 6024316 7757606 0410602 3163606 2124246 2060626 2224606 7777575 4647633 4645214	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C	77575757 77575757 16, REAL TIME CLOCK 77775757 32, STANDARD ARITHMETIC CAPABILITIES 77776060 28:24 BIT AUD, SUB, MULT + DIV 77576060 20:48 BIT AUD + SUB
COMPASS=32 COMPAS	251606; 2521512; 3060214; 2460444; 652504; 4725512; 6331464; 6260606; 7757575; 2346456; 4643256; 651316; 2551606; 7757575; 5125214; 6603314; 2560234; 4623426; 7777575; 623214; 2421512; 6021513] 6331236; 231472; 2231433; 6331236; 7777606; 632124; 736046; 7377606; 632124; 736046; 7377606; 7377606; 7377606; 7377606; 7377606; 7377606; 7377606; 7377606; 73777606; 7377606; 7377606; 7377606; 73777606; 73777606; 73777606; 73777606; 73777606; 73777606; 73777606; 73777606; 73777606; 73777606; 73777606; 7377777606; 73777606; 73777606; 73777606; 737777606; 737777606; 737777606; 7377777606; 7377777606; 737777777606; 7377777777777777777777777777777777777	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C	71575757 20.COVSOLE TYPE#HITER 71575757 16.REAL TIME CLOCK 71775757 32.STANDARD ARITHMETIC CAPABILITIES 71776060 28.24 BIT AUD. SUB, MULT + DIV 77576060 20.48 BIT AUD + SUB
COMPASS=32	(2-1) 3060214: 2460444 65252644 725512 6331464: 6260606 7757575 5125214 60633144 2560234 4623426 67777575 6262314 2260234 602314 2421512 6021513 6331236 2321472 2231433 6331256 77777606 62642 73604602 3163606 6124247 6062642 73604606 6124247 6062642 73604606 6124247 6062642 73604606 6124247 6062642 73604606 6124247 6062642 73604606 6124247 6062642 73604606 6124247 6062642 73604606 612626 61260606 7777575 6260606 7777575	EXAMPLE 24 (DEMO) OCT BCD.C OCT BCD.C OCT BCD.C OCT BCD.C	71575757 20.COVSOLE TYPE#HITER 71575757 16.REAL TIME CLOCK 71775757 32.STANDARD ARITHMETIC CAPABILITIES 71776060 28.24 BIT AUD. SUB, MULT + DIV 77576060 20.48 BIT AUD + SUB
COMPASS=32	(2-1) 3060214: 2521512: 3060214: 2460444: 6525644: 4725512 6331444: 6260606: 7757575: 5346456: 4643256: 6651316: 2551006: 7757575: 5125214: 606314: 2421612: 603144: 2421512: 6031246: 231433: 6331236: 231472: 2231433: 633046: 7757606: 602642: 736046: 4363602: 2124246: 6024316: 7757606: 6024316: 7757606: 6024316: 7757606: 6024316: 7757606: 6024316: 7757606: 6024316: 7757606: 6024316: 7757606: 6024316: 7757506: 6024316: 7757506: 6024316: 7757506: 6024316: 7757506: 6024316: 7757506: 6024316: 7757506: 6024316: 7757506: 6024316: 7757506: 6024316: 7757506: 6024316: 7757606: 6024316: 7757606: 6024316: 7757606: 6024316: 77577606: 6024316: 77577606: 6024316: 77577606: 6024316: 77577606: 6024316: 77577606: 6024316: 77777606: 6024316: 77777606: 6024316: 77777606: 6024316: 77777606: 6024316: 6024316: 777777606: 6024316: 6024316: 77777606: 6024316: 6024316: 77777606: 6024316: 77777606: 6024316: 77777606: 6024316: 77777606: 6024316: 6024316: 777777606: 6024316: 77777606: 6024316: 6024316: 777777606: 6024316: 6024316: 77777606: 6024316: 6024316: 777777606: 6024316: 6024316: 77777606: 6024316: 6024316: 77777606: 6024316: 777777606: 6024316: 6024316: 777777606: 6024316: 6024316: 77777606: 6024316: 6024316: 77777606: 6024316: 77777606: 6024316: 6024316: 777777606: 6024316: 6024316: 6024316: 77777606: 6024316: 6024	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C	7757577 20.CONSOLE TYPERRITER 7757577 16.REAL TIME CLOCK 77775757 32.STANDARD AHITHMETIC CAPABILITIES 77776060 20.48 BIT AUD + SUB 77775757 32.OPTIONAL ARITHMETIC CAPABILITIES
COMPASS=32	(2*1) 30(021*) 2521512: 2460*4*i 65250*i 4725512 633140*i 6260806 7757575 512521*i 6651316 2551606 7757575 512521*i 6651316 255120*i 633124*i 256023*i 633124*i 231*33 6331256 7777506 62124247 606262*i 74606262*i 74606262*i 7476066 62124247 606262*i 7476066 62124246 6330442*i 633042*i 633042*i 633042*i 6331236 6331236 6331236 6331236 6331236	EXAMPLE 24 (DEMO) OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C OCT BCD+C	7757577 775757 77575757 77576060 777576060 77576060

COMPASS-32	2.1)	EXAMPLE 24 (DEMO)	,	11/21/66 PAGE 5
00232 00233 00234 00235 00236 00237 00240 00241 00242 00243 00244 00245 00246 00247	60602643 46216331 45276047 46314563 60212424 73606264 227360046 64436360 20606060 60606060 60606060 60606060 60606060 60602431 65312425 60214524	OCT BCD•C	77576060 DIVIDE AND F	TXED POINT 48 BIT
00253 00254 00255 00256 00257 00260 00261 00262 00263 00264	60263167 25246047 46314563 60041060 22316360 77576060 60606060 60606060 60606060 60606060 60606060	OC↑ BCD∗C	77576060 MULT + DIV	
00266 00267 00270 00271 00272 00273 00274 00275	43636020 60243165 77576060 22232460 47212342 21272560 60606060 60602231 45215170	OC⊤ BCD∗C	/7576060 52.BCD PACKAGE BINARY CODED	DECIMAL ADD + SUB
00277 00300 00301 00302 00303 00304 00306 00307 00310 00311	60234624 25246024 25233144 21436060 21242460 20606264 22606060 77775757 31454764 63614664 63476463 60232147	OCT BCD+C	77775757 28:INPUT/OUTPUT CAPARILITIES	
00313 00314 00315 00316 00317	21223143 31633125 62606060 77776060 02401060	OCT BCD+C	77776060 20,2-B DATA CHANNELS	
COMPASS-32 00320 00321 00322 00323 00324 00325 00326 00327 00330	(2.1) 24216321 60233021 45452543 62606060 77576060 01401060 25506431 47442545 63602346 45635146 43432551	EXAMPLE 24 (DEMO) OCT BCD+C	77576060 44,1-8 EQUIPMENT CONTROLLERS PER	11/21/66 PAGE 6 R DATA CHANNEL
00332 00333 00335 00335 00337 00340 00341 00342 00344 00345 00346	62604725 51602421 63216023 30214545 25435060 77776060 21652131 43212243 25602550 64314744 25456360 60606060	OCT BCn+C	77776060 40, AVAILABLE EQUIPMENT	SPEEDS
00351 00352 00353 00354 00356 00356 00356 00356 00362 00363	27452563 31236063 21472562 60606060 60606060 60073305 42236040	OCT 8CD•C	77576060 48, MAGNETIC TAPES	7.5KC - 120KC
00367 00370 00371	42236060 77576060 60606060 60602321 51246051	BCD•C	77576060 48, CARD READER	1200 CARDS/MIN
00372 00373 00374 00375 00377 00407 00407 00407	60606060 60606060 60606060 606063321			

CUMPASS-32 00406	(2.1)	EXAMPLE 24 (DEMO)			11/21/66 PAGE 7	
00407 00410	12620909	BCD+C	48,	CARD PUNCHES	150 - 250 CARDS/MIN	
00411	51246047 64452330					
00412 00413	25626060 60606060					
00414 00415	60606001					
00416	05006040 60020500					
00417 00420	60232151 24626144					
00421 00422	31456060 77576060	007	77576060			
00423	60606060	BCD+C	77576060 48,	PAPER TAPE STATE	DNS 350 - 1000 CPS READ	
00424 00425	60604721 47255160					
00426 00427	63214725 60626321					
00430 00431	63314645 62606003					
00432 00433	05006040					
00434	60010000 00602347					
00435 00436	44606051 25212060					
00437 00440	77576060 60606060	OCT BCD•C	77576060			
00441 00442	60606060	50,70	48,		110 CPS PUNCH	
00443	60606060 60606060					
00444 00445	60606060 60606060					
00446 00447	60606060 60606060					
00450 00451	60600101					
00452	00602347 44606047					
00453 00454	6445233 <u>0</u> 77576060	ОСТ	77576060			
00455 00456	60606060 60604331	8CD+C		LINE PRINTERS	150 - 1000 LINES/MIN	
00457 00460	45256047 51314563					
00461	25516260					
00462 00463	60606060 60606001					
00464 00465	05006040 60010000					
00466 00467	00604331 45256261					
00470 00471	44314560					
00472	77576060 60606060	OCT BCD+C	77576060 52•	DISC PACKS	97 MILLI SEC AVG ACCESS	
00473	60602431				A MARCI SEC AVO ACCESS	
	(2.1)	EXAMPLE 24 (DEMO)			11/21/66 PAGF a	
00474 00475	62236047 21234262	EXAMPLE 24 (DEMO)			11/21/66 PAGE A	
00474	62236047 21234262 60606060	EXAMPLE 24 (DEMO)			11/21/66 PAGE A	
00474 00475 00476 00477 00500	62236447 21234262 60606060 60606060 60606011	EXAMPLE 24 (DEM _O)			11/21/66 PAGE A	
00474 00475 00476 00477 00500 00501 00502	62236047 21234262 60606060 60606060 60606011 07604431 44433160	EXAMPLE 24 (DEMO)			11/21/66 PAGE A	
00474 00475 00476 00477 00500 00501	62236047 21234262 60606060 60606060 60606011 07604431 43433160 62252360	EXAMPLE 24 (DEMO)			11/21/66 PAGE A	
00474 00475 00476 00477 00500 00501 00502 00503 00504	62236047 21234262 6006000 6006000 6006011 07604431 43433160 62252360 21652760 21232325	EXAMPLE 24 (DEMO)			11/21/66 PAGE A	
00474 00475 00476 00477 00500 00501 00502 00503 00504 00505 00506	62236047 21234262 60006060 60006060 60606011 07604431 43433160 62252360 21652760 21232325 62626060 77576060	ОСТ	77576060			
00474 00475 00476 00477 00500 00501 00502 00503 00504 00505 00506 00507	62236047 21234262 6006060 6006060 60606011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 60606060		77576060 48,		11/21/66 PAGE A 11/21/66 PAGE A 71K CHAR/SEC AVG XFER	
00474 00475 00476 00477 00500 00501 00502 00503 00504 00505 00507 00510 00511	62236047 21234262 60060060 60060060 6006011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 60606060 60606060	ОСТ				
00474 00475 00477 00500 00500 00501 00502 00503 00504 00505 00506 00507 00510 00511	62236047 21234262 60060060 60060060 6006011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 60606060 60606060 60606060 60606060 60606060	ОСТ				
00474 00475 00477 00500 00500 00501 00502 00503 00504 00505 00506 00507 00510 00511 00512 00513	62236047 21234262 6006060 6006060 6006011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 6006060 6006060 6006060 60606060 60606060 60606060 60606060 60606060	ОСТ				
00474 00475 00476 00477 00501 00501 00502 00503 00504 00505 00507 00510 00511 00512 00514 00515 00516	62236047 21234262 6006060 6006060 60606011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060	ОСТ				
00474 00475 00476 00477 00500 00501 00502 00503 00504 00505 00506 00507 00511 00512 00513 00514 00515 00516 00517	62236047 21234262 6006060 6006060 6006011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060	ОСТ				
00474 00475 00476 00477 00500 00501 00502 00503 00506 00506 00507 00510 00511 00512 00513 00514 00515 00517	62236047 21234262 60060060 60060060 6006011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 61252360 21652760 67262551	0C↑ BC0•C	48,			
00474 00475 00477 00501 00501 00502 00503 00504 00505 00506 00507 00511 00512 00513 00514 00515 00516 00517 00515	62236047 21234262 60060060 600606011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 6006060 6006060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060	ОСТ	48.	PRUM STORAGE		
00474 00475 00476 00477 00501 00502 00503 00504 00505 00506 00507 00511 00512 00513 00514 00515 00516 00517 00522 00523 00524 00525	62236047 21234262 6006060 6006060 600606011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 6060606060 6060606060 606060606060	OCT BCD*C	48.	PRU™ STORAGE	71k CHAR/SEC AVG XFER	
00474 00475 00476 00477 00500 00501 00503 00504 00505 00506 00507 00511 00512 00513 00514 00515 00516 00512	62236047 21234262 60060060 60060060 6006011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 60606060	OCT BCD*C	48.	PRUM STORAGE	71k CHAR/SEC AVG XFER	
00474 00475 00477 00501 00500 00501 00502 00503 00504 00505 00506 00507 00510 00511 00512 00513 00514 00515 00516 00517 00520 00521 00522 00523 00524 00525 00526 00527	62236047 21234262 6006060 6006060 60060611 07604431 43433160 62252360 21652760 21652760 60606060	OCT BCD*C	48.	PRU™ STORAGE	71k CHAR/SEC AVG XFER	
00474 00475 00476 00477 00501 00500 00501 00504 00505 00506 00507 00511 00512 00513 00514 00515 00516 00516 00522 00523 00524 00525 00525 00527 00527 00530 00531 00532	62236047 21234262 6006060 6006060 60060611 07604431 43433160 62252360 21652760 21652760 6006060 6006060 6006060 6006060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 6060606060 60606060 60606060 60606060 60606060 60606060 60606060 6060606060 60606060 60606060 60606060 60606060 60606060 60606060 6060606060 60606060	OCT BCD*C	48.	PRUM STORAGE	71k CHAR/SEC AVG XFER	
00474 00475 00476 00477 00500 00501 00502 00503 00504 00505 00506 00507 00511 00513 00513 00515 00516 00517 00522 00523 00524 00525 00525 00527 00527 00527 00531 00531 00531 00532	62236047 21234262 6006060 6006060 6006060 60060611 07604431 44433160 62252360 21652760 21232325 62626060 77576060 60606060	OCT BCD*C	48.	PRUM STORAGE	71k CHAR/SEC AVG XFER	
00474 00475 00476 00477 00500 00500 00501 00503 00504 00505 00506 00507 00510 00511 00513 00514 00515 00513 00514 00515 00516 00517 00522 00522 00523 00524 00527 00530 00531 00532	62236047 21234262 60060060 6006060 60060611 07604431 43433160 62252360 21652760 21652760 606060001 07604431 43433160 62252360	OCT BCD*C	48.	PRUM STORAGE	71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	
00474 00475 00477 00477 00500 00500 00501 00505 00506 00505 00506 00510 00511 00512 00513 00514 00515 00517 00520 00521 00522 00523 00524 00525 00526 00527 00530 00531 00532	62236u+7 21234262 6006006 6006060 60060601 07604431 43433160 62252360 21652760 21232325 62626060 77576060 6060606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060	OCT BCO+C OCT BCO+C	77576060 52,	PRUM STORAGE	71k CHAR/SEC AVG XFER	
00474 00475 00477 00477 00500 00500 00501 00505 00506 00506 00507 00511 00512 00513 00514 00515 00516 00517 00520 00521 00522 00523 00524 00525 00526 00527 00530 00531 00532 00533	62236047 21234262 6006060 6006060 600606011 07604431 43433160 62252360 21652760 6006060 6006060 6006060 6006060 60606060	OCT BCD*C	48.		71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	
00474 00475 00477 00477 00501 00501 00503 00504 00505 00506 00507 00511 00511 00513 00514 00515 00516 00517 00522 00523 00524 00525 00524 00527 00530 00531 00531 00531 00531	62236047 21234262 60060060 6006060 60060601 107604431 43433160 62252360 21652760 21232325 62626060 77576060 60602451 64446062 63465121 27256060 60606060 60606060 606060001 07604431 43433160 62252360 21652760 21232325 62626060 77576060	0CT BCO+C	77576060 77576060		71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	
00474 00475 00476 00477 00501 00501 00502 00503 00506 00505 00506 00510 00511 00512 00513 00514 00515 00514 00515 00520 00521 00522 00523 00524 00525 00526 00526 00527 00530 00531 00532 00533 00534 00535 00537 00536 00537	62236u+7 21234262 60060060 6006060 600606011 07604431 43433160 62252360 21652760 21652760 60606060 60606060 60606060 60606060 60606060 60606060 6077576060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060	0CT BCO+C	77576060 77576060		71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	
00474 00475 00477 00477 00501 00501 00502 00503 00506 00506 00507 00511 00512 00513 00514 00515 00516 00517 00522 00521 00522 00523 00524 00525 00526 00527 00530 00531 00532 00533 00534 00535 00536 00537 00540 00541 00542	62236047 21234262 6006060 6006060 60060601 07604431 43433160 62252360 21652760 21652760 60606060	0CT BCO+C	77576060 77576060		71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	
00474 00475 00476 00477 00477 00501 00502 00503 00504 00505 00506 00507 00511 00512 00513 00514 00515 00516 00517 00520 00522 00522 00524 00525 00526 00527 00530 00531 00532 00533 00534 00535 00536 00537 00530 00537 00540 00541 00545 00545 00545	62236047 21234262 6006060 6006060 6006060 60060611 07604431 43433160 62252360 21652760 6006060 6006060 6006060 6006060 60606060	0CT BCO+C	77576060 77576060		71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	
00474 00475 00476 00477 00477 00501 00501 00502 00503 00504 00505 00506 00507 00511 00512 00513 00514 00515 00516 00517 00520 00521 00522 00523 00524 00527 00530 00531 00532 00533 00534 00537 00530 00531 00536 00537 00530	62236u+7 21234262 60060060 60060060 6006011 07604431 43433160 62252360 21652760 21232325 62626060 77576060 60606060	0CT BCO+C	77576060 77576060		71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	
00474 00475 00476 00477 00477 00501 00501 00502 00503 00506 00505 00506 00512 00513 00514 00515 00514 00515 00515 00516 00517 00522 00523 00524 00525 00526 00527 00530 00531 00532 00534 00535 00536 00537 00540 00541 00542 00543 00544 00545	62236047 21234262 60060060 6006060 60060611 07604431 43433160 62252360 21652760 21652760 60606060 60606060 60606060 60606060 60606060 60606060 6077576060 60606060	0CT BCO+C	77576060 77576060		71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	
00474 00475 00476 00477 00477 00501 00501 00502 00503 00504 00505 00506 00507 00511 00513 00514 00515 00516 00517 00520 00521 00522 00523 00524 00525 00527 00530 00531 00531 00531 00534 00540 00541 00542 00542	62236047 21234262 6006060 6006060 6006060 60060611 07604431 43433160 62252360 21652760 21652760 21232325 62626060 77576060 60606060 60606060 60606060 60606060 60606060 67262531 77576060 60606060 67262531 77576060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060 60606060	0CT BCO+C	77576060 52, 77576060 48,		71K CHAR/SEC AVG XFER 17 MILLI SEC AVG ACCESS	

CUMPASS-32	(2.1)	EXAMPLE 24	(DEMO)	11/21/66 PAGE 9
00562 00563	46636325 51626060			
00564 00565	77576060 60606060		OCT BCD+C	77576060 20. PAGE READER
00566	60604721			
00567 005 <u>7</u> 0	27256051 25212425			
00571 00572	51606060 77576060		ОСТ	77576060
00573 00574	60606060 60602351		BCD+C	24, CRT DISPLAY UNITS
00575 00576	63602431 62474321			
00577	70606445			
00600 00601	31636260 77576060		OCT	77576060 40. AND MANY OTHER SPECIALIZED DEVICES
00602 00603	60606060 60602145		9CD•C	40. AND MANY OTHER SPECIALIZED DEVICES
00604 00605	24604421 45706046			
00606 00607	63302551 60624725			
00610 00611	23312143 31712524			
00612	60242565			
00613	31232562 00614	MSGEND	EQU+C	* ·
			END	START
			NUMBER OF I	LINES WITH DIAGNOSTICS 0
		-		
COMPASS-32	(2•1)	EXAMPLE 24	(DEMO)	11/21/66 PAGE 1
COMPASS-32	(2.1)	EXAMPLE 24		
MSG	P00007	EXAMPLE 24	P00001	
	P00007	EXAMPLE 24		
MSG	P00007	EXAMPLE 24	P00001	
MSG	P00007	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	
MSG	P00007 P00614 0 P00000	EXAMPLE 24	P00001	

```
COMPASS-32
                             (2.1)
                                                               EXAMPLE 25 (MTDRIVER)
                                                                                                                                                             11/21/66 PAGE
           ENTRY-POINT SYMBOLS
                                          00000
                  MTDRIVER
           LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
                                                         00000
                                                         00000
•
         COMPASS=32
                                                                 EXAMPLE 25 (MTDRIVER)
                                                                                                                                                            11/21/66 PAGE
                                                                         ENTRY MIDRIVER

ENTRY MIDRIVER

THIS SUBPROGRAM IS AN I/O DRIVER DESIGNED TO HANDLE ALL MAG TAPE
OPERATIONS, USE OF THIS DRIVER WILL GREATLY REDUCE THE AMOUNT OF EFFORT
REQUIRED ON THE PROGRAMMER*S PART WHEN WORKING WITH MAG TAPE. HE NEED
NOT EVEN BE CONCERNED WITH THE EQUIPMENT CONFIGURATION OF THE PARTICULAR
MACHINE IN USE, SINCE THIS IS MANDLED BY MIDRIVER.
                                                                                       ----- CALLING SEQUENCE -----
                                                                                                       1. SET PARAMETERS INTO A + Q
                                                                                                          (A) A = TAPE UNIT NUMBER (0-7)
                                                                                                           (8) Q 23-18 = FUNCTION CODE
(C) Q 14-00 = BUFFER FWA (NEEDED FOR I/O REQUEST ONLY)
                                                                                                       2. RTJ TO MTDRIVER (MTDRIVER MUST BE DECLARED EXTERNAL)
                                                                                       ----- OPERATIONS AVAILABLE -----
                                                                                                                                                                   FUNCTION CODE (OCTAL)
                                                                                                                   OPERATION
                                                                                                        1. READ 30 WUS IN BCD (120 CHARS)
                                                                                                     1. READ 30 WUS IN BCD (120 CHARS)
2. READ 40 WOS IN BINAHY
3. WRITE 30 WOS IN BCD (120 CHARS)
4. WRITE 40 WDS IN BINARY
5. REWIND
6. UNLOAD
7. BACKSPACE
9. SEARCH FILE FORWARD
10. WRITE FILE MARK
11. SKIP BAD SPOT
                                                                                        ----- ON RETURN -----
                                                                                                       1. B REGS ARE UNCHANGED.
                                                                                                       2. IF REQUEST WAS I/O (FC 1-4). THE OPERATION WILL BE
                                                                                                       COMPLETE.

3. A 11-00 = STATUS FROM THE TAPE AT ENU OF OPERATION IF REQUEST WAS I/O (FC 1-4).

4. A IS MEANINGLESS IF NOT I/O REQUEST.

5. Q IS MEANINGLESS.
                                                                                       ----- ERROR PROCEDURES -----
                                                                                                       1. IF TAPE UNIT IS FOUND #1401 READY# A DIAGNOSTIC
                                                                                                       WILL BE TYPED (READY OT X), PROGRAM WILL CONTINUE WHEN UNIT IS READY.

2. ALL REJECTS WILL LOOP.
```

```
5-32 (2-1) EXAMPLE 25 (MTDRIVER)
00000 0107/777 01 0 77777 0 MTDRIVER UJP *
                                                                                                                                           11/21/66 PAGE
CUMPASS-32
                                                                                                                        LINKAGE BACK TO USER
                                                            ****** INITIALIZING PROCEDURE *****
                                                                                                                         ESTABLISH CONNECT CODE
          00001 42000157 42 0 P00033 3
                                                                        SACH
                                                                                        CONNECT+3
                                                                                                                         SET TAPE NO. IN READY MESSAGE
          00002 42000371 42 0 P00076 1
                                                                         SACH
                                                                                        HDYMSG+9
                                                                                                                         PLACE FUNCTION CODE
          00003 14600000 14 1 00000 2
                                                                        ENA
                    13000000 14 1 000000 2
13000006 13 0 00006 0
42000400 42 0 P00100 0
05600017 05 1 00017 2
05600010 05 1 00010 2
01000013 01 0 P00013 0
                                                                                                                         IN A 5-0.
SAVE FUNCTION CODE
IS THIS AN
I/O REQUEST
                                                                        SHAW
SACH
ASG
ASG
          00004
00005
          00006
00007
                                                                                                                              YES - THEN JUMP
                                                                                        INPOUT
                                                                        UJP
          00010
                                                                                                                             NO - THEN SET SELECT CODE AND
                                                                                        SELECT+3
          00011 42000247 42 0 P00051 3
                                                                         SACH
                                                                                                                                     GO TO CONNECT PROCEDURE
                                                                        دارن
           00012 01000033 01 0 P00033 0
                                                                                        CONNECT
                                                                                                                         TEST TO SEE IF FUNCTION CODE IS
          00013 05600005 05 1 00005 2 INPOUT
                                                                        ASG
                    05600001 05 1 00001 2
00000015 00 0 P00015 0
                                                                                                                         LEGAL.
BLIND HALT ON ILLEGAL CODE
                                                                         ASG
                                                                                                                         POSITION FC AND FWA IN A
A 14-00 = FWA OF USER#S BUFFER
A 23 = 1 IF BCD REQUEST .D IF BINARY
           00016 12000005 12 0 00005 0
                    13000022 13 0 :00022 0
                                                                         SHAQ
                                                                                        18
                                                                                                                        BCD SELECT CODE TO Q +
IS REQUEST BCD
NO - THEN BINARY CODE TO Q
PLACE SELECTED CODE IN SEL INSTRUCTION
           00020 14700002 14 1 00002 3
                    03300023 03 0 P00023 3
14700001 14 1 00001 3
43000247 43 0 P00051 3
                                                                         AZJ+LT
ENG
SUCH
                                                                                        *+2
           00021
                                                                                         SELECT+3
           00023
                                                                                        INPUT+1
                                                                                                                         SET FWA IN INPUT/OUTPUT
                     44000066 44 0 P00066 0
                                                                         SWA
           00024
                    44000066 44 0 P00066 0
15000036 15 1 00036 2
03300031 03 0 P00031 3
15600012 15 1 00012 2
44000065 44 0 P00065 0
44000061 44 0 P00061 0
                                                                         SWA
SWA
INA
AZJ+LT
INA
SWA
SWA
                                                                                         OUTPUT+1
                                                                                                                         INSTRUCTIONS
           00025
                                                                                                                         INSTRUCTIONS
FORM BCD LWA+1
IS REQUESTBCD
NO - THEN FORM BINARY LWA+1
SET LWA+1 IN INPUT/OUTPUT
INSTRUCTIONS
                                                                                        30
*+2
           00026
00027
00030
                                                                                         10
INPUT
OUTPUT
           00031
```

•					
•	COMPASS=32	(2.1)	EXAMPLE 25	(MIURIVER)	11/21/66 PAGE 4
			*****	CUNNECT PROCEDURE	5250969*
_	00033	77001000 77 0 0100	0 0 CONNECT	CON CONCODE	CH CONNECT TO SPECIFIED MAG TAPE
	00034	01000033 01 0 P0003	33 0	UJP *=1	
_			*****	TEST FOR READY ***	*****
	00035	77200001 77 0 0000	01 2	EXS 0001,CH	IS THE CONNECTED UNIT READY
	00036	01000051 01 0 P0005	51 0	UJP SELECT	YES - THEN GO TO SELECT PROCEDURE
	00037	77600400 77 1 0040	00 2	PAUS 400B	NO - THEN TYPE DIAGNOSTIC
•	00040	01000037 01 0 P0003		UJP *-1	WAIT FOR TY NOT BUSY
	00041	11000360 11 0 P000	74 0	ECHA RDYMSG	•
_		53420023 53 1 2007		TAM 238	•
l _	00043	15600013 15 1 000	13 2	INA 11	- INITIATE TY OUTPUT
	00044			TAM 338	•
	00045	77760000 77 1 600	00 3	CTO	
	00046	77200001 77 0 000	01 2	EXS 0001.CH	
1	00047	01000051 01 0 P000	51 0	UJP #+2	- LOOP UNTIL READY
	00050	01000046 01 0 P000	46 0	015 +-5	•
•			*****	SELECT PROCEDURE	*****
	00051	77100000 77 0 000	00 1 SELECT	SEL 0000.CH	
		01000051 01 0 P000		UJP #=1	SELECT MODE FOR I/U OPERATION
	00053	22000400 22 0 P001	00 0	LACH FC	FUNCTION CODE TO A
•	00054	05600006 05 1 000		ASG 6	IS THIS AN I/O REQUEST
1	00055			UJP *	NO - THEN GO TO READ/WRITE PROCEDURE
	00056			UJP EXIT	YES - THEN GO TO EXIT
_			*****	READ/WRITE PROCED	URE *****
	00067	05600003 05 1 000	03.2	ASU 3	IS THIS A READ REQUEST
	00057 00060			TUPNI YUU	YES - GO TO INPUT INSTRUCTION
	00000				THE THETH CHITCHE
	00061	76077777 76 0 777		OUT# CH,**,*	* NO - THEN INITIATE OUTPUT
	00062			UJP *− 2	LOOP ON REJECT
1	00063			TIAW YUU	GO TO WAIT BEFORE EXIT
1_	00064				
	00065			INPW CH, ##, #	* INITIATE INPUT
1	00066			UJP +-2	LOOP ON REJECT
	00067	01000065 01 0 P000	V C01	UE	

•	CUMPASS+32	(2•1) EXA	MPLE 25	(MTDRIVE	ER)	11/21/66 PAGE 5
			*****	WAIT FOR	R END OF OPERATION ****	••••
	00070 00071	77200002 77 0 00002 2 01000070 01 0 P00070 0	WAIT	EXS UJP	0002.CH *-1	IS UNIT STILL BUSY YES - THEN LOOP
			******	EXIT PRO	OCEDURE ******	•
•	00072 00073	77200000 77 0 00000 2 01000000 01 0 P00000 0	EXIT	COPY	CH MTDRIVER	RETURN TO USER
•			******	MISCELLA	ANEOUS ******	
• .	00074 00075 00076 00077	51252124 70604463 6067	RUYMSG	BCD•C	10.READY MT X	
•	00100	7700000	FC	VFU BSS+C	06/77 1	
			******	SYMBOL E	EQUATIONS ******	
•		00000 01000	CH CONCODE	EQU END	0 1000B	THIS DRIVER MAY BE ALTERED TO FIT ANY EQUIPMENT CONFIGURATION BY ONLY THESE
•				NUMBER OF	LINES WITH DIAGNOSTIC	s 0
•						

00000						
		P00033	P00035	P00046	P00051	
01000		P00061 P00033	P00065	P00070	P00072	
P00033 P00072		P00001	P00012			
P00100 P00013		P00005	P00053			
P00065 R P00000		P00024	P00031	P00060		
P00061		P00025	P00032			
P00051		P00011	P00023	P00036		
	P00033 P00072 P00100 P00103 P00065 R P00000 P00061 P00074	P00033 P00072 P00100 P0013 P00065 P00000 P00061 P00074 P00051	01000	01000	01000	01000

```
11/21/66 PAGE
                                                            MAC
       COMPASS-32
                             (2.1)
                                                                                                                                                                                                               lacktriangle
                                                                                                                                                                                                               •
          EXTERNAL SYMBOLS
                CIO
          LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
                                                     00076
                                                     00000
                                                                                                                                                                                                               •
                                                                                                                                                                                                               •
                                                                                                                                                                                                               •
                                                                                                                                                                                                               •
                                                                                                                                                                                                               •
                                                                                                                                                                                                               lacktriangle
                                                                                                                                                                                                                lacktrian
                                                                                                                                                                                                                •
                                                                                                                                                                                                                •
                                                                                                                                                                                                                •
                                                                                                                                                                                                                •
                                                                                                                                                                                                                •
                                                                                                                                                       11/21/66 PAGE 2
         COMPASS-32
                                                              MAC
•
                                                                      LIRM READS.REWIND.STATUS.FORMAT
                                                                                                                                                                                                                •
                                                                                 MACHO EXAMPLES
                                                                                                                                                                                                                •
lacktriangle
                                                                     READS
                                                                                   MACRO
                                                                                                   (L,R,FWA,N,X,IA,M,C)
                                                                                                  CIO
CIO
L,X
/*/:R:1
*=2
/*/;R:1
R
                                                                                   EXT

01

IFT

UJP

M

C IFF

00

END

M
                                                                                                                                                                                                                •
                                                                                                   N
/0/+X+1
IA
                                                                                                                                                                                                                 •
                                                                                                   (L.R.X.IA)
CIO
CIO
L.X
/*/.R.1
*~2
/*/.R.1
R
/0/.X.1
                                                                                   REWIND
                                                                                    ENDM
                                                                                                   (L•X)
                                                                                    MACRO
EXT
RTJ
13
                                                                     STATUS
                                                                                   ENDM
MACRO
EXT
RTJ
14
IFT
                                                                                                   (L.R.X)
CIO
CIO
                                                                     FORMAT
                                                                                                   C10
L,X
/*/,R,1
*-2
/*/,R,1
R
                                                                                    UJP
IFF
UJP
                                                                                     READS
                                                                                                    (14.*, INBUFF.40..,40)
                                                                                                                                                                                        READS
READS
READS
READS
                                                                                    READS

EXT CIO

RTJ CIO

01 14.0

1FT ***.1

UJP *-2

IFF *.*.1

40 INBUFF

0 40
                     00000 00777777 00 1 X77777 3 00001 01000016 01 0 00016 0
                      00002 01000000 01 0 P00000 0
                                                                                                                                                                                         READS
READS
READS
                     00003 40000026 40 0 P00026 0
00004 00000050 00 0 00050 0
```

COMPASS-32	(2.1)	MAC	IFF 0,0,1		11/2	1/66 PAGE	3 READS
			READS	(14,REJX,INBUFF,40,2	,INTADD+40+40)		
00005 00006	00700000 00 1 01200016 01 0	1 X00000 3 0 00016 2	EXT CIO RTJ CIO 01 14+2 IFT *+REJ	X•1			READS READS READS READS
00007 00010	01000024 01 0 40000026 40 0	0 P00024 0 0 P00026 0	IFF **REJ UJP REJX 40 INBUFF	X•1			READS READS
00011	40000050 40 (0 00050 0	40 40 IFF 0+2+1				READS READS READS
00012	00000022 00 (0 700022 0	00 INTADD				READS
00013	00700005 00 1	1 X00005 3	REWIND EXT CIO RTJ CIO	(14,*)			REWIND REWIND
00014	04000016 04 0	0 00016 0	04 14.0 IFT *.*.1				REWIND REWIND
00013	01000013 01	0 P00013 0	UJP #=2 IFF #:#:1 IFF 0:0:1				REWIND REWIND
			FORMAT Ext cio	(14,14,2)			FORMAT
00016 00017	00700013 00 1 14200016 14 0	1 X00013 3 0 00016 2	RTJ CIO 14 14.2 IFT *.14.	1			FORMAT FORMAT FORMAT
00020	01000016 01 0	0 00016 0	IFF **14* UJP 14	i			FORMAT FORMAT
00022	77770000 77 1 01077777 01 0	0 77777 0 INTADD	UCS UJP	**			
00023 00024 00025	01400022 01 1 01077777 01 0 01400024 01 1	1 P00022 0 77777 0 REJX 1 P00024 0	I • 9LU UJP UJP • I	INTADD ## REJX			
00026		INBUFF	85S END	40			
			NUMBER OF	INES WITH DIAGNOSTIC	5 0		
CIO CIO	(2•1)	MAC External	P00000	P00005	11/21 P00013	/66 PAGE P00016	1
INBUFF INTADD REJX	P00026 P00022		P00003 P00012	P00010 P00023	P00013	F00018	
7.04	P00024		P00007	P00025			

•

•

•

•

•

•

•

COMPASS-32 (2.1) EXAMPLE 26 (COPY)

11/21/66 PAGE

EXTERNAL SYMBOLS
PRORIVER
CRORIVER
MTDRIVER

ENTRY-POINT SYMBOLS
COPY 00000

LENGTH OF SUBPROGRAM 00112 LENGTH OF COMMON 00000 LENGTH OF DATA 00000

COMPASS-32 (2.1) EXAMPLE 26 (COPY) 11/21/66 PAGE ENTRY COPY
ENTRY COPY
EXT MIDRIVER, CRORIVER, PRORIVER
THIS SUBPROGRAM IS DESIGNED TO TEST THE DRIVERS THAT WERE WRITTEN
PREVIOUSLY (EXAMPLE 25 AND WORKSHEET 8). IT COPTES A DECK OF HOLLERITH
CARDS TO MAG TAPE, REWINDS THE TAPE AND COPIES THE TAPE ON THE PRINTER. PROGRAM REPEATS ON RESTART UNLESS JUMP KEY 1 IS SET IN WHICH CASE IT WILL EXIT BACK TO SCOPE. ** 00000 01077777 01 0 77777 0 COPY UJP LINKAGE BACK TO SCOPE ----- REWIND TAPE 1 -----108 PLACE FUNCTION CODE 00001 14600010 14 1 00010 2 00002 13077771 13 0 77771 0 00003 14600001 14 1 00001 2 00004 00777777 00 1 X77777 3 ENA IN Q 23-18 (REWIND)
PLACE TAPE NUMBER IN A 5-1 SHAQ -6 1 MTDRIVER ENA RTJ ----- READ NEXT CARD -----00005 14600054 14 1 P00054 2 NEXTCARD ENA 00006 13077755 13 0 77755 0 SHAQ 00007 14600001 14 1 00001 2 ENA 00010 13077771 3 0 77771 0 SHAQ 00011 00777777 00 1 X77777 3 RTJ BUF SHAQ ENA SHAQ RTJ -18 1 -6 CRDRIVER ----- TEST FOR END OF FILE CARD ------00012 17600010 17 1 00010 2 00013 03100023 03 0 P00023 1 ANA 108 AZJ.NE FILEMARK ----- OUTPUT CARD IMAGE TO MAG TAPE 1 -----00014 14600054 14 1 P00054 2 00015 13077755 13 0 77755 0 00016 14600003 14 1 00003 2 00017 13077771 13 0 77771 00020 14600001 14 1 00001 2 00021 00700004 00 1 X00004 3 **BUF** SHAQ ENA SHAQ -18 3 -6 1 MTDRIVER 00022 01000005 01 0 P00005 0 NEXTCARD

```
COMPASS-32 (2.1)
                                              EXAMPLE 26 (COPY)
                                                                                                                                    11/21/66 PAGE
                                                                    ----- CLOSE OUT MAG TAPE 1 WITH A FM -----
          00023 14600015 14 1 00015 2 FILEMARK ENA
00024 13077771 13 0 77771 0 SHAQ
00025 14600001 14 1 00001 2 ENA
00026 00700021 00 1 X00021 3
                                                                                  158
                                                                                    -6
                                                                    ENA
                                                                                   1
MTDRIVER
                                                                     ----- REWIND MAG TAPE 1 -----
          00027 14600010 14 1 00010 2
00030 13077771 13 0 77771 0
00031 14600001 14 1 00001 2
00032 00700026 00 1 x00026 3
                                                                     EΝΔ
                                                                                   108
                                                                     SHAU
ENA
RTJ
                                                                                   -6
1
MTDRIVER
                                                                     ----- READ NEXT RECORD FROM MAG TAPE 1 -----
          00033 14600054 14 1 P00054 2 NEXTREC ENA
00034 13077755 13 0 77755 0 SMAQ
00035 14600001 14 1 00001 2 ENA
00036 13077771 13 0 77771 0 SMAQ
00037 14600001 14 1 00001 2 ENA
00037 00700032 00 1 x00032 3 RTJ
                                                                                   BUF
                                                                     SHAQ
                                                                                    -18
                                                                     ENA
SHAQ
ENA
RTJ
                                                                                   1-6
                                                                                    I
MTDRIVER
                                                                     ----- TEST FOR END OF FILE -----
          00041 17600010 17 1 00010 2
00042 03100051 03 0 P00051 1
                                                                     ANA
                                                                     AZJ.NE
                                                                                   EXIT
                                                                     ----- OUTPUT RECORD TO PRINTER -----
          00043 14600054 14 1 P00054 2
                                                                     ENA
                                                                                   BUF
          00044 13077755 13 0 77755 0
00045 14600003 14 1 00003 2
00046 13077771 13 0 77771 0
00047 00777777 00 1 x77777 3
                                                                     SHAQ
ENA
SHAQ
                                                                                   -18
3
                                                                                   -6
PRDRIVER
                                                                     RTJ
          00050 01000033 01 0 P00033 0
                                                                     UJP
                                                                                    NEXTREC
                                                                     ----- EXIT PROCEDURE ----
          00051 77770000 77 1 70000 3 EXIT
00052 00100000 00 0 P00000 1
00053 01000001 01 0 P00001 0
                                                                     UCS
                                                                                   COPY
COPY+1
                                                                     SJ1
                                                                                                                                                                                       •
COMPASS-32 (2.1)
                                                 EXAMPLE 26 (COPY)
                                                                                                                                                                                       •
                                                                                                                                   11/21/66 PAGE
                                                                    ----- BUFFER AREA -----
         00054
                                                       BUF
                                                                    BSS
                                                                                  30
                                                                    END
                                                                                   COPY
                                                                   NUMBER OF LINES WITH DIAGNOSTICS
                                                                                                                                                                                       •
                                                                                                                                                                                       •
```

CUMPASS-32	(2•1)	EXAMPLE	26 (COPY)			11/21/66 PAGE	1
BUF COPY CHORIVER	P00054 P00000	EXTERNAL	P00005 P00052 P00011 P00042	P00014 P00053	P00033	P00043	
EXIT FILEMARK MTUHIVER	P00051 P00023	EXTERNAL	P00013 P00004 P00040	P00021	P00026	P00032	
NEXTCARD NEXTREC PRURIVER	P00J05 P00033	EXTERNAL	P00022 P00050 P00047				
						·	
CUMPASS-32			VERSION SI 0.0	12/07/64			
	(2.1)	CIC	ACKOTOM DI 000			11/21/66 PAGE	1
	(2•1)	cic	72.510. 31 0.0			11/21/66 PAGE	1
EXTERNAL SYN	IBOLS	cic	tensjon si oto			11/21/66 PAGE	1
EXTERNAL SYM CUI ABNORMAL	IBOLS	CIC				11/21/66 PAGE	1
CDI ABNORMAL	SYMBOLS					11/21/66 PAGE	1
ARNOKWAF CD1	MBOLS - SYMBOLS					11/21/66 PAGE	1
CUI ABNORMAL ENTRY-POINT CIC CIT LENGTH OF SI	SYMBOLS 00000 00044	0007z				11/21/66 PAGE	1
ENTRY-POINT CIC CIT	SYMBOLS SYMBOLS 00000 00044					11/21/66 PAGE	
CUI ABNORMAL ENTRY-POINT CIC CIT LENGTH OF SI LENGTH OF C	SYMBOLS SYMBOLS 00000 00044	00072 00000				11/21/66 PAGE	
CUI ABNORMAL ENTRY-POINT CIC CIT LENGTH OF SI LENGTH OF C	SYMBOLS SYMBOLS 00000 00044	00072 00000				11/21/66 PAGE	
CUI ABNORMAL ENTRY-POINT CIC CIT LENGTH OF SI LENGTH OF CI	SYMBOLS SYMBOLS 00000 00044	00072 00000				11/21/66 PAGE	
CUI ABNORMAL ENTRY-POINT CIC CIT LENGTH OF SI LENGTH OF CI	SYMBOLS SYMBOLS 00000 00044	00072 00000				11/21/66 PAGE	
CUI ABNORMAL ENTRY-POINT CIC CIT LENGTH OF SI LENGTH OF C	SYMBOLS SYMBOLS 00000 00044	00072 00000				11/21/66 PAGE	

```
CUMPASS-32
                                                                                                                                         VERSION SI 0.0
                                           (2.1)
                                                                                                       CIC
                                                                                                                                             /EMSION SI 0.0 12/07/64 11/21/66 PAG
CENTRAL INTERRUPT CONTROL PROCEDURE REVISED 12-04-64
                                                                                                                                                                                                                                                                                    11/21/66 PAGE
                                                                                                                                                                                                                                                                                                                                                          00004
                                                                                                                                                WHENEVER AN INTERRUPT OCCURS. THE HARDWARE
                                                                                                                                                                                                                                                                                                                                                          00006
                                                                                                                                                WHENEVER AN INTERRUPT OCCURS, THE HANDWAME
1. DISABLES THE INTERRUPT SYSTEM
2. HEPLACES (00004, BITS 14-00) WITH THE LOCATION OF THE INTERRUPTED INSTRUCTION
3. HEPLACES (000075, BITS 11-00) WITH AN IDETIFYING CODE
4. THANSFERS CPU CONTROL TO LOCATION 00005.
                                                                                                                                                                                                                                                                                                                                                          00007
                                                                                                                                                                                                                                                                                                                                                          00009
                                                                                                                                                                                                                                                                                                                                                          00011
                                                                                                                                                SCOPE-32 LOADS THE FOLLOWING LINKAGE TO CIC
                                                                                                                                                                                                                                                                                                                                                          00013
                                                                                                                                                (00004) UJP
(00005) NOP
(00006) UJP
                                                                                                                                                                                                                                                                                                                                                          00014
                                                                                                                                                                                                       0
OIC
                                                                                                                                                                                                                                                                                                                                                          00016
                                                                                                                                              CIC PERFORMS THE FOLLOWING TASKS

1. LOGICALLY IGNORES AN INTERRUPT ON A DINT INSTRUCTION
2. SAVES THE (A), (Q), (B1), (B2) AND (B3)
3. SETS LOCKOUT FLAG TO IDENTIFY INTERRUPT PROCESSING
4. THANSFORMS INTERRUPT CODE INTO RELATIVE CIT ENTHY
5. SETS ENTRY LOCATION (FHOM CIT) TO LINK TO HISEH
6. SETS INCL INSTRUCTION FOR EXECUTION ON USER RETURN
7. RESTORES ABORMAL ADDRESS TO CIT ENTRY
8. ENTERS USER INTERRUPT PROCEDURE
9. CLEARS NON-I/O INTERRUPTS
10. RESTORES SAVED REGISTERS
11. HESTORES SAVED REGISTERS
12. ENABLES INTERRUPT SYSTEM
13. EXITS TO INTERRUPTED PROGRAM
                                                                                                                                                                                                                                                                                                                                                          00018
                                                                                                                                                                                                                                                                                                                                                          00019
                                                                                                                                                                                                                                                                                                                                                          00021
                                                                                                                                                                                                                                                                                                                                                         00021
00022
00023
00024
00025
00026
00027
00028
                                                                                                                                                                                                                                                                                                                                                          00024
00030
00031
00032
```

	CUMPASS-32	(2.1)	CIC	VERSION SI ENTHY EXT	0.0 12/07/64 CIC+CIT ABNORMAL+CDI	11/21/66 PAGE 3	00034 00035
•	00000	45000045 45	0 P00045 0 CIC	STAG	CIT+1 SAV	E (A) AND (Q)	00037
_						PT ON DINT	00038
•	00001	24400004 24		LCA+I)) = INTERRUPTED INSTRUCTION	00039
	00002	37000043 37		LPA		K DINT INST (ZEHO BITS 11-0)	00040
_	00003	03100006 03		AZJ.NE		P IF ((4)) NOT DINT	00041
•	00004	20000045 20		LDA		E RESTORE (A)	00042
	00005	01400004 01	1 00004 0	UJP+I		EXIT. INTERRUPT DISABLED	00043
	00006	47100047 47	0 P00047 1 CIC2.1	STI	SAVE REGISTERS IN CIT -	F (B1)	00044
•	00007			SIT	CIT+4.2	(82)	00046
	00010	47300051 47		STI	CIT+5.3	(B3)	00047
	*****				SET LOCK-OUT FLAG		00048
	00011	14477777 14	1 77777 0	ENA+S	-0		00049
_	00012	40000044 40	0 P00044 0	STA	CIT		00050
•						TO RELATIVE CIT ENTRY	00051
	00013	54100005 54		LUI		D AND	00052
•		17107777 17		ANI		K INTERRUPT CODE	00053
•	00015			ISG		P IF NON-I/O INTERRUPT	00054
	00016 00017			INI		E GO PROCESS THEM Pute index relative to cit.	00055 00056
	00017	19111019 19	0 77075 1) INTO RTJ	00057
•	00020	20100044 20	0 P00044 1 CIC5.0			R ENTRY LOCATION GOES	00058
	00021	44000026 44		SWA		RTJ INSTRUCTION	00059
						NG INTERRUPT	00060
_	00022	12000006 12	0 00006 0	SHA		RACTER O CARRIES MASK	00061
_	00023	42000136 42	0 P00027 2	SACH	CIC9.0+2		00062
•					HESTORE ABNORMAL ADDRESS	TO CIT ENTRY	00063
	00024	14677777 14		ENA	ABNORMAL		00064
_	00025	44100044 44	0 P00044 1	SWA	CIT+1		00065
•					ENTER USER INTERRUPT PRO	CEDURE	00066
	00026	00700026 00	1 P00026 3 CIC8.0	RTJ	#		00067
	00027	77500000 77	1 00000 1 CIC9.0	INCL		/0	00068
•	00021	77500000 77	1 50000 1 6169.0	REM		WILL BE ZERO ON I/O	00069
				NEM -	INTERRUPTS . CLEARED WITH RESTORE LOCK-OUT FLAG -		00070
•	00030	14400000 14	1 00000 0	ENA , S	0		00072
-		40000044 40		STA	ČIT		00073
_					HESTORE SAVED REGISTERS		00074
	00032	54100047 54		LUI	CIT+3+1		00075
	00033	54200050 54		LDĪ	CIT+4.2		00076
	00034			LDI	CIT+5,3		00077
•	00035	25000045 25	0 P00045 0	LDAQ	CIT+1	- TO THE	00078
	00034	77740000 77	1 40000 3	<u>-</u>	EMARTE INTERMEDIT AND EXT.	T TO INTERRUPTED PROGRAM	00079
	00036 00037	77740000 77		EINT UJP+I	A .		00080
•	00031	01400304.01			TRANSFORM I/O INTERRUPT	-00F	00085
	00040	17100007 17	0 00007 1 CIC4-1	ANT		CHANNEL BITS	00083
•	00041	15100016 15		INI		PEASE (81) TO RELATIVE	00084
-	00042	01000020 01		UJP		NEL ENTRY AND CONTINUE	00085
_					CONSTANTS AND CENTRAL IN		00086
	00043	77730000 77	1 30000 3 DINT	DINT	_		00087

•

•

•

•

•

•

```
11/21/66 PAGE
                                                                                                                                                                                                                 12/07/64
                                                                                                        210
                                                                                                                                          VERSION SI 0.0
                                                                                                                                                                                                                                                                                                                                                            00089
00090
00091
COMPASS-32
                                            (2.1)
                                                                                                                                                                                        С
                                                                                                                                                                                                      ī
                                                                                                                                                                                                                                                                                                                                                             00092
00093
00094
                                                                                                                                                                                77777777 INTERRUPT LOCK-OUT FLAG.
VALUE IS -0 *HEN INTERRUPT PROCESSING IN PROGRESS.
INTERRUPT DISABLED. AND IS +0 OTHERWISE
                                                                                                                                                                                                                                               INTERRUPT LOCK-OUT FLAG.
                                                                                                                    CIT
                                                                                                                                                 ОСТ
                                                                   7777777
                      00044
                                                                                                                                                CONTENTS OF REGISTERS ON ENTRY TO CIC SAVED IN CIT AND RESTURED FROM THESE LOCATIONS (A) (U) (U) (CT 0 (B1)
                                                                                                                                                                                                                                                                                                                                                              00096
                                                                                                                                                                                                                                                                                                                                                             00097
                                                                                                                                                                                                                                                                                                                                                             00098
00099
00100
                                                                     00000000
                      00045
                      00046
00047
                                                                                                                                                                                0
                                                                     00000000
                                                                                                                                                                                                                                                                                                                                                              00101
                                                                                                                                                 OCT
                                                                     00000000
                       00050
                                                                                                                                                                                                                                                  (83)
                       00051
                                                                                                                                                NON-I/O USER INTERRUPT LINKAGE CELLS. INCL MASK IS IN CHARACTER 0 AND GOES INTO BIS 11-06 OF INCL INSTRUCTION. ADDRESS IS INITIALIZED TO ABNORMAL AND RESTORED PRIOR TO ENTRY TO A USER ROUTINE.

04 ABNORMAL CODE=0110 REAL TIME CLOCK
20 ABNORMAL 0111 ARTTHMETIC OVERFLOW
20 ABNORMAL 0112 DIVIDE FAULT
10 ABNORMAL 0113 EXPONENT OVERFLOW
110 ABNORMAL 0114 BCD FAULT
40 ABNORMAL 0115 SEARCH/MOVE
00 ABNORMAL 0116 MANUAL FROM CONSOLE
00 ABNORMAL 0117 ADJACENT PROCESSOR
1/O INTERRUPT LINKAGE CELLS. INCL MASK ACTS AS NOP - A CLEAR
MUST BE GIVEN IN THE I/O INTERRUPT PROCEDURE. ADDRESS
INITIALIZATION IS PERFORMED BY CIO.
00 CDI CHANNEL 0
00 CDI CHANNEL 0
00 CDI CHANNEL 2
00 CDI CHANNEL 3
                                                                                                                                                                                                                                                                                                                                                              00104
                                                                                                                                                                                                                                                                                                                                                             00104
00105
00106
00107
00108
                                           04000024 04 0 X00024 0
20000052 20 0 X00052 0
20000053 10 0 X00054 0
10000055 10 0 X00055 0
40000056 40 0 X00056 0
00000057 00 0 X00057 0
00000060 00 0 X00060 0
                       00052
00053
00054
00055
                                                                                                                                                                                                                                                                                                                                                              00109
                                                                                                                                                                                                                                                                                                                                                               00110
                                                                                                                                                                                                                                                                                                                                                              00113
                        00056
00057
                                                                                                                                                                                                                                                                                                                                                               00114
                                                                                                                                                                                                                                                                                                                                                                00115
                        00060
                                                                                                                                                                                                                                                                                                                                                              00115
00116
00117
00118
00119
                         00061
                                            00077777 00 0 X77777 0 CITCHO
0000062 00 0 X00062 0
0000063 00 0 X00063 0
0000065 00 0 X00065 0
0000066 00 0 X00065 0
0000066 00 0 X00066 0
0000067 00 0 X00067 0
                                                                                                                                                                                 CDI
CDI
CDI
CDI
                         00062
                         00063
00064
                                                                                                                                                                                                                                                                                                                                                                00121
                                                                                                                                                                                                                                                                                                                                                              00121
00122
00123
00124
00125
                                                                                                                                                                                                                                                  CHANNEL 3
CHANNEL 4
CHANNEL 5
CHANNEL 6
CHANNEL 7
                                                                                                                                                   00
                         00065
                                                                                                                                                   00
00
00
                                                                                                                                                                                  COI
                         00066
00067
00070
                                                                                                                                                                                                                                                                                                                                                                00127
                                                                                                                                                    END
                                                                                                                                                 NUMBER OF LINES WITH DIAGNOSTICS
```

	COMPASS-32 (2.1)	CIC	VERSION SI	0.0	12/07/64	11/2	1/66 PAGE	1
)	ABNORMAL		EXTERNAL	P00024 P00055 P00061	00111	P00052 00108 P00056 00112	P00053 00109 P00057 00113	P00054 P00060	
	CDI		EXTERNAL	P00062 P00066	00119	P00063 00120 P00067 00124	P00064 00121 P00070 00125	P00065 P00071	
	CIC2.1 CIC4.1 CIC5.0 CIC8.0	P00006 P00040 P00020 P00026		P00003 P00016 P00042 P00021	00055 00085 00059				
	CIC9.0	P00027 P00044		P00023 P00000 P00010 P00031	00037 00047 00073	P00004 00042 P00012 00050 P00032 00075	P00006 00045 P00020 0005R P00033 00074	P00025	00065
	CITCHO DINT	P00062 P00043		P00035 P00041 P00002	00084	P00041 00084			

SYMBOLS NOT REFERENCED

*CIC P00000

lacktriangle

•

•

•

EXTERNAL SYMBOLS

ENTRY-POINT SYMBOLS
MTMTCIO 00000

LENGTH OF SUBPROGRAM 00274 LENGTH OF COMMON 00000 LENGTH OF DATA 00000

COMPASS-32 (2.1)

MTMTCIO

THIS SUBPROGRAM COPIES A VARIABLE SIZE RECORD IMPUT TAPE (LOGICAL UNIT 14) TO ANOTHER TAPE (LOGICAL UNIT 15) THE DENSITY OF THE OUTPUT TAPE WILL BE THE DENSITY SET BY THE OPERATOR. THIS SUBPROGRAM DOES NOT CHECK FOR TAPE ERRORS, PARITY IS CHECKED ONLY TO INSURE THAT THE MODE OF THE INPUT TAPE IS THE SAME AS THE MODE SELECTED.

			ENTHY	MTMTCIO	•
			EXT	CIO	
00000	01077777 01		UJP	**	
00001	00777777 00		LIN	CIO	REWIND INPUT TAPE
00002	04000016 04		04	14	
00003	01000001 01		UJP	*-2	
00004	00700001 00		ΝTJ	CIO	REWIND OUTPUT TAPE
00005	04000017 04		04	15	
00006	01000004 01		UJP	*-2	
00007	00700004 00		RTJ	CIO	ASSUME AND SET INPUT TAPE TO
00010	14200016 14		14	14,2	BINARY MODE (MODE MAY BE CHANGED
00011	01000007 01		UJP	*-2	LATER)
00012	00700007 00		нŢJ	CIO	INITIATE READING INPUT RECORD
00013	01000016 01		01	14	FROM LOGICAL UNIT 14 (MAX RECORD
00014	01000012 01		UJP	*-2	SIZE IS 500 CHARACTERS)
00015	00000374 00		00,C	INBUFF	
00016	40000764 40		40	500	
00017	00700012 00		RTJ	CIO	WAIT UNTIL THE INPUT IS COMPLETE
00020	13100016 13		13	14+1	
00021	03200017 03		AZJ•GE	* - 2	
00022	17702010 17	1 02010 3	ANQ	20108	MASK OUT EVERY SATAUS BIT EXCEPT
					EOF AND PARITY
00023	04700000 04		USF	0	WAS THERE AN EOF OR PARITY ERROR
00024	01000046 01		UJP	TEST	YES JUMP TO TEST.
00025	37000076 37		LPA	MASK	AFTER STATUS REQUEST (A) = LCA+1
00026	31000015 31		SHA	FCA	CALCULATE NUMBER OF INPUT CHAR-
00027	44000041 44		SWA	NOC	ACTERS AND STORE IN OUTPUT
00030	22000041 22		LACH	MODE+1	FETCH MODE OF INPUT RECORD AND
00031	42000155 42	0 P00033 l	SACH	OUTMODE+1	STORE TO SET OUTPUT MODE THE
00032	00700017 00		HTJ	CIO	SAME AS INPUT.
00033	14000017 14 (14	15.0	- · · · · · · - · · · · · · · · · · · ·
00034	01000032 01 (UJP	*=2	
00035	00700032 00		ATJ	CIO	INITIATE WRITING OUTPUT BUFFER
00036	02000017 02 (02	15	
00037	01000035 01 (UJP	*-2	
00040	00000374 00 0	0 P00077 0	00.C	INBUFF	
00041	40000000 40 0	0 00000 0 NOC	40	0	
00042	00700035 00 1	1 X00035 3	КŤJ	Č10	WAIT UNTIL OUTPHT IS COMPLETE
00043	13100017 13 (13	15.1	
00044	03200042 03 (AZ.J+GE	*-2	
00645	61000007 01 0	0 P60007 0	QU	400E-1	LOOP TO READ NEW INPUT RECORD
00046	17700010 17 1	1 00010 3 TEST	ANO	108	
00047	04700000 04 1		ÚSF.	0	WAS AN EOF READ
00050	01000061 01 0	0 P00061 0	UJP	FOF	YES JUMP TO FOF
					THE DOME TO EUR

COMPASS=32	(2.1)			ATMTCIO			11/21/66 PAGE
00051	77770000 7	7 1			UCS		IF PARITY ERROR STOP SO THE OPERATOR MAY DECIDE IF IT IS A LEGAL PARITY ERROR OR WRONG MO
00052	00700042 0	0 1	X00042	3	RTJ	CIO	BACKSPACE INPUT TAPE A RECORD
00053	06000016 0	6 0	00016	0	06	14	BACKSPACE INDUI TAPE A RECORD
00054	01000052				UJP	*-2	SCT-11 ACCUMEN MADE AND
00055	22000041 2	2 0	P00010	1	LACH	MODE+1	FETCH ASSUMED MODE AND
00056	16600030 1	6 1	00030	2	AOA	308	CHANGE IT. SET NEW MODE IN SEL CALL AND
00057		2 0	P00010	1	SACH	MODE+1	
00060	01000007	1 0	P00007	0	UJP	MODE-1	TRY AGAIN.
			×	3 EOF	RTJ	CIO	WRITE EOF ON OUTPUT TAPE
00061	00700052	10 1	AUUU32		11	15	-,
00062	11000017	1 0	00017	0	ÜJP	*•2	
00063	01000061	1 0	P00001	2	SLS		STOP IF SELECTIVE STOP SWITCH
00064	77700000	7 1	00000	3	363		SET ON CONSOLE.
00065	00100067	0 0	P00067	1	SJ1	EXIT	EXIT AND UNLOAD TAPES IF JUMP KEY 1 IS SET, ON CONSOLE.
00066	01000007	01 0	P00007	0	QLU	MODE-1	LE NOT JUMP TO READ INPUT RECO
*****	00700061		Y00061	3 EXII	. RTJ	CIO	UNLOAD INPUT TAPE
00067					05	14	
00070	05000016	25 0	00010		ÜJP	*=2	
00071	00700067				RTJ	C10	UNLOAD OUTPUT TAPE
00072	05000017	00 1	000001		05	15	
00073	01000072	03 0	P00072	ň	ÜJP	*-2	
00074	014000072				UJP • I	MTMTCIO	EXIT TO SCOPE
00075 00076		0377		MASI		377777	
00077	U	0311		INB		500	
00077				•	END	MTMTCIO	
					MINOED O	F LINES WITH DIA	GNOSTICS 0

•	COMPASS-32	(2.1)	MTMTCIO			11/	/21/66 PAGE	1
•	CIO		EXTERNAL	P00001 P00017 P00052	P00004 P00032 P00061	P00007 P00035 P00067	P00012 P00042 P00072	
•	EOF Exit FCA	P00061 P00067 P00015		P00050 P00065 P00026				
•	INBUFF MASK MODE	P00077 P00076 P00010		P00015 P00025 P00030 P00060	P00040 P00045 P00066	P00055	P00057	
•	MTMTCIO NOC OUTMODE TEST	P00000 P00041 P00033 P00046		P00075 P00027 P00031 P00024				

• •

lacktriangle

•

ENTRY-POINT SYMBOLS
TYPEIN 00000

LENGTH OF SUBPROGRAM LENGTH OF COMMON LENGTH OF DATA 00027 00000 00000

COMPASS-32 (2.1) TYPEIN

THIS SUBROUTINE ALLOWS FOR TYPING IN A VARIABLE QUANTITY OF FOUR DECIMAL DIGIT NUMBERS. THE INPUT IS TERMINATED WHEN A PERIOD IS TYPED IN, THE CALLING SEQUENCE IS.

CALL (P) = RIJ TYPEIN

(P+1) = RETURN

(A) = FIRST CHARACTER ADDRESS OF INPUT BUFFER

0

OUTPUT (81) = NUMBER OF NUMBERS

							ENTHY	TYPEIN	
00000	01077777	01	0	77777	0	TYPFIN	UJP	**	
00001	14100000				ì		ENI	0.1	CLEAR B1
00002	46000020	46	0	P00020	ō		SCHA	CKPERIOD	C D1
00003	46000010	46	0	P00010	0		SCHA	SET23	SAVE INPUT PAR.
00004	15400004	15	1	00004	0		INA . S	4	Serve and or range
00005	77600400	77	1	00400	2		PAUS	400B	IS THE TYPEWRITER BUSY
00006	01000005	01	0	P00005	0		عرا	#=1	YES LOOP
00007	53420033	53	1	S0033	0		TAM	33B	SET LAST CHARACTER ADDRESS+1 OF
									INPUT BUFFER INTO REGISTER FILE
									LOCATION 33B.
00010	11377777	11	0	77777	3	SET23	ECHA	**	£
00011	53420023	53	1	20023	0		TAM	238	SET FIRST CHARACTER ADDRESS INTO
									REGISTER FILE LOCATION 238.
00012	77750000				3		CTI		SET TYPE IN
00013	77602000					LOOP	PAUS	2000B	HAS THE REPEAT SWITCH ON TYPE+
00014	01000016	01	0	P00016	0		QLU	FINISH	WRITER BEEN PUSHED-YES JUMP TO
00015	01000010	01	0	P00010	0		O JP	SET23	ADDRESS SET23 AND START OVER-
								-	NO JUMP TO FINISH.
00016	77601000	77	1	01000	5	FINISH	PAUS	10008	HAS THE FINISH SWITCH BEEN
00017	01000013				0		UJP	LOOP	PUSHED-NO JUMP TO LUDP.
00020	22377777			77777	3	CKPERIOU	LACH	**	,
00021	04600033			00033			ASE	338	IS THE FIRST CHARACTER A PERIOD-
00022	01000024	01	0	P00024	Ű		UJP	BYPASS	YES EXIT-NO JUMP TO BYPASS
00023	01400000	01	1	P00000	0		UJP•I	TYPEIN	
00024	15100001	15	0	00001	1	BYPASS	INI	1+1	INCREASE BI BY 1
00025	53020033						TMA	338	SET NEW INPUT BUFFER AND LOOP
00026	01000002	01	0	F00002	0		UJP	TYPEIN+2	TO TYPEIN+2
							END		

NUMBER OF LINES WITH DIAGNOSTICS

CUMPASS-32 (2.1) BYPASS PU0024 CKPERIOD P00020 FINISH P00016	TYPEIN	200022 200002 200014		11/21/66 PAGE 1	•
LUUP P00013 SET23 P00010 TYPEIN P00000		P00017 P00003 P00023	F00015 P00026		
					(
					•
					•
					•
COMPASS-32 (2.1)	SORT			11/21/66 PAGE 1	
ENTRY-POINT SYMBOLS SORT 0000	0				
LENGTH OF SUBPROGRAM LENGTH OF COMMON LENGTH OF DATA	00030 00000 00000				

•

•

•

•

•

• • • •

lacktriangle

.

•

```
COMPASS-32
                                     (2.1)
                                                                                                                               THIS SUBPROGRAM SORTS A BLOCK OF NUMBERS INTO ASCENDING ORDER.

UPON ENTRY THE ADDRESS OF THE FIRST NUMBER IS LOCATED IN THE
LOWER 15 BITS OF THE A REGISTER AND THE NUMBER OF NUMBERS IS IN
82.
                                                                                            SORT
                                                                                                                                                 (P) =RTJ SORT
(P+1)=RETURN
(A) =AODRESS OF THE FIRST NUMBER
(B1) =NUMBER OF NUMBERS
                                                                                                                               CALL
                                                                                                                               ENTRY
                                                                                                                                                          SORT
                  00000 01077777 01 0 77777 0 SORT 00001 44000010 44 0 P00010 0
                                                                                                                                                                                                                   SAVE FIRST WORD ADDRESS OF DATA BLOCK.
ADD FIRST WORD ADDRESS TO NUMBER OF FINHTES TO CALCULATE LAST WORD ADDRESS+1 OF INPUT BLOCK.
                                                                                                                                                           INIT-1
                                     53640000 53 1 40000 2
                                                                                                                               IAT
                                   15277776 15 0 77776 2
47200022 47 0 P00022 2
15277776 15 0 77776 2
47200024 47 0 P00024 2
47100026 47 0 P00026 1
14177777 14 0 77777 1
                  00003
00004
00005
                                                                                                                               INI
STI
INI
STI
STI
                                                                                                                                                          -1.2
INLOOP.2
                                                                                                                                                                                                                   SET LIMIT OF INLOOP PASSES
                                                                                                                                                          -1.2
OUTLOOP.2
                  00006
00007
00010
                                                                                                                                                                                                                  SET LIMIT OF OUTLOOP PASSES SAVE (81)
ENTER 81 WITH FIRST WORD ADDRESS OF INPUT BLOCK
                                                                                                                                                          BSAVE,1
                                  53100000 53 0 00000 1 INIT
15600001 15 1 00001 2
53600000 53 1 00000 2
21100000 21 0 00000 1
                  00011
00012
00013
                                                                                                                               TIA
                                                                                                                               INA
TAI
LOG
                                                                                                                                                                                                                   SET B2 EQUAL TO (B1)+1
                   00014
                                                                                                                                                                                                                  LOAD Q WITH FIRST NUMBER FOR
THIS PASS.
LOAD A WITH NEXT NUMBER
IS A GE Q YES JUMP TO INLOOP
IF (A) WAS LESS THAN (4) SWAP
THE REGISTER AND ALSO SWAP THEM
IN CORP
                                                                                                                                                          0,1
                                 20200000 20 0 00000 2 L000P
03600022 03 1 P00022 2
41200000 41 0 00000 2
40100000 40 0 00000 1
13000030 13 0 00030 0
10277777 10 0 77777 2 INLOOP
01000015 01 0 P00015 0
10177777 10 0 77777 1 OUTLOOP
01000011 01 0 P00011 0
14177777 14 0 77777 1 BSAVE
                  00015
00016
00017
                                                                                                                               LDA
AQJ•GE
STQ
STA
                                                                                                                                                         0.2
INLOOP
0.2
0.1
24
                   00020
                                                                                                                               SHAG
                                                                                                                                                                                                                   IN CORE.
                                                                                                                              ISI
UJP
ISI
UJP
ENI
UJP•I
END
                   00022
                  00023
00024
00025
00026
                                                                                                                                                          LOUP
**•1
INIT
**•1
                  00027
                                                                                                                                                          SORT
                                                                                                                             NUMBER OF LINES WITH DIAGNOSTICS
```

CUMPASS-32 (2.1) SORT 11/21/66 PAGE P00026 P00011 P00022 P00015 P00024 BSAVE INIT P00007 P00001 P00004 P00023 P00006 P00025 INLOOP LOUP OUTLOOP P00016

SOHT

P00000

```
11/21/66 PAGE
                                                                               TYPEOUT
          CUMPASS-32
                                      (2.1)
             ENTRY-POINT SYMBOLS
TYPEOUT 00000
                                                                                                                                                                                                                                                                             •
              LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
                                                                     00010
                                                                     00000
                                                                                                                                                                                                                                                                             •
                                                                                                                                                                                                                                                                             •
                                                                                                                                                                                                                                                                             •
                                                                                                                                                                                                                                                                             •
11/21/66 PAGE
THIS SUBROUTINE ALLOWS FOR TYPING OUT A VARIBLE NUMBER OF
CHARACTERS.THE CALLING SEQUENCE IS.
                                                                                                                                                                                                                                                                             •
           COMPASS-32
                                                                               TYPEOUT
                                                                                                                          (A) =FIRST CHARACTER ADDRESS OF OUTPUT BUFFER
(81) =NUMBER OF CHARACTERS IN OUTPUT BUFFER
(P) =RTJ TYPEOUT
(P+1) =RETURN
                                                                                                                                                                                                                                                                             •
                                                                                                           ENTRY
                                                                                                                               TYPEOUT
                         00000 01077777 01 0 77777 0 TYPEOUT 00001 77600400 77 1 00400 2 00002 01000001 01 0 P00001 0 00003 53420023 53 1 20023 0
                                                                                                           UJP
PAUS
                                                                                                                                **
400B
                                                                                                                                                                        IS THE TYPEWRITER BUSY
YES LOOP AND WAIT UNTIL NOT BUSY
TRANSFER FIRST CHARACTER ADDRESS
INTO REGISTER FILE LOCATION 238.
CALCULATE LAST CHARACTER ADDRESS
1 BY ADDING (A) AND (B1).
TRANSFER LCA+1 INTO RF 338
SET TYPE OUT
                                                                                                                                                                                                                                                                             •
                                                                                                           UJP
                                                                                                                                *-1
23B
                                                                                                                                                                                                                                                                             •
                                                                                                                               1
                          00004 53140000 53 0 40000 1
                                                                                                           AIA
                                                                                                           TAM
CTO
UJP,I
END
                          00005 53420033 53 1 20033 0
00006 77760000 77 1 60000 3
00007 01400000 01 1 P00000 0
                                                                                                                                33B
                                                                                                                                                                                                                                                                             •
                                                                                                                                TYPEOUT
                                                                                                         NUMBER OF LINES WITH DIAGNOSTICS
```

•								•
•		(2.1) P00000	TYPEOUT	P00007	11/21/	66 PAGE	1	•
•				, ••••				•
•								•
•								•
•								•
•								•
•								•
•								
•						•		
•								
•								
•								
•								•
•								•
•								•
•								•
•								•
•								
•								
•								
•								•
•								•
•	COMPASS=32	(2.1)	FLOATF		11/21/	66 PAGE	1	•
•								•
•	ENTRY-POINT FLOATF	SYMBOLS						•
•	FLOAT	00000						•
•								
•	LENGTH OF S LENGTH OF C LENGTH OF D	UBPROGRAM OMMON	00025					
_	LENGTH OF D	ATA	00000					
•								
•								
•								•
•								•
•								•
•								•
•								•
•								
-								
•								
•	•							
•	·							•
•	•							•

```
THIS SUBPROGRAM CONVERTS AN INTEGER NUMBER INTO FLOATING POINT FORMAT, UPON ENTRY THE ADDRESS OF THE INTEGER NUMBER IS LOCATED IN THE LOWER IS BITS OF P+1.
                                                                                                            FLOATE
               COMPASS-32
                                                      (2.1)
                                                                                                                                                CALL (P) = RTJ FLOATF
                                                                                                                                                                (P+1) = ADDRESS OF THE INTEGER NUMBER (P+2) = RETURN
                                                                                                                                                OUTPUT (AQ) = FLOATING POINT EQUIVALENT OF THE INTEGER NUMBER
                                                                                                                                               ENTRY
UJP
                                                                                                                                                                           FLOAT, FLOATF
                                  00000 01077777 01 0 77777 0 FLOATF

        00000
        010777777
        01
        0
        777777

        00000
        00000
        00000
        00000
        1

        00002
        5410000
        54
        0
        P000021
        1

        00003
        20500000
        20
        1
        00000
        1

        00004
        15100001
        15
        0
        00001
        1

        00005
        74000022
        47
        0
        P00021
        0

        00006
        13077747
        13
        0
        77747
        0

        00010
        40000023
        40
        0
        P00023
        0

        00011
        13502057
        13
        1
        02057
        1

                                                                                                                                                                           FLOATE
                                                                                                                                                                                                                                     EQUATE FLOAT TO FLOATF
                                                                                                                      FLUAT
                                                                                                                                                EQU
                                                                                                                                                                                                                                    SAVE BI
LOAD BI WITH ADDRESS OF INTEGER
LOAD A WITH INTEGER NUMBER
INCREASE AND SET RETURN ADDRESS
TO P+2 OF CALLING ROUTINE
                                                                                                                                                                            FOUT.1
FLOATF.1
                                                                                                                                               LDI
LDA+I
INI
STI
SHAQ
AQJ+EQ
STA
SCAQ
                                                                                                                                                                           0.1
                                                                                                                                                                           1.1
EXIT
                                                                                                                                                                           -24
FOUT
MASKO
20578•1
                                                                                                                                                                                                                                    DID THE INPUT NUMBER=0 YES EXIT SAVE SIGN OF INPUT NUMBER NORMALIZE THE INTEGER BY USING THE SCALE INSTRUCTION MERGE THE EXPONENT AND BIAS (CONTENTS OF B1) WITH THE MANTISSA
0
                                                                                                                                               SHAG
                                                                                                                                                                           -11
                                   00012 13077764 13 0 77764 0
                                                  41000024 41 0 P00024 0
13077763 13 0 77763 0
53100000 53 0 00000 1
36000023 36 0 P00023 0
                                  00013
00014
00015
                                                                                                                                                STQ
SHAQ
                                                                                                                                                                            TEMP
                                                                                                                                                                            -12
                                                                                                                                                                                                                                     COMPLEMENT EXPONENT AND BIAS IF THE INPUT NUMBER WAS NEGATIVE.
                                                                                                                                                                            MASKO
                                   00016
                                  00017 13000014 13 0 00014 0
00020 21000024 21 0 P00024 0
00021 14177777 14 0 77777 1
00022 01077777 01 0 77777 0
                                                                                                                                                SHAQ
                                                                                                                                               LOQ
ENI
UJP
OCT
BSS
END
                                                                                                                                                                            TEMP
**,1
.
                                                                                                                       FOUT
EXIT
MASKO
                                  00023
                                                                            0000000
                                                                                                                                                                            0
                                                                                                                                               NUMBER OF LINES WITH DIAGNOSTICS
                                                                                                                                                                                                                                                                                                                                                                          •
                                                                                                                                                                                                                                                                                                                                                                          •
                                                                                                                                                                                                                                                                       11/21/66 PAGE
                COMPASS-32
                                                       (2.1)
                                                                                                             FLOATF
                                                                                                                                                         P00005
                                 EXIT
                                                                  P00022
                                 FLOATF
FOUT
MASKO
                                                                  P00000
P00021
P00023
                                                                                                                                                         P00000
P00001
P00010
                                                                                                                                                                                                     P00002
                                                                                                                                                                                                     P00007
P00016
P00020
                                 TEMP
                                                                  P00024
                                                                                                                                                          P00013
  •
                      SYMBOLS NOT REFERENCED
                                            *FLOAT
                                                                       P00000
                                                                                                                                                                                                                                                                                                                                                                          •
                                                                                                                                                                                                                                                                                                                                                                          •
```

```
CUMPASS-32 (2.1)
                                                                                    CROTP
                                                                                                                                                                                                                                             11/21/66 PAGE
    ENTRY-POINT SYMBOLS
CROTP 00000
     LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
                                                                             00121
                                                                             00000
                                                                                                                           THIS SUBPROGRAM COPIES A FILE OF CARDS FROM A CARD READER (UNIT 0-CONTROLLER 3.0N CHANNEL 0) TO A TAPE UNIT (UPIT 1.CONTROLLER 0 ON CHANNEL 1). THIS SUBPROGRAM DOES NOT CHECK FOR CARD OF TAPE ERRORS. THE MODE OF EACH TAPE RECORD IS DETERMINED BY THE MODE OF THE CARD RECORD. THE OFFNSITY OF THE OUTPUT TAPE WILL GE THE DENSITY SET BY THE OPERATOR.
COMPASS-32
                                                                                          CROTP
```

•									
ĺ							ENTRY	CRDTP	
_	00000	01077777	7 01	0 7777	7 0	CHUTP	UJP	**	
•	00001	77003000				•	CUN	30008.0	CONNECT CARD READER ON CHANNEL O
1	00002	01000001	01	0 P0000	1 0		ÜJP	*-1	Carried Control (Carried Control Carried Contr
۱ ـ	00003	77010001	77	0 1000	1 0		CUN	18•1	CONNECT OUTPUT TAPE ON CHANNEL
●	00004	01000003	01	0 P0000	3 0		UJP	#=1	
	00005	77110010	77	0 1001	0 1		SEL	108,1	REWIND OUTPUT TAPE
! _	00006	01000005	01	0 P0000	5 0		UJP	*-1	
•	00007	77200000				INPUT	CUPY	0	15 THE CARD READER HEADY AND
	00010	17600003					ANA	38	NOT AUSY-YES INITIATE INPUT-
	00011	04600001					ASE	18	NO LOOP UNTIL IT BECOMES HEADY
•	00012	01000007					UJP	INPUT	AND NOT BUSY.
	00013	74000121					INP	0.BUFF.BUFF+40	INITIATE READING A BINARY OR
	00014	00000051							
•	00015	01000013					UJP	*-2	HCD_CARD.
	00016	7/200002					EXS	59 • 0	WALT UNTIL THE CARD HEADER
	00017	01000016					UJP	4-1	RECOMES NOT BUSY.
•	00020	77200004					EXS	4H+0	WAS THE CARD JUST READ A BINARY
	15000	01000041					UJP 	HINARY	CARD YES JUMP TO BINARY.
	00055	77200010					EXS	100.0	WAS A FILE CARD GEAU (ROW 7 AND
	00023 00024	01000044					UJP	EOF	A PUNCHED) YES JUMP TO EOF
	00024	42000133					ENA	28	-FF can used and authors sens
	00025	77110000				SELMODE	SACH SEL	SELMODE+3	SET ACD MODE FOR OUTPUT TAPE.
	00027	01000026				3554005	076 350	0 • 1 *-1	*
	00030	53020000					IMA	0	FETCH LAST CHARACTER ADDRESS+1
	00031	12077775					SHA	-2	AND CHANGE IT TO LAST WORD
_		********	• • •		, ,		3.14	-2	ADURESS+1
	00032	44000033	44	0 20003	9 0		SWA	OUTPUT	STURE ADDR IN OUTPUT INSTRUCTION
	00033	76077777				OUTPUT	OUTW	1.8UFF.**	INITIATE WRITING OUTPUT BUFFER
	00034	10000051	10	0 P0005	1 0				•
_	00035	01000033	01	0 P0003	3 0		IJΡ	*-2	
•	00036	77210002	77	0 1000	5 5		EXS	28 • 1	WAIT UNTIL THE OUTPUT TAPE
	00037	01000036	01	0 P0003	5 0		UJP	*-1	HECOMES NOT HUSY
_	00040	01000007	01	0 P0000	7 0		UJP	INPUT	
						****	****		************
						***	*****	*****	****
	00041	14600001				BINARY	ENA	1	SET BINARY MODE FOR OUTPUT TAPE.
	00042						SACH	SELMODE+3	
	00043	01000056	0.1	0 20005	5 0		JJP	SELMODE	
•						*****	******	**************	***************************************
	00044	77110015	77	0 1001	5 1	EOF	SEI	158•1	WRITE EOF ON OUTPUT TAPE
	00045	01000044					UJP	#=1	TOTAL BETT BUT WELL BY THE
	00046	77110011					SEL	118+1	INLOAD OUTPUT TAPE (UNIT 1)
				,	•				

```
COMPASS-32 (2:1) CRDTP
00047 01000046 01 0 P00046 0
00050 01400000 01 1 P00000 0
                                                                                                                                                                           11/21/66 PAGE
                                                                                            UJP, I
BSS
END
                                                                                                               CRDTP
CRDTP
CRDTP
                                                                                                                                                   EXIT TO SCOPE
                                                                                            NUMBER OF LINES WITH DIAGNOSTICS
•
          CUMPASS-32
                                   (2.1)
                                                                      CHDTP
                                                                                                                                                                          11/21/66 PAGE
                    BINARY
BUFF
CROTP
EOF
INPUT
OUTPUT
SELMODE
                                         P00041
P00051
P00000
P00044
P00007
P00033
P00026
                                                                                                  P00021
P00013
P00050
P00023
P00012
P00032
P00025
                                                                                                                               P00013
                                                                                                                                                            P00033
                                                                                                                               P00040
                                                                                                                               P00042
                                                                                                                                                            P00043
```

•							DENSITY THIS SUB CHECKED	SET BY THE OPERATOR. PROGRAM DOES NOT CHECK	ITY OF THE OUTPUT TAPE WILL BE THE K FOR TAPE ERRORS.PARITY IS HE MODE OF THE INPUT TAPE IS THE	•
•										•
_							ENTRY	MTMT		_
•	00000	01077777	01 (77777	0	MTMT	UJP	**		•
	00001	77000001					CON	18•0	CONNECT INPUT TAPE (UNIT 1)	
	00002	01000001					UJP	*-1	ON CHANNEL O	
•	00003	77010002					CON	28 • 1	CONNECT OUTPUT TAPE (UNIT 2)	•
	00004	01000003					UJP	*-1	ON CHANNEL 1	
	00005	77100010					SEL QLU	108.0	REWIND INPUT TAPE	
•	00006	01000005 77110010					SEL	*-1 108•1	REWIND OUTPUT TAPE	•
	00010	01000007					UJP	*-1	REWIND COTTO! TAPE	
	00011	77100001				MODE	SEL	18.0	ASSUME AND SET INPUT TAPE TO	
•	00012	01000011				MODE	UJP	#=1	BINARY MODE (MODE MAY BE CHANGED	•
1	00012	0100001	••		•		•••		LATER).	
	00013	73001270	73 (P00256	0		INPC	0.INRUFF.INBUFF.500	READ INPUT RECORD FROM TAPE UNIT	•
1	00014	00000304					, -			
	00015	01000013	01 (P00013	0		UJP	**2	1 (MAX RECORD SIZE IS 500	_
									CHARACTERS)	•
_	00016	77200002	77 (00002	2		EXS	28.0	WAIT UNTIL INPUT IS COMPLETE	
_	00017	01000016	01 (P00016	0		UJP	+-1		_
●	00020	77200010	77 (00010	2		EXS	108.0	WAS AN EOF READ	•
I	00021	01000047	01 (P00047	0		UJP	EOF	YES JUMP TO EOF	
1 -	00022	77202000					EXS	20008,0	WAS THERE A PARITY ERROR	_
	00023	01000040					UJP	SETMODE	YES JUMP TO CHANGE MODES	•
	00024	53020000	53 (50000	0		TMA	0	FETCH LAST CHARACTER ADDRESS OF	
							CCA		INPUT RECORD+1	
	00025	46000032	46 () P00032	. 0		SCHA	OUTPUT	STORE CHARACTER ADDRESS IN OUT-	•
İ					-				PUT INSTRUCTION.	
	00026	22000047					LACH	MODE+3	FETCH MODE OF INPUT RECORD AND STORE TO SET OUTPUT MODE THE	•
_	00027 00030	42000143 77110000				OUTMODE	SACH SEL	OUTMODE+3	SAME AS INPUT	•
İ	00030	01000030				OUTMODE	UJP	0,1 *-1	Same as Ideal	
	00032	75377777				OUTPUT	OUTC	1.INBUFF.**	INITIATE WRITING DUTPUT RECORD	•
•	00032	10000304				001701	0010	INTROPPE	THE THE BUTTLE BOLLOL MECOND	•
	00034	01000032					UJP	*-2		
	00034	77210002					EXS	28,1	WAIT UNTIL OUTPUT IS COMPLETE	•
1	00036	01000035					บัวิค	*-1	THE DATE OF THE TOTAL STATE	
	00037	01000011					UJP		LOOP TO READ NEW INPUT RECORD	_
•						*****	*******	**************	*************	•
_						*****	*******	******	************	
1 '_							*******	*************	***********	_
•	00040	77770000	77	70000	3	SETMODE	UCS		IF PARITY ERROR STOP SO THE OPERATOR MAY DECIDE IF IT IS A	
l 🕳									LEGAL PARITY ERROR OR WRONG MODE	•
I •	00041	77100012	77 (00012	1		SEL	120.0	RACKSPACE INPUT TAPE A RECORD	

```
11/21/66 PAGE
COMPASS-32
                  (2.1)
        00042 01000041 01 0 P00041 0
00043 22000047 22 0 P00011 3
00044 16600003 16 1 00003 2
00045 42000047 42 0 P00011 3
                                                           UJP
                                                                         *-1
MODE+3
                                                           LACH
XOA
SACH
                                                                                                  FETCH ASSUMED MODE AND
                                                                                                  CHANGE IT
SET NEW MODE IN SEL INSTRUCTION
AND TRY AGAIN.
                                                                         3
MODE+3
                                                  00046 01000011 01 0 P00011 0
                                                                                                                                                                  •
        00047 77110015 77 0 10015 1 EOF
00050 01000047 01 0 P00047 0
00051 77700000 77 1 00000 3
                                                           SEL
                                                                        158.1
*-1
                                                                                                WRITE EOF ON OUTPUT TAPE
                                                  •
         00052 00100054 00 0 P00054 1
                                                                                                                                                                  •
         00053 01000011 01 0 P00011 0
                                                                                                                                                                  EXIT SEL UJP SEL UJP INBUFF BSS.C ENO
        00054 77100011 77 0 00011 1 EXIT
00055 01000054 01 0 P00056 0
00056 77110011 77 0 10011 1
00057 01000056 01 0 P00056 0
00060 01400000 01 1 P00000 0
                                                                                                  UNLOAD INPUT TAPE
                                                                                                                                                                 •
                                                                        *-1
118,1
*-1
MTMT
                                                                                            UNLOAD OUTPUT TAPE
                                                                                                                                                                  •
         00061
                                                                         500
                                                                         MTMT
                                                           NUMBER OF LINES WITH DIAGNOSTICS
                                                                                                       0
                                                                                                                                                                  •
                                                                                                                                                                  11/21/66 PAGE
                                                                                                                                                                  •
                                                                                                                                            1
 COMPASS-32 (2.1)
                                            MTMT
                                                                P00021
        EOF
                       P00047
        EXIT
INBUFF
MODE
                       P00054
P00061
P00011
                                                                P00052
P00013
P00026
                                                                                     P00013
P00037
P00053
                                                                                                         P00032
P00043
                                                                                                                              P00045
                                                                                                                                                                  lacktriangle
                                                                 P00046
        MTMT
OUTMODE
OUTPUT
SETMODE
                                                                P00060
P00027
P00025
                       P00000
P00030
                        P00032
                        P00040
                                                                 P00023
```

```
COMPASS-32
                         (2.1)
                                                              CVTBCDB
                                                                                                                                                                      11/21/66 PAGE
    ENTRY-POINT SYMBOLS
CVTBCDB 00000
    LENGTH OF SUBPROGRAM
LENGTH OF COMMON
LENGTH OF DATA
                                                      00017
00000
00000
COMPASS-32 (2.1)
                                                               CVTBCDB
                                                                                                                                                                      11/21/66 PAGE
                                                                                       THIS SUBPROGRAM CONVERTS A POSITIVE FOUR CHARACTER BCD NUMBER TO A 24 BIT BINARY NUMBER.
                                                                                       CALL (P) =RTJ CVTBCCB
(P+U)=RETURN
(A) =THE FOUR CHARACTER RCD NUMBER
                                                                                       OUTPUT (A)=24 BIT BINARY NUMBER
                                                                                       ENTRY
                                                                                                         CVTBCDB
             00000 01077777 01 0 77777 0 CyTBCDH
00001 40000015 40 0 P00015 0
00002 47200013 47 0 P00013 2
00003 14200000 14 0 00000 2
00004 22000064 22 0 P00015 0
                                                                                       STA
STI
ENI
                                                                                                          ##
TEMP
                                                                                                                                              SAVE INPUT PAR.
SAVE (82)
                                                                                                          B2SAVE . 2
                                                                                                          0.2
TEMP
                                                                                                                                              LOAD A WITH MOST SIGNIFICANT CHARACTER.
MULTIPLY (A) BY AN OCTAL 12
                                                                                       LACH
              00005 50000016 50 0 P00016 0 L00P
00006 15200001 15 0 00001 2
00007 23400064 23 1 P00015 0
                                                                                                          =012
                                                                                                          1.2
TEMP.2
                                                                                       LOCH
                                                                                                                                              LOAD Q WITH NEXT SIGNIFICANT CHARACTER.
             00010 53040000 53 0 40000 0
00011 04200003 04 0 00003 2
00012 01000005 01 0 P00005 0
00013 14277777 14 0 77777 2
00014 01400000 01 1 P00000 0
                                                                                        AQA
                                                                                                        3,2
LOOP
**,2
CVTBCDB
1
                                                                                      ISE
UJP
ENI
UJP•I
8SS
END
                                                                                                                                              IS B2 EQUAL TO 3 YES EXIT NO JUMP TO LOOP RESTORE 82
                                                                     BESAVE
                                                                       TEMP
    LITERALS
                                  00000012
                                                                                     NUMBER OF LINES WITH DIAGNOSTICS
```

CUMPASS-32	(2.1)	CVTBCUB				11/21/66	PAGE	1	
B2SAVE CVTBCDB LUUP TEMP LITERAL	P00005 P00015	00000012	P00002 P00014 P00012 P00001 P00005	P00004	P00007				
		*							
COMPASS=32	(2•1)	CVTBBCD				11/21/66	PAGE	1	
ENTRY-POIN CVTBBC	T SYMBOLS D 00000								
LENGTH OF LENGTH OF LENGTH OF	SUBPROGRAM COMMON	00033 00000 00000							
CENGIN OF	OATA	•							

•

```
COMPASS-32
                                                                         (2.1)
                                                                                                                                                                             CYTBBCD
                                                                                                                                                                                                                                                 11/21/66 PAGE THIS SUBPROGRAM CONVERTS A 24 BIT BINARY NUMBER TO A EIGHT CHARACTER BCD NUMBER WITH BLANKS INSERTED TO THE LEFT OF THOST SIGNIFICANT DIGIT.
                                                                                                                                                                                                                                                 CALL (P) ERT.I
                                                                                                                                                                                                                                                                                                                                            CVTBACD
                                                                                                                                                                                                                                                                           (P+1) =RETURN
(A) = 24 BIT BINARY NUMBER
                                                                                                                                                                                                                                                  OUTPUT
                                                                                                                                                                                                                                                                                                     (AQ) = EIGHT CHARACTER BCD NUMBER
                                00000 01077777 01 0 77777 0 CVTBBCD 00001 47100025 47 0 P00025 1 0 00002 1000002 2 10000027 2 10 P00027 0 00003 41000030 41 0 P00031 0 00004 41000031 41 0 P00031 0 00005 43000113 43 0 P00012 2 00007 14100040 14 0 00040 1 00010 47100022 47 0 P00022 1 00011 16477777 16 1 77777 0 0012 14100007 14 0 00007 1 BYPASS LOOP 00015 43400140 43 1 P00032 0 00015 43400140 43 1 P00032 0 00015 43400140 43 1 P00032 0 00016 0250020 20 1 P00022 1 00017 0100022 01 0 P00022 0 00021 00016 0250020 20 1 P00022 0 00021 01000013 0 00021 1000013 0 00021 1477070 10 00025 1477077 14 0 07777 1 0 00025 14770777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 14777777 14 0 77777 1 0 15540000 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 14000000 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 14000000 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 1400000 0 0 00025 14000000 0 00025 1400000 0 0 00025 14000000 0 00025 1400000 0 00025 1400
                                                                                                                                                                                                                                                                                                   CVTBBCD
                                                                                                                                                                                                                                                  ENTRY
                                                                                                                                                                                                                                          STI
                                                                                                                                                                                                                                                                                                      BISAVE.1
                                                                                                                                                                                                                                                                                                                                                                                                         SAVE (81)
                                                                                                                                                                                                                                                                                                   BLANKS
HCDANS
BCDANS+1
SETSIGN+3
HYPASS
                                                                                                                                                                                                                                                  LDa
                                                                                                                                                                                                                                                 STQ
STQ
SQCH
AZJ+GE
                                                                                                                                                                                                                                                                                                                                                                                                          SET OUTPUT AREA TO BLANKS
                                                                                                                                                                                                                                                                                                                                                                                                          SET ASSUMED SIGN TO POSITIVE IS INPUT NUMBER POSITIVE YES JUMP NO SET SIGN
                                                                                                                                                                                                                                                ENI
STI
XOA+S
                                                                                                                                                                                                                                                                                                     408.1
SETSIGN.1
                                                                                                                                                                                                                                                                                                                                                                                                         COMPLEMENT THE 24 BIT NUMBER
SET WAX TIMES THROUGH LOOP
SHIFT FOR 48 BIT DIVIDEND
DIVIDE BY OCTAL 12
STORE NEXT SIGNIFICANT DIGIT
                                                                                                                                                                                                                                                                                                       -0
                                                                                                                                                                                                                                                ENI
SHAQ
DVA
SQCH
                                                                                                                                                                                                                                                                                                   #012
9CDANS+1
#+2+1
SETSIGN
                                                                                                                                                                                                                                                  IJD
UJP
                                                                                                                                                                                                                                                 ASE . S
                                                                                                                                                                                                                                                                                                                                                                                                         IS THE QUOTIENT ZERO-YES SKIP
                                                                                                                                                                                                                                                                                                     LOOP
                                                                                                                                                                                                                                             UJP
ENG
SQCH
LUAG
ENI
UJP•I
BCD
BSS
                                                                                                                                                                                                                                                 UJP
                                                                                                                                                                                                                                                                                                  60B
BCDANS+1
BCDANS
                                                                                                                                                                                                                                                                                                                                                                                                         PLACE SIGN JUST TO THE LEFT OF MOST SIGNIFICANT DIGIT.
                                                                                                                                                                                                                                                                                                  **,1
CVTBBCD
                                                                                                                                                                                                                                                                                                                                                                                                         RESTORE (81)
                                    00027
                                                                                                                60606060
                                                                                                                                                                                                 BLANKS
                                    00030
                                                                                                                                                                                                 BCDANS
         LITERALS
                                                                                           00000012
                                                                                                                                                                                                                                           NUMBER OF LINES WITH DIAGNOSTICS
```

COMPASS-32 (2.1) CYTHRCD 11/21/66 PAGE BISAVE P00025 P00001 P00003 BCDANS P00004 P00015 P00023 P00024 P00002 BLANKS P00027 BYPASS CVTBBCD LOOP SETSIGN P00012 P00000 P00013 P00006 P00026 P00021 P00005 P00014 P00032 P00010 P00017 00000012

SEQUENCE,002 JOB + + + + COMPASS + L + X • 11/21/66 PAGE 1 COMPASS=32 (2.1) IDC EXTERNAL SYMBOLS ENTRY-POINT SYMBOLS
00000 LENGTH OF SUBPROGRAM LENGTH OF COMMON LENGTH OF DATA 00032 00050 00000

```
COMPASS-32
                                                                           (2.1)
                                                                                                                                                                             IDC
                                                                                                                                                                                                                                                                                                                                                                                                                                                               11/21/66 PAGE
                                                                                                                                                                                                                                            ENTRY
EXT
UJP
RTJ
                                     00000 01077777 01 0 77777 0 IDC
00001 00777777 01 0 77777 0 IDC
00002 01000074 01 0 00074 0
00003 01000001 01 0 P00001 0
00004 00000000 00 0 000000 0
00006 00700001 01 1 00000 3
00001 1770001 17 1 00010 3
00012 04700000 04 1 00000 3
00012 04700000 07 0 000000 0
00015 0460004 04 1 00000 3
00015 0460004 04 1 00000 3
00016 0100001 01 0 P00001 0
00017 0070006 00 1 00000 0
00015 0460004 04 1 00000 3
00018 0100001 01 0 P00001 0
00019 000000 00 000000 0
00015 0460004 04 1 00001 3
00016 0100001 01 0 P00001 0
00017 0070006 00 1 00001 0
00017 0070006 00 1 00001 0
00021 01000017 01 00001 0
00022 00000002 00 00002 0
00024 00700017 00 1 000017 0
00025 13000002 00 00002 0
00024 00700017 00 1 00001 0
00025 13000073 13 0 00073 0
00026 03200024 03 0 P00024 2
00027 77700000 77 1 00000 3
00030 01000001 01 P00001 0
00031 01400000 01 1 P00001 0
                                                                                                                                                                                                                                                                                              10C
C10
                                                                                                                                                                                                                                             01
UJP
                                                                                                                                                                                                                                                                                                60
#=2
                                                                                                                                                                                                                                                                                                INBUFF
                                                                                                                                                                                                                                                                                               40
CIO
60
                                                                                                                                                                                                                                            RTJ
13
AZJ, GE
ANG
UJP
LACH
ASE
UJP
RTJ
02
                                                                                                                                                                                                                                                                                               108
                                                                                                                                                                                                                                                                                               EOF
                                                                                                                                                                                                                                                                                            EOF
INBUFF
41B
READ
CIO
59
                                                                                                                                                                                                                                             UJP
                                                                                                                                                                                                                                                                                               INBUFF+2
                                                                                                                                                                                                                                                                                              CIO
S
                                                                                                                                                                                                                                             RTJ
                                                                                                                                                                                                                                            13
AZJ.GE
SLS
UJP
UJP.I
COMMON
BSS
                                                                                                                                                                                                                                                                                             READ
IDC
                                         00000
                                                                                                                                                                                                 INBUFF
                                                                                                                                                                                                                                                                                              40
                                                                                                                                                                                                                                            END
                                                                                                                                                                                                                                                                                              IDC
                                                                                                                                                                                                                                        NUMBER OF LINES WITH DIAGNOSTICS
10A0+56
5NAP+(IUC)15+C0+C47+0+0P
R/N+10
```

SUBP 15547	IODRAIN	15611	IOPACK	16245	SNAPSHOT	17705	IDC				
15621 00745 02402	IODRAIN WRITELUN SEL HDCKSUM	16163 02130 02305	RDCKF1	16307 02170 02015	BCDBOXS	16266 00060 02015	FDPBOXS	16200 16245 02241 00107	WRITEACC SNAPSHOT RHT CIO	17705 02201	WRITEPUN IDC AET Start2
COMM	LOADER	02261	ACCOUNTS	02303	MEMORY	02015	ABNORMAL				
03206 DATA											
NONE											
NONE	•										
			•								

A-50

```
SEQUENCE.003

JOH, JC:482:15

OCC:416

OCC:416

OCC:416(DC):27:01000000A

OCC:4.20000074 (TDC):44000003A:44000010<,00777777

OCC:4000073:01000003X:0000015X:0000001

OCC:40000777777-13000073:03700010X:77700000

OCC:4000030(TDC):77606060

RUN;10
                                                                                                                                                                                                                                                                                                                                              lacktriangle
       SUBP
17635 IDC
        ENTR
          ENTR
17635 IDC
02201 AET
02453 START2
                                                              00745 SEL
02402 ROCKSUM
02737 LOADEH
                                                                                                                  02130 UST
02305 HDCKF)
0226) ACCOUNTS
                                                                                                                                                                        02170 CST
02015 GCDROXS
02303 MEMORY
                                                                                                                                                                                                                            00060 CTT
02015 FDPROXS
02015 ABNORMAL
                                                                                                                                                                                                                                                                                 02241 RHT
       COMM
NONE
       DATA
NONE
        EXTA
           17617
```

•

```
•
                  LOC 00043 A 00002015 9 40004003 RJ 00014 R2 17635 R3 00000 IC 0116 IA 17645 TC 00 TA 02015 IMR 0003
                   REGISTER FILE
                                                                                                                             00770077
00770077
26571102
23575770
00077776
                                                                                                                                                                        00770077
00770077
00770077
00007725
00007725
00770077
00003320
                                                                                                                                                                                                                                                       10770077
                                                                                                                                                                                                                                                                                             00770077
00770077
40004003
                                                  00077460 20413534
04077574 26013534
60445400 0045254
71045400 72045404
                              00
10
20
30
                                                                                                                                                                                                                                                        10002015
                                                                                                                                                                                                                                                                                                                                       00000014
                                                                                                                                                                                                                                                       10000000 00917302
10000505 00000000
10003271 0000417
                                                                                                                                                                                                                                                                                               00000000
                                                   71045400
00006243
01007331
                                                  | 1.11 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 1.21 | 
                                                                                                                                                                                                                                                                                                                                      0000000
                                                                                                                                                                        0000000
60404060
00000050
                                                                                                                                                                                                                 00000057
00000005
00000144
                                50
                                                                                                                                                                                                                                                        10003271 00006171
10000013 60606060
                                                                                                                                                                                                                                                                                                                                        0000013
                                                                                                                                                                                                                                                                                                                                        00000000
                    ME HORY
                   GAP
                                                    <u> 60606060 40606060 60606060 40404060 40606060 40606040 00702015 40702015</u>
                    03-00
                   6AP
17510
17620
                                                                                                                                                                                                                                                                                                                                     20017561
n0777777
n100n074
                                                                                                                                                                                                                                                       00702015 00702015
00017634 00000001
01002037 00700107
                                                   00702015 00702015 00702015
44017622 44017627 00777777
13000073 03217627 77700000
                                                                                                                                                                                                                 00702015
01017622
77506060
                                                                                                                                                                          00702015
                     17630
                                                                                                                                                                         91017665
                                                                                                                                                                                                                                                           3217643 17700010
                                                                                                                                                                                                                                                                                                                                      n4700000
                                                                                                                                                                       00700107
                                                                                                                                                                                                                 13000074
                    17540
                                                   01017636
                                                                                            10017667 00000050
                                                                                                                                                                         01017636
03217661
11022100
                                                                                                                                                                                                                  00700107
01017617
11021004
                                                                                                                                                                                                                                                      02000073
01017636
0000000
                                                                                                                                                                                                                                                                                                01017654
01417635
00000000
                                                   01017666 22077334 04600041
00000002 00700107 13000073
20102001 11002001 44002020
                                                                                                                                                                                                                                                                                                                                       00017671
                     17550
17660
                                                                                                                                                                                                                                                                                                                                        00000000
                     17670
                     GAP
                                                    noonnon noonnoo vanoonn nonnoon nonnoon noonnon 000noon n0702015
                     17730
                                                                                                                                                                               #FNn#
                    SEG ERR
                    SEQUENCE + 004
```

ADDITIONAL EXERCISES (Assignment Sheets)

3200 Computer Characteristics	B1 - B2
Load Instructions	В3
Store Instructions	В4
Arithmetic, Fixed Point	B5 - B6
Register Operations Without Storage Reference	B7 - B8
Stop and Jump Instructions	B9 - B11
Inter-Register Transfer	B12 - B13
Search and Move Operations	B14 - B17
Storage Tests	B18 - B19
BCD Operations	B20 - B22

3200 COMPUTER CHARACTERISTICS

For each of the following word addresses and character positions, provide the equivalent character address and the *torage module in which it is contained.

Wor	d Address	Character Position	Character Address	Storage Module
a)	00027	# 0		
b)	06313	#1		
c)	15346	# 2		
d)	20476	#3		

2. For each of the following character addresses provide the equivalent word address, character position and storage module.

<u>Cha</u>	racter Address	Word Address	Character Position	Storage Module
a)	300630			
b)	152063			
c)	325076			

3. If Character Address 340556 were specified, what character address would actually be referenced in an 8K system?

d) 150762

- 4. If Character Address 160560 were specified, what character address would actually be referenced in a 16K system?
- 5. The 3200 system can consist of a maximum of ______ 12-bit data channels.

6.	A 24-bit data channel may be used in place of	12-bit data
	channel(s). It will be programmed as channel number	•
7.	A 3200 data channel may control a maximum ofequipment controllers.	_ peripheral
8.	Give a brief description of the four (4) types of Proces	sors.
9.	What memory locations are always permanently protected as	od why?
	and memory received are armayo permanentry proceeded an	id wily.
10.	What address or block of addresses are protected by the S	Stanos
10.	Protect Switches below?	corage
	111 111 110 NNN NNN =	_
11.	Describe what happens when an instruction attempts to wri	te into a
	Protected address?	
12.	Give the function of each location within the register fi	11e.

LOAD INSTRUCTIONS

What are the contents of the indicated registers after the execution of each instruction? Assume initial condition above for each problem.

1.	LDA	TEMP	(A)	=
2.	LDQ	TEMP+1	(Q)	÷
3.	LACH	TEMP,1	(A)	=
4.	LDA,I	TEMP,2	(A)	=
5.	LDL	TEMP,2	(A)	=
6.	LCAQ	TEMP+1	(A) (Q)	=
7.	20113315		(A)	=
8.	22055462		(A)	=
9.	54113316		(B ¹)	=
10.	LDI,I	TEMP+4,1	(B ¹)	=
11.	LQCH	TEMP+7	(Q)	=
12.	LACH	TEMP+2,1	(A)	=

STORE INSTRUCTIONS

GIVEN: (A) = 24130120
$$(B^1) = -1$$

(Q) = 13000003 $(B^2) = 10$
(B³) = 1

TEMP = Memory Location 33444

TEMP1 = Memory Location 33446

TEMP	01 33	34	43
	77 53	34	44
TEMP1	66 73	34	45
	65 03	34	46
	44 55	66	77

What are the contents of the indicated registers or memory locations after the execution of each instruction? (Assume original settings at beginning of each instruction set.)

1.	STA	TEMP+4	(A) =
2.	STQ,I	TEMP	(TEMP) =
3.	SACH	TEMP,2	(TEMP+2) =
4.	SWA	TEMP+3	(TEMP+3) =
5.	STAQ,I	TEMP	Where are A & Q stored =
6.	SCHA	TEMP+1	(TEMP+1) =
7.	STI	TEMP+4	(TEMP+4) =
8.	sqcн	TEMP1,1	(Modified location) =
9.	STI	TEMP1,3	(TEMP1) =
10.	SWA,I	TEMP1+1	(TEMP1) =

ARITHMETIC, FIXED POINT

The following problem set is to familiarize the student with the arithmetic instructions.

1. MC, set P to "GO" and start.

GO	ENA,S	604B
	ENQ	77777B
	MUA	INTEGER
	HLT	GO
INTEGER	HLT	4
	$(A)_{f} =$	
	$(Q)_{f} =$	

2. MC, set P to "GO" and start.

GO ENA,S 0
ENQ,S 600B
DVA DIVISOR
HLT GO
OCT -7

$$(A)_{f} = (Q)_{f} =$$

3. MC, set P to "GO" and start.

4. MC, set P to "GO" and start.

GO ENI 7,1
ENA,S 6
INA,S 1
SBA MINUS
HLT
MINUS OCT 10
$$(A)_{f} =$$

5. What are the contents of A register when program halts?

ENI -6,1
LDA TEMP
SHA 5,1
HLT
TEMP OCT 40123400

(A) =

REGISTER OPERATIONS WITHOUT STORAGE REFERENCE

For each of the following short routines, indicate the final contents of designated register. Assume that a M.C. was performed prior to starting each program.

1.	M.L.		CONT	ENTS
	00000 00001 00002 00003 00004		ENI INI XOI ANI HLT	40000B,1 100B,1 7677B,1 7777B,1
		$(B^1)_f =$		
2.	00000 00001 00002 00003 00004		ENA,S XOA,S INA,S ANA,S HLT	40000B 40000B 50000B 40000B
		$(A)_{f} =$		
3.	00000 00001 00002 00003 00004		ENQ XOQ INQ ANQ HLT	60000B 70000B 77777B 77777B
		$(Q)_{f} =$		
4.	00000 00001 00002 00003 00004 00005 00006		ECHA ENQ SHA SHAQ SHQ SHAQ HLT	2003B 0 -2 24 1 35430B
		$(A)_f =$		
		$(Q)_{f} =$		

GIVEN: (A) =
$$40372156$$
 (B¹) = 77777 (Q) = 35642761 (B²) = 41745 (B³) = 72156

Regarding each of the following instructions as separate problems, indicate which will RNI at P+1 by placing a check $(\slashed{\nu})$ in the space provided.

1.	ISE	0,1
2.	ISE	41745B,3
3.	ISE	43745B,2
4.	ASE,S	27614B
5.	ASE	72156B
6.	QSE	47321B
7.	QSE,S	34763В
8.	ISE	72156в,3
9.	ISE	0,0
10.	ASE,S	72156В
11.	ISG	77777В,1
12.	1SG	27317B,2
13.	ISG	77345B,3
14.	ASG,S	73452В
15.	Qsg,s	04210В
16.	ASG	72156B
17.	QSG	35016в
18.	ISG	72156в,3
19.	ISG	17774B,0

20. ____ISG

37432B,2

STOP AND JUMP INSTRUCTIONS

GIVEN: (A) = 40372156 (B¹) = 77777(Q) = 35642761 (B²) = 41745(B³) = 72156

Regarding each of the following instructions as separate problems, indicate which will RNI at P + 1 by placing a check (\checkmark) in the space provided.

1.	ISI	0,1
2.	ISI	30632B,2
3.	ISI	72156B,3
4.	ISD	0,0
5.	ISD	77777В,1
6.	ISD	47445B,2
7.	ISD	05621B,3
8.	ISD	41745B,2
9.	ISI	37621B,1
10.	IJI	0,0
11.	IJD	62156B,3
12.	IJI	44444B,3
13.	IJI	77777B,3
14.	IJD	67565B,C
15.	AZJ,EQ	73125B
16.	AZJ,NE	33127B
17.	AZJ,GE	27215B
18.	AZJ,LT	77777В
19.	AQJ,EQ	41425B

20. ____AQJ,GE 42761B

1. MC, set P to 06000 and start.

<u>M.L.</u>	CONT	ENTS
06000	LDA	6004B
06000	INA,S	-1
06002	AZJ,NE	6005B
06003	HLT	
06004	00	0
06005	INA,S	2
06006	UJP	6001B
	$(A)_{c} =$	
	//t	

2. MC, set P to 05120 and start.

<u>M.L.</u>		CONT	ENTS	
05120 05121 05122 05123 05124 05125 05126 05127		ENI INA,S IJD INQ,S ISI UJP ANA HLT	77B,1 10000B 5121B,1 10000B 77B,1 5123B	
	$(A)_{f}$ $(Q)_{f}$ $(B^{1})_{f}$	=		

3. MC, set P to 07000 and start.

M.L.		CON	ITENTS
07000 07001 07002 07003 07004 07005		IJI UJP UJP IJI UJP UJP	7007B,1 7006B,3 7004B 7002B,2 7005B,1
07006 07007		RTJ HLT	7002B 7002B
	(P) _f	=	
	(07002)	=	

4. What does this program do?

	ENI	4,1
AGAIN	LDA	TEMP,1
	RTJ	ROUTINE
	UJP	*+4
	*RAD	TALLY
	IJD	AGAIN,1
	HLT	**
	RAD	COUNT
	UJP	*- 3
ROUTINE	UJP	**, 2
	ENI	0,2
	ASG	100B
	INI	1,2
	ENA	1
	UJP,I	ROUTINE
TEMP	OCT	100
	OCT	21
	OCT	77
	OCT	101
	OCT	10
TALLY	OCT	0
COUNT	OCT	0

*The RAD instruction must have been discussed before the above problem can be done.

5. MC, set P to "C.O" and start. The selective stop switch and jump switches l and θ are set.

M.L.	<u>cc</u>	NTENTS
C.O	UJP	C.6
C.1	HLT	C.O
C.2	SJ1	C.1
	SLS	
C.4	SJ3	C.10
	SJ6	C.2
C.6	SJ2	C.10
	UJP	C.4
C.10	SLS	
	$(P)_{f} =$,

If the machine were restarted from where it stopped, what memory location would it go to?

INTER-REGISTER TRANSFER

1. What are the contents of the A register and Q register when program is executed?

M.L.				
00000 00001 00002 00003 00004 00005 00006		LDQ ENA SWA LDA AQA STA ENQ HLT		TEMP GET *+1 ** *+2 -6 **
00007 00010 00011 00012	GET TEMP	HLT ENI OCT		** 0,0 02677771
		(A) (Q)	=	

2. MC, set P to GO and start.

GO ENA 10
TAI 3
ENQ 10
INI -1,3
HLT

$$(A)_{f} = (Q)_{f} = (B^{3})_{f} =$$

Write the octal coding that will be generated by the following COMPASS coding.

	COMPASS			OCTAL
1)	AQA		=	
2)	INA	3	=	
3)	TIA	2	The same of the sa	
4)	TQM	22B	-	
5)	AIA	1	===	
6)	TIM	20B,2	=	
7)	TAM	77B	=	
8)	TMI	60B,3	==	
9)	TMA	27B	-	
10)	TMQ	55B	=	
11)	TAI	1	- sha	

4. MC, set P to BEGIN and start.

5. MC, set P to BEGIN and start.

BEGIN	LDAQ	NUMB
	MUAQ	INTEGER
	DVAQ	DIVISOR
	STAQ	ANSWER
	ELQ	
	EUA	
	STAQ	ANSWER+2
	HLT	
NUMB	OCT	-0,-100
INTEGER	OCT	0,4
DIVISOR	OCT	0,2
ANSWER	OCT	0,0,0,0
	(ANSWER)	=
	(ANSWER+1)	=
	(ANSWER+2)	=
	(ANSWER+3)	=

SEARCH AND MOVE OPERATIONS

1.

START	IDENT ENTRY EXT •	MAIN START DELBLANK
	• ENA RTJ •	DATACARD DELBLANK
	•	
DATACARD	BSS END	20 START
BELBLANK	IDENT ENTRY UJP	DELETE DELBLANK **
	STI ENI SHA	SAVEB2,2 0,2 2
	SCHA SCHA INA,S	FCA SRC+1 80
SRC	SCHA SRCN UJP	SRC 60B,**,** *-2
	PAUS UJP TMA	4000B *-1 30B
	LPA SHAQ TMA	MASK 24 20B
	LPA AQJ,EQ SCHA	MASK EXIT *+3
INCRE	INA,S SCHA LACH	1 SCR+1 **
FCA	SACH INI	. **, 2 1,2
EXIT	UJP LDA LPA	SRC *-3 MASK
SAVEB2	AIA ENI UJP,I	2 **,2 DELBLANK
MASK	OCT END FINIS	0037777

Assume program MAIN had previously read in one card image into the area labeled DATACARD before it transfers control to a commonly used subprogram called DELETE.

- A. Why is Index Register No. 2 saved upon entrance to the DELETE subroutine?
- B. Why does the program MAIN execute an ENA instruction before it does a return jump to the DELETE subroutine?
- C. What is the significance of the double asterisk (**) in the coding of the SRCN instruction in the DELETE subroutine?
- D. What is the function of the unconditional jump instruction which follows the SRCN instruction in the DELETE subroutine?
- E. What two conditions will cause the PAUS instruction within the DELETE ROUTINE to do a SKIP EXIT (P+2)?

- F. Why at location INCRE is the character address in A updated by 1?
- G. What does the A register contain when control is transferred back to program MAIN?

2.

	ENTRY	PROG1
PROG1	ENI	0,1
	ENI	0,2
MOVE	LACH	FILE1,1
	SACH	FILE2,2
	INI	1,2
	ISI	7,1
	UJP	MOVE
	HLT	
	END	PROG1
	ENTRY	PROG2
PROG2	MOVE	10B, FILE1, FILE2
	UJP	+-2
	PAUS	4000B
	UJP	*-1
	HLT	
	END	PROG2

Given the above routines, which one will accomplish the move faster?

Assume both routines do a character by character move.

Does the MOVE instruction buy the programmer much time if he has to wait until the MOVE is completed?

3. Write a short program which will search a character block (character addresses CARD to CARD+80) for the first COMMA(,). Loop until the search is complete and determine if a COMMA(,) was found; if one were found, load the ADDRESS into the A register; if not, set A=0.

STORAGE TESTS

1.

	ENTRY	SEARCH
SEARCH	ENI	0,2
	ENI	7,1
	ENA	200
	ENQ	100
	CPR	LIST,1
	UJP	*+3
	UJP	*+2
	RTJ	FIND
	IJD	*-4,1
	HLT	.,-
FIND	UJP	**
	ENA	LIST
	AIA	1
	STA	ADDRESS, 2
	INI	1,2
	UJP,I	FIND
LIST	DEC	1,150,20,300,5,200,100,77
ADDRESS	OCT	0,0,0,0,0,0,0
	END	. , , , , , , , , , , , , , , , , , , ,

What does the above program do?

When the program comes to a HALT, what do the following locations contain?

ADDRESS =

ADDRESS+1 =

ADDRESS+2 =

ADDRESS+3 =

- 2. The number in the A register after executing a SSH instruction is?
 - a) Zero
 - b) The original number from memory, unshifted.
 - c) The original number from memory, shifted.
 - d) The same number that was in A.

3.

	Dimbir	COLV
	ENTRY	SCAN
SCAN	ENI	0,3
	ENI	0,2
	ENI	3,1
	LDQ	MASK
CONTINUE	LDA	DATA
	MEQ	LIST,1
	UJP	CHECK
	ENA	LIST
	AIA	1
	SHA	2
CHARADDR	AIA	2
	STA	LIST1,3
	INI	1,3
	UJP	CONTINUE
CHECK	SSH	CONTROL
•	HLT	
	SHQ	18
	SHA	18
	STAQ	MASK
	INI	1,2
	UJP	SCAN+2
CONTROL	OCT	73567356
MASK	OCT	77000000
DATA	OCT	45000000
LIST	BSS	3
LIST1	OCT	0,0,0,0,0,0,0,0,0,0,0
	END	

What does the above program do?

4. Write a program which will search a table called INFO, looking for the value 62_8 in bit positions 11 - 06. Search every other location in INFO, which is a total of 16_{10} locations long, starting with the last location within the INFO table. The program must keep track of all addresses, where a find had occurred.

BCD OPERATIONS

1. The decimal quantity +32,768,987 is contained in a field beginning at character address 010000. Indicate the octal contents of the appropriate memory locations.

MEMORY LOCATIONS

CONTENTS

2. After executing a SET 12 and a LDE AA+2 instruction, indicate the sign and contents of the E register. AA - 65136

		CONTENTS
(5)	AA	11071002 02050711
$(E)_{f} =$		06010210 11117102

3. After executing a SET 10 and a ADE BB+2 instruction, indicate the final sign and contents of the E register. BB=13417

CONTENTS

(E)_i = -0,000,987,654,321

BB 04060701
10010010
11100000

4. After executing a SET 4 and a SBE CC+2 instruction, indicate the final sign and contents of the E register. CC=40000

CONTENTS

(E)_i = +0,000,000,000,989

(C)
01141011
02650411

5. After executing a SET 13 and a ADE DD+1,3 instruction, indicate the final sign and contents of the E register. (B3) = 77765 DD = 04002

CONTENTS

$(E)_{i} = +1,000,000,000,000.$		01100611
- -		11070302
$(E)_{f} =$		10100301
	DD	00111151

6. After executing a SET 9 and a STE 10B instruction, indicate the final sign and contents of the E register as well as the contents of the storage locations affected.


$$(E)_{i} = -9,568,765,867,898.$$
 M.L. CONTENTS
 $(E)_{f} =$

7. Fill in the six (6) locations starting with "CHARS" with their octal contents, after the following has been executed. Place X's where contents not known.

$$(E_{D}) = +0000045468799$$

	EZJ,EQ EZJ,LT SET SFE STE	OUT OUT 10 2 ANSWER
OUT	NOP HLT	
CHARS ANSWER	BCD,C BCD,C	12,TOTAL EQUAL 10,

CHARS



$$(E)_{f} =$$

$$(D) =$$

8. Fill in the octal contents of the four (4) locations starting at "DATA", after the following program has been executed. Place X's where the contents are not known.

 $E_{D} = -0405060708090$

	SET	1
	ENI	0,2
LOOP	EZJ,EQ	DONE
	SFE	-1
	STE	DATA,2
	INI	1,2
	UJP	LOOP
DONE	HLT	
DATA	BCD,C	12,

DATA

(E)_f =

ANSWER SHEETS

3200 Computer Characteristics - Answers	C1 - C3
Load Instructions - Answers	C4
Store Instructions - Answers	C5
Arithmetic, Fixed Point - Answers	C6
Register Operations Without Storage Reference - Answers	C7
Stop and Jump Instructions - Answers	C8
Inter-Register Transfer - Answers	С9
Search and Move Operations - Answers	C10 - C11
Storage Tests - Answers	C12
BCD Operations - Answers	C13

3200 COMPUTER CHARACTERISTICS - ANSWERS

1.	Character Address	Storage Module
	a) 000134 ₈	0
	b) 031455 ₈	0
	c) 065632 ₈	0
	d) 102373 ₈	1

2.	Word Address	Character Position	Storage Module
	a) 60146 ₈	0	3
	b) 32414 ₈	3	1
	c) 65217 ₈	2	3
	d) 32174 ₈	2	1

3.	Character Address	Word Address	Character Position
	0405568	101338	2

4.	Character Address	Word Address	Character Position
	160560	34134 ₈	0

- 5.
- 6. a) 2
 - b) #2
- 7. 8
- 8. a) 3204 (Basic Processor) contains the logic to perform 24-bit fixed point arithmetic, 48-bit fixed point addition and subtraction,
 Boolean, character and word handling and decision making operations.
 - b) 3205 (Scientific Processor) contains the capability of the 3204, plus floating point and 48-bit precision fixed point multiplication and division.

- c) 3210 (Data Processor) contains the capability of the 3204, plus the ability to handle BCD characters.
- d) 3215 (General Processor) contains the capability of the 3204, 3205 and 3210.

9.	Memory Size	Locations Protected
	4K	07640 - 07677
	8K	17640 - 17677
	16K	37640 - 37677
	32K	77640 - 77677

The auto-load program resides here, and consists of the necessary instructions to bring in a program from magnetic tape unit. If these locations were not protected, this program could be destroyed and no more auto-load capability, which is a necessary item for the 3200 Scope operating system.

- 10. LOCATIONS 77600₈ thru 77677₈
- 11. No writing takes place and the write instruction acts like a NOP instruction. The computer does not HALT and does not generate an interrupt. The illegal write can be only sensed by the INS instruction.

12.	Register Numbers	Reserved for:
	00 - 07	Modified I/O instruction word containing the current character or word address (channel 0-7 control)
	10 - 17	Modified I/O instruction word containing the last character or word address \pm 1, depending on the instruction (channel 0-7 control)
	20	Search instruction word containing the current character address (search control)
	21	Move instruction word containing the source address (move control)

12. (cont.)

Register Numbers	Reserved for:
22	Real-time clock, current time
23	Current character address (typewriter control)
24 - 27	Temporary storage
30	Instruction word containing the last character address ± 1 (search control)
31	Instruction word containing the destination address (move control)
32	Real-time clock, interrupt mask
33	Last character address $+ 1$ (typewriter control)
34 - 77	Temporary storage

C-4

LOAD INSTRUCTIONS - ANSWERS

1.	27313317

- 2. 40513315
- 3. 00000033
- 4. 23142615
- 5. 00003314
- 3726446257364463
- 7. 23142615
- 8. 00000033
- 9. 13314
- 10. 42615
- 11. 00000015
- 12. 00000040

STORE INSTRUCTIONS - ANSWERS

- 1. 24130120
- 2. 01333443
- 3. 20733445
- 4. 65030120
- 5. (TEMP) = A (TEMP+1) = Q
- 6. 77530120
- 7. 44500000
- 8. (TEMP+1) = 77533403
- 9. 66700001
- 10. 66730120

ARITHMETIC, FIXED POINT - ANSWERS

- 1. $(A)_{f} = 00003020$
 - (Q) $_{\mathbf{f}}$ = 000000000 (can't be a negative zero)
- 2. $(A)_f = 77777711 (-66_8)$
 - $(Q)_{f} = 00000006$ Same Sign as Dividend
- 3. $(A)_f = 00075767$
- 4. $(A)_f = 77777776$
- 5. $(A)_{f} = 60051600$

REGISTER OPERATIONS WITHOUT STORAGE REFERENCE - ANSWERS

1.
$$(B^1)_f = 07777$$

$$2. (A)_{f} = 77740000$$

3.
$$(Q)_{f} = 00007777$$

$$4. (A)_{f} = 00001000$$

$$(Q)_{f} = 00000000$$

8.

9.

10. 🗸

11.

12.

13.

14.

15.

16.

17.

18.

19.

20.

STOP AND JUMP INSTRUCTIONS - ANSWERS

1. V

2. V

3.

4.

5.

5. V

7. V

8.

9. V

10.

11.

12.

13.

14.

15. V

16.

17. V

18.

19.

20. V

1. $(A)_{f} = 00000000$

 $2. (A)_{f} = 00000000$

 $(Q)_{f} = 01000000$

 $(B^1)_f = 00000$

3. $(P)_{f} = 07007$

(07002) = UJP 07007B

4. Looks at all values of TEMP TEMP+4, for values greater or equal to 100 octal. A count of all values equal to or greater than 100 octal are kept in COUNT. A count of all values less than a 100 octal are kept in TALLY.

5. $(P)_{f} = C.1_{C.0}$

INTER-REGISTER TRANSFERS - ANSWERS

1.
$$(A) = 16600000$$

$$(Q) = 00077771$$

$$2.$$
 (A) = 00000012

$$(Q) = 00000012$$

$$(B^3)_f = 00011$$

- 2) 53740000
- 3) 53200000
- 4) 53410022
- 5) 53140000
- 6) 53630020
- 7) 53420077
- 8) 53330060
- 9) 53020027
- 10) 53010055
- 11) 53500000

$$4. (A)_{f} = 00000000$$

$$(Q)_{f} = 77777777$$

$$(B^1)_f = 77676$$

$$(V24) = 77777777$$

$$(V25) = 00100177$$

$$(V26) = 00177776$$

$$(V27) = 00077577$$

5. 77777777

77777577

00000000

00000000

SEARCH AND MOVE OPERATIONS - ANSWERS

- 1. A) All subroutines which are used by other programs, should save any register that is uses in performing its task. Index Register #2 may contain valuable data to program MAIN, at the time it transfers control to the DELETE subroutine; so if (B²) was not saved upon entrance and restored before exiting from the DELETE subroutine, it would contain invalid data upon return to program MAIN.
 - B) The DELETE subroutine must have the first word address of the card image area in the A Register upon entrance to its routine. So program MAIN <u>must</u> obtain the first word address of the card image area into A, before it transfers control to the DELETE subroutine. It does this by an ENA DATACARD.
 - C) Normally a field represented by a double asterisk(**) will be modified during the execution of a program and the double asterisk (**) provides a convenient way to see if the modification took place. (**) presets the field to all 12/s.
 - D) Control is transferred to this instruction if a SRCE, SRCN, or MOVE instruction is already in progress and the search instruction preceding this jump instruction will not be initiated until any previous search or move is completed.
 - E) 1. When a comparison occurs between the search character (nonblank) and a non-blank character in storage.
 - When register file 20 is equal to register file 30 (no nonblank character found).
 - F) The search is to continue until all blank characters are deleted. Upon a find, the search is terminated and register file location #20 contains the address of the find. So to continue the search this address must be updated by 1 or the program will be hung in a loop.

G) Upon exiting from the DELETE subroutine, A will contain the last character address $+\ 1$ of the DATACARD area with all blank characters deleted.

2.	A)	PROG1	PROG2
		1.8	90.2
		1.8	1.8
		3.5	92.0 usec.
		3.5 Repeated 8 times	
		1.8	
		2.6	
		1.8	
	_	1.8	
	1	09.2 usec.	

B) On the above move he saves only 17.2 usec. (approximately 2 usec. per character). On a maximum move of 128 characters, the MOVE instruction would be approximately 256 usec.

	IDENT	PROGRAM
	ENTRY	START
START	SRCE	73B, CARD, CARD+80
	UJP	*- 2
	PAUS	4000B
	UJP	*- 1
	TMA	30B
	LPA	MASK
	SHAQ	24
	TMA	20B
	LPA	MASK
	AQJ,EQ	EXIT
	HLT	
EXIT	ENA,S	+0
	UJP	*- 2
MASK	ØCT	377777
	END	

STORAGE TESTS - ANSWERS

1. A) The program searches a list of operands from LIST thru LIST+7 (10 locations) looking for values that are within or equal to the upper limit in A (200_{10}) and the lower limit in Q (100_{10}). On a find, the addresses of the operands are stored in a table called ADDRESS.

B)	M.L.	Contents of
	ADDRESS	LIST+6
	ADDRESS+1	LIST+5
	ADDRESS+2	LIST+1
	ADDRESS+3	0

- 2. Answer is d; contents of A is not altered.
- 3. The program searches a list of 6 bit characters, from LIST thru LIST+2
 (3 locations) for a 45 code in any character position (0 thru 3) of
 each location. Upon a find, the character address is generated and
 stored into a table called LIST1.

4. START	IDENT ENTRY ENI ENI	PRØGRAM START 17,1 0,2	B ¹ = SIZE ØF TABLE (16) + INTERVAL-1 B ² = ADDRESS CØUNTER
	ENQ	7700B	Q = 00007700 (MASK)
SEARCH	i ena	6200B	
	MEQ	INFØ,2	$INF\emptyset = START \emptyset F TABLE, 2 = INTERVAL$
	UJP	THRU	SEARCH CØMPLETE
	ENA	INFØ	$(A) = 000INF\emptyset$
	AIA	1	$(A) = 000 INF \not O + B^{1}$
	STA	LIST,2	SAVE FIND ADDRESS
	INI	1,2	PREPARE FØR NEXT FIND
	UJP	SEARCH	,
THRU	HLT		
INFØ	BSS	16	
LIST	ØCT	0,0,0,0,0,0	0,0,0

Index register 1 must start with 17_{10} , because it will be decremented by the interval (2) before the search begins. This will start the search at INFØ+15, which is the last location of the table.

BCD OPERATIONS - ANSWERS

02000 0302070602001 10111007

2. $(E)_f = +0822579612899$

3. $(E)_f = +0006193435479$

 $4. \quad (E)_{f} = +0000000009914$

5. $(E)_{f} = +0026711689001$

 $6. \quad 00010 = 07060510$

00011 = 06071011

00012 = 50XXXXXX

 $(E)_{f} = -0000000009568$

7. CHARS T 0 T A
L E Q
U A L
04 05 04
06 10 07 11
11 00 00 XX

 $(E)_{f} = +0000000000000$

(D) = 10_{10} or 12_{B}

8. DATA 51 50 47 46 45 44 XX XX XX XX XX XX XX XX XX XX XX

 $(E)_{f} = +0000000000000$

automatically changes to a ± 0

SUMMARY OF INSTRUCTION EXECUTION TIMES, $\mu sec.$

2.5 ADA 3.8 ADAQ 11.5* ADE 1.3* AEU 1.3 AIA 1.3 ANA	2.5 LDI 2.5 LDL 2.5 LDQ 2.5 LPA 2.5 LQCH
1.3 ANI 1.3 ANQ 1.3 AQA 1.3* AQE 1.9 AQJ 1.9 ASE	4.2 + 4.2n MEQ 3.3 MOVE 4.2 + 4.2n MTH 7.8-11.0 MUA 16.0-21.0* MUAQ
1.9 ASG 1.9 AZJ 1.3-1.7 CINS	3.3 OTAC 3.3 OTAW 3.3 OUTC 3.3 OUTW
1.3-1.7 COPY 2.5-3.4 CPR	2.0 us-40 ms PAUS
1.3 CTI 1.3 CTO 1.3 DINT	1.3* QEL 1.9 QSE 1.9 QSG
11.25 DVA 22.5* DVAQ	3.8 RAD 2.5 RTJ
22.5* DVAQ 1.3* EAQ 1.3 ECHA 1.3 EINT 1.3* ELQ 1.3 ENA 1.3 ENI 1.3 ENQ 1.3* EOJ 1.3* EUA 1.3-1.7 EXS 1.3* EZJ 10.0-12.0* FAD 20.0* FDV 14.0-18.0* FMU 10.0-12.0* FSB — HLT 1.3 IAI 1 IAPR 1.9 IJD 1.9 IJI 1.3 INA 1 INAC 1 INAC 1 INAC 1 INAW 1.3 INCL 1.3 INI 3.3 INPC 3.3 INPW 1.3 INQ 1.3-1.7 INS 1.3-1.7 INTS 1.3-1.7 INTS 1.3 IOCL 1.9 ISD	2.5 RTJ 2.5 SACH 2.5 SBA 3.8 SBAQ 1.3 SBCD 11.5 SBE 2.5 SCA 1.9-3.9 SCAQ 2.5 SCHA 1.3 SCIM *** SEL 1.3* SET 1.3-4.3* SFF 1.3-2.7 SHA 1.3-2.7 SHAQ 1.3-2.7 SHAQ 1.3-2.7 SHQ 1.3 SJ1-6 1.3 SLS 2.5 SQCH 3.3 SRCE 3.3 SRCN 2.5 SSA 3.8 SSH 1.3 SSIM 2.5 STA 3.8 STAQ 8.0* STE 2.5 STI 2.5 STQ 2.5 SWA 1.3 TAI 1.8 TAM 1.3 TIA 1.8 TIM 1.8 TIM 1.8 TIM 1.8 TIM 1.8 TIM
1.9 ISI 2.5 LACH 2.5 LCA 3.8 LCAQ 2.5 LDA 3.8 LDAQ 8.0* LDE	1.8 TMQ 1.8 TQM — UCS 1.3 UJP 1.3 XOA 1.3 XOI 1.3 XOQ

n = number of words searched.

 ⁼ Trapped instruction in computers without the appropriate optional hardware package.
 = Dependent upon interrupt response.
 = Dependent upon a variable signal response time from an external source of equipment.

INSTRUCTION INDEX

BY OCTAL OPERATION CODE					BY MNEMONIC OPERATION CODE				
OCTAL OPERATION CODE	MNEMONIC OPERATION CODE	SECTION NUMBER	OCTAL OPERATION CODE	MNEMONIC OPERATION CODE	SECTION NUMBER	MNEMONIC OPERATION CODE	SECTION NUMBER	MNEMONIC OPERATION CODE	SECTION NUMBER
00.0 00.1 00.2 00.3 00.4 00.5 00.6 00.7 01 02.0 02.1-3 02.4 02.5-7 03.0 03.1 03.2 03.3 03.4 03.5 03.6 03.7 04.0 04.1-3 04.4 04.5 04.6 04.7 05.0 05.1-3 05.4 05.5 05.6 05.7 06.0-7 07.0-7 10.0 10.1-3 10.4 10.5-7 11.0 11.4 12.0-3 12.4-7 13.0-3 13.4-7 14.0 14.1-3 14.4 14.5 14.6 14.7 15.0 15.1-3 15.4 15.5 15.6 15.7 16.0 16.1-3 16.4 16.5 16.6 16.7 17.0 17.1-3 17.4 17.5 17.6 17.7 20 21 22 23 24 25 26 27 30 31 32 33 34 35 36 37	HLT SJ1 SJ2 SJ3 SJ4 SJ5 SJ6 RTJ UJP,I No Operation IJD AZJ,EQ AZJ,NE AZJ,GE AZJ,LT AQJ,EQ AQI,NE AQI,GE AZJ,LT ISE ISE ASE,S QSE,S ASE QSE ISG ASG,S QSG,S ASG QSG MEQ MTH SSH ISI ISD ISD ISD ECHA ECHA,S SHA SHQ SHAQ SCAQ NOP ENI ENA,S ENQ,S ENA ENQ SCAQ NOP ENI INA,S INA INQ,S INA INQ IDA,I LCAC,I LDA,I LCAC,I LDA,I LCAC,I LDA,I SBA,I SCA,I S	3.5.7 on 3.5.7 3.5.2 3.5.2 3.5.2 3.5.2 3.5.2 3.5.3 3.5.3 3.5.3 3.5.3 3.6.1 3.6.1 3.6.1 3.6.1 3.6.1 3.6.1 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.2 3.6.3 3.	40 41 42 43 44 45 46 47 50 51 52 53.01 53.02 53.04 53.(0+b)0 53.(0+b)3 53.(0+b)4 53.41 53.42 53.(4+b)0 53.(4+b)3 53.(4+b)4 54 55.0 55.1 55.2 55.3 55.4 55.5 55.6 66 67 70.0-3 70.4 70.6 70.7 71 71 72 73 77.3 77.4 77.50 77.51 77.52 77.53 77.54-56 77.77 77.77 77.77 77.77 77.77 77.77 77.77 77.77 77.77 77.77	STA,I STQ,I STA,I STQ,I SACH SQCH SWA,I STAQ,I SCHA,I STI,I MUA,I CPR,I TMQ TMA AQA TIA TMI AIA TQM TAM TAI TIM IAI LDI,I NO Operation ELQ EUA EAU AQE MUAQ,I FAD,I FAD,I FAD,I FAD,I FAD,I FAD,I FAD,I FOV,I LDE STE ADE SBE SFE EJJ,EQ EZJ,LT EOJ SET SRCC,INT SRCN,INT MOVE,INT INPC,INT, B,M INAW,INT OUTC,INT, B,M INAW,INT OUTC,INT, B,M OTAC,INT INFW,INT, B,M OTAC,INT OUTW,INT, CON SEL SCOPY INS CONS SING CINS SING CINS SING CINS SING CINS SING CINS CINS CINS COPY INS COP	13.3.1 13.2.1 13.2.1 13.4.1 100 13.3.2 13.4.2 6.3 6.4 12.3.1 12.3.2 12.3.3 12.3.4 14.2.6 14.2.7 14.2.8 14.2.9 14.2.1 14.2.2 14.2.3 14.2.4 14.2.5 10.2.1 10.2.2 10.3 20.6 20.8.1 20.4 20.8.2 20.7 20.8.3 20.5 20.8.4 20.2 20.3 20.9.1 20.9.2 20.9.3 21.2 21.1	ADA,I ADAQ,I ADE AEU AIA ANA ANA,S ANI ANQ ANQ,S AQA AQE AQJ,EQ AQJ,EQ AQJ,LT AQJ,NE ASE,S ASG,S AZJ,EQ AZJ,EQ AZJ,EC CINS CON COPY CPT,I CTO DINT DVA,I DVAQ,I EAQ ECHA ECHA,S EINT ELQ ENA ENA ENA ENA ENA ENA ENA ENA ENA ENA	3.3.1 6.1 14.2.8 13.2.2 9.5.2 7.4.2 7.4.2 7.4.4 7.4.3 9.5.1 13.4.2 3.5.3 3.5.3 3.5.3 3.5.3 3.6.1 3.6.2 3.5.2 3.5.2 3.5.2 20.9.5 20.9 20.9.2 20.9.2 21.4 20.10.5.1 20.10.5.1 20.10.5.2 3.3.4 6.4 13.4.1 8.2.6 8.2.6 21.1-2 13.3.1 3.4.4 3.4.4 13.4.4 14.2.4 13.2.1 20.9.1 14.2.2 14.2.3 12.3.3 12.3.4 12.3.3 12.3.5 9.5.3 3.5.7 3.4.1 3.4.4 13.2.1 20.9.1 14.2.2 14.2.3 12.3.1 12.3.4 12.3.3 12.3.5 9.5.3 3.5.7 3.4.1 3.4.1 20.8.1 20.8.1 20.9.4 20.9.3 3.6.3 3.6.1 3.6.2 3.4.2 20.9.4 20.9.3	LDA,I LDAQ,I LDAQ,I LDE LDI;I LDL,I LDQ,I LPA,I LDQ,I LPA,I LDQH MEQ MOVE,INT MTH MUA,I MUAQ,I NOP OTAC,INT OTAW,INT OUTC,INT, B,H OUTW,INT, B,H PAUS QEL QSE QSE,S QSG QSG,S RAD,I RTJ SACH SBA,I SBAQ,I SBCD SBE SCA,I SCIM SEL SET SFE SFPF SHA SHAQ SHQ SJ1 SJ2 SJ3 SJ4 SJ5 SJ6 SLS SQCH SRCE,INT SRCN,INT SSA,I SSIM STA,I STAQ,I STA	3.1.1 14.2.6 3.1.3 7.2 7.4.1 8.2.2 11.1 10.3 11.2 3.3.3 6.3 20.8.3 20.8.4 20.7 20.5 10.4 & 20.10.5.3 13.3.2 3.6.1 3.6.2 3.3.5 3.5.4 8.2.3 3.3.5 3.5.4 8.2.3 3.3.2 6.2 14.2.9 7.5.1 13.5 8.2.5 20.3 14.2.5 14.2.1 3.8.2 5.3 3.8.2 3.5.6 3.5

CONTROL DATA

1.1/4

► CUT OUT FOR USE AS LOOSE-LEAF BINDER TITLE TAB



CORPORATE HEADQUARTERS, 8100 34th AVE. SO., MINNEAPOLIS, MINN, 55440 SALES OFFICES AND SERVICE CENTERS IN MAJOR CITIES THROUGHOUT THE WORLD